



**(REALTEK RTL8852CE)**

**802.11ax RTL8852CE Combo module**

**Preliminary Version**

**2021/12/16**

## Contents [ [hide](#) ]

### [1 ENVIRONMENTAL](#)

#### [2 Installing the Wireless PCIe NGFF2230 module Hardware](#)

#### [3 Installing the WLAN PCIe & Bluetooth USB NGFF2230 module Software](#)

#### [4 Un-installing the Wireless PCIe NGFF2230 module Software](#)

### [5 Documents / Resources](#)

#### [5.1 References](#)

## ENVIRONMENTAL

### Operating

Operating Temperature: -20°C to +70 °C

Relative Humidity: 5-90% (non-condensing)

### Storage

Temperature: -40°C to +80°C (non-operating)

Relevant Humidity: 5-95% (non-condensing)

### MTBF caculation

Over 150,000hours

### Warning

#### Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device and its antenna(s) must not be co-located with any other transmitters except in accordance with FCC multi-transmitter product procedures. Referring to the multi-transmitter policy, multiple-transmitter(s) and module(s) can be operated simultaneously without C2P.

Operations in the 5.15-5.25GHz band are restricted to indoor usage only.

FCC regulations restrict the frequency 5850-5895MHz operation of this device to indoor use only.

The operation of this device is prohibited on oil platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet.

This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

**§ 15.407(d)(2) Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.**

#### **Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This module is intended for OEM integrators only. Per FCC KDB 996369

D03 OEM Manual v01 guidance, the following conditions must be strictly followed when using this certified module:

**KDB 996369 D03 OEM Manual v01 rule sections:**

#### **2.2 List of applicable FCC rules**

This module has been tested for compliance to FCC Part 15

#### **2.3 Summarize the specific operational use conditions**

The module is tested for standalone mobile RF exposure use condition. Any other usage

conditions such as co-location with other transmitter(s) or being used in a portable condition will need a separate reassessment through a class II permissive change application or new certification.

This module is authorized for client device applications under the control of an indoor access point or subordinate.

The final host product must comply with the following operational restrictions:

a) Cannot have a direct connection to the internet to source the internet to other clients, access points, subordinates or clients from a wired or direct connection.

**This module is authorized for Dual Client (6CD) device applications. The final host product must comply with the following operational restrictions:**

a) Cannot connect directly to any other client device;

b) Cannot source internet/network (obtained via wired connection or other means such as cellular) to other clients, access points and subordinate devices or provide any direct peer to peer connections to other clients or subordinates;

c) Is prohibited for control of or communications with unmanned aircraft systems.

This module is authorized for use in a Very Low Power Device (6VL) device.

**The final host product must comply with the following operational restrictions:**

a) The operation of this device is prohibited on oil platforms and aircraft, except that operation of this device in 5.925-6.425 GHz is permitted in large aircraft while flying above 10,000 feet.

b) Installation on outdoor fixed infrastructure is prohibited.

c) Controlling or communications with unmanned aircraft systems, including drones, is prohibited.

## **2.4 Limited module procedures**

Not applicable.

## **2.5 Trace antenna designs**

Not applicable.

## **2.6 RF exposure considerations**

This equipment complies with FCC mobile radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. If the module is installed in a portable host, a separate SAR evaluation is required to confirm compliance with relevant FCC portable RF exposure rules.

## **2.7 Antennas**

The following antennas have been certified for use with this module; antennas of the same type with equal or lower gain may also be used with this module. The antenna must be installed such that 20 cm can be maintained between the antenna and users.

Ant. t.	Brand	Model Name	Antenna Type	Gain (dBi)		
				WLAN 2.4GHz	WLAN 5GHz/6 GHz	Bluetooth
1	ARISTOTLE	RFA-27-JP378-4B-200	Monopole	3.	5.	3.
2	ARISTOTLE	RFA-27-JP326-MHF4300	PIFA	3.50	5.00	3.50
3	ARISTOTLE	RFA-27-C38H1-MHF4300	Dipole	3.00	5.00	3.00
4	ARISTOTLE	RFA-57-JP697-4B-300	Monopole	–	–5.00	–

## 2.8 Label and compliance information

The final end product must be labeled in a visible area with the following: “Contains FCC ID: TX2-RTL8852CE”. The grantee’s FCC ID can be used only when all FCC compliance requirements are met.

## 2.9 Information on test modes and additional testing requirements

This transmitter is tested in a standalone mobile RF exposure condition and any co-located or simultaneous transmission with other transmitter(s) or portable use will require a separate class II permissive change re-evaluation or new certification.

## 2.10 Additional testing, Part 15 Subpart B disclaimer

This transmitter module is tested as a subsystem and its certification does not cover the FCC Part 15 Subpart B (unintentional radiator) rule requirement applicable to the final host. The final host will still need to be reassessed for compliance to this portion of rule requirements if applicable. As long as all conditions above are met, further transmitter

test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed.

**IMPORTANT NOTE:** In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can. not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

### **Manual Information To the End User**

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.

The end user manual shall include all required regulatory information/warning as show in this manual.

### **OEM/Host manufacturer responsibilities**

OEM/Host manufacturers are ultimately responsible for the compliance of the Host and Module. The final product must be reassessed against all the essential requirements of the FCC rule such as FCC Part 15 Subpart B before it can be placed on the US market. This includes reassessing the transmitter module for compliance with the Radio and EMF essential requirements of the FCC rules. This module must not be incorporated into any other device or system without retesting for compliance as multi-radio and combined equipment.

### **RF Exposure Information (SAR)**

This device has been tested at 5 mm separation distance and meets applicable limits for Radio Frequency (RF) exposure. To ensure RF exposure compliance, the antenna(s) used with the device must be installed in host platforms providing a minimum separation distance 5 mm from the users. Any separation distances less than Smm will require additional evaluation and FCC/ISED authorization.

### **Industry Canada statement:**

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **Radiation Exposure Statement:**

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with greater than 20cm between the radiator & your body.

This device is intended only for OEM integrators under the following conditions: (For module device use)

1. The antenna must be installed and operated with greater than 20cm between the antenna and users, and
2. The transmitter module may not be co-located with any other transmitter or antenna.

As long as 2 conditions above are met, further transmitter test will not be required.

However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed.

#### **IMPORTANT NOTE:**

In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the Canada authorization is no longer considered valid and the IC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate Canada authorization.

#### **End Product Labeling**

This transmitter module is authorized only for use in device where the antenna may be installed and operated with greater than 20cm between the antenna and users.

The final end product must be labeled in a visible area with the following: “**Contains IC: 6317A-RTL8852CE**”.

#### **Manual Information To the End User**

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user’s manual of the end product which integrates this module.

The end user manual shall include all required regulatory information/warning as show in this manual.

ISED regulations restrict the frequency 5850-5895MHz operation of this device to indoor use only.

#### **Caution :**

- (i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;
- (ii) for devices with detachable antenna(s), the maximum antenna gain permitted for devices in the bands 5250-5350 MHz and 5470-5725 MHz shall be such that the equipment still complies with the e.i.r.p. limit;
- (iii) for devices with detachable antenna(s), the maximum antenna gain permitted for devices in the band 5725-5850 MHz shall be such that the equipment still complies with the e.i.r.p. limits as appropriate;
- (iv) where applicable, antenna type(s), antenna models(s), and worst-case tilt angle(s) necessary to remain compliant with the e.i.r.p. elevation mask requirement set forth in section 6.2.2.3 shall be clearly indicated.

### **RSS-248 Issue 3 General statement**

- Devices shall not be used for control of or communications with unmanned aircraft systems.
- Devices shall not be used on oil platforms.
- Devices shall not be used on aircraft, except for the low-power indoor access points, indoor subordinate devices, low-power client devices, and very low-power devices operating in the 5925-6425 MHz band, that may be used on large aircraft as defined in the Canadian Aviation Regulations, while flying above 3,048 metres (10,000 feet).
- Devices shall not be used on automobiles.
- Devices shall not be used on trains.
- Devices shall not be used on maritime vessels.

This radio transmitter [IC: 6317A-RTL8852CE] has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

				Gain (dBi)
			Antenn	



An t.	Brand	Model Name	a Type	WLAN 2.4GHz	WLAN5 GHz / 6GHz	Bluetoot h
1	ARISTOTL E	RFA-27-JP378-4B-20 0	Monopol e	3.38	4.86	3.38
2	ARISTOTL E	RFA-27-JP326-MH43 00	PIFA	3.50	5.00	3.50
3	ARISTOTL E	RFA-27-C38H1-MH43 00	Dipole	3.00	5.00	3.00

### Japan Statement

Host system must be labeled with “Contains MIC ID: xxxxxx”, MIC ID displayed on label.


### CE/UK Statement

This equipment complies with EU radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

The frequency and the maximum transmitted power in EU are listed below:

- 2412-2472MHz: <20 dBm
- 2402-2480MHz (BR/EDR): < 15.90 dBm
- 2402-2480MHz (LE): < 13.15 dBm
- 5180-5240MHz: <23 dBm
- 5260-5320MHz: <23 dBm
- 5500-5700: <23 dBm
- 5745-5825MHz: < 13.98 dBm (For CE only)
- 5745-5825MHz: < 23 dBm (For UK only)
- 5955-6415MHz: <23 dBm

The device is restricted to indoor use only when operating in the 5150 to 5350 MHz frequency range.

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IE
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK

Norway(NO), Iceland(IS), Lichtenstein(LI), Turkey(TR), Switzerland(CH)

## Installing the Wireless PCIe NGFF2230 module Hardware

Installing PCIe NGFF2230 module to PCIe NGFF2230 connector and connect two external Wi-Fi antennas on I-PEX connectors.



Remove 2 external Wi-Fi Antennas from the Wireless PCIe NGFF2230 module board and remove the Wireless PCIe NGFF2230 module board from PCIe NGFF2230 connector port




## Installing the WLAN PCIe & Bluetooth USB NGFF2230 module Software

Before you proceed with the installation, please notice following descriptions.


**Note1:** The following installation was operated under Windows 7.

**Note2:** If you have installed the WLAN driver & utility before, please uninstall the old version first.


A. Execute the “setup.exe”, Click “Next” to process the installation




B. Select “I accept the terms in license agreement” and click “Next” to process the installation




C. Click "Next" button.



D. Select "Complete" and click "Next" button.




E. Click "Install" button.




F. Click "Finish" button.



G. Please click “#”to continue.




H. Please click “#”to continue.



I. Please click “ ”to start installation.



J. Please click “ ”to finish the installation.





## Un-installing the Wireless PCIe NGFF2230 module Software

A. Uninstall the RTL8852CE WLAN Driver from “Start”— “Control Panel”— “Programs”  
Please select items as below and click “Uninstall” to remove RTL8852CE WLAN, BT driver and MP UL.



# REALTEK

Realtek Semiconductor Corp.


No. 2, Innovation Road II, Hsinchu Science  
Park, Hsinchu 300, Taiwan

Tel.: +886-3-578-0211.

Fax: +886-3-577-6047



## Documents / Resources

	<a href="#">Realtek RTL8852CE 11ax RTL8852CE Combo Module [pdf]</a> User Manual TX2-RTL8852CE, TX2RTL8852CE, rtl8852ce, RTL8852CE 11ax RTL8852CE Combo Module, RTL8852CE, 11ax RTL8852CE Combo Module, Combo Module, Module
---	--

## References

- [User Manual](#)

Realtek

11ax RTL8852CE Combo Module, Combo Module, Module, Realtek, RTL8852CE, RTL8852CE 11ax RTL8852CE Combo Module, TX2-RTL8852CE, TX2RTL8852CE

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

---

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.