




reolink RLC-842A IP camera Instruction Manual

[Home](#) » [reolink](#) » reolink RLC-842A IP camera Instruction Manual 

Contents

- [1 reolink RLC-842A IP camera](#)
- [2 What's in the Box](#)
- [3 Camera Introduction](#)
- [4 Connection Diagram](#)
- [5 Set up the Camera](#)
- [6 Mount the Camera](#)
- [7 Install the Camera](#)
- [8 Troubleshooting](#)
- [9 Specification](#)
- [10 Notification of Compliance](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)



reolink RLC-842A IP camera



What's in the Box



Camera



Antenna *



Waterproof Lid




Power Adapter *



1M
Ethernet Cable



4.5M Power *
Extension Cable




Mounting Hole
Template



Surveillance Sign



Quick Start Guide



Pack of Screws





Mounting Wrench

NOTE:



- The power adapter, antennas and 4.5m power extension cable only come with a WiFi camera.
- The quantity of accessories varies with the camera model you purchase.

Camera Introduction

WiFi Camera



PoE Camera




Connection Diagram

Before initial setup, follow the steps below to connect your camera.

1. Connect the camera to a LAN port on cable.
2. Use the power adapter to power on the camera.

NOTE: The connection diagram takes the WiFi Camera as an example and also apply to the PoE camera. For PoE Camera, please power the camera with a PoE Switch/Injector/Reolink PoE NVR or a DC 12V power adapter. (not included in the package)



Set up the Camera

Download and launch the Reolink App or Client software, and follow the onscreen instructions to finish the initial setup.



- On Smartphone
Scan to download the Reolink App.
- On PC Download
path of the Reolink Client: Go to <https://reolink.com> > [Support App & Client](#).
- When setting up the WiFi camera, you need to follow the onscreen instructions to finish the WiFi configuration first.
- If you are connecting the PoE camera to a Reolink PoE NVR, please set up the camera via the NVR interface.




Mount the Camera

Installation Tips



- Do not face the camera toward any light sources.
- Do not point the camera towards a glass window. Or, it may result in poor image quality because of the window glare by infrared LEDs, ambient lights or status lights.
- Do not place the camera in a shaded area and point it towards a well-lit area. Or, it may result in poor image quality. To ensure best image quality, the lighting condition for both the camera and the captured object shall be the same.
- To ensure better image quality, it's recommended to clean the dome cover with a soft cloth from time to time.
- Make sure the power ports are not directly exposed to water or moisture and not blocked by dirt or other elements.

- With IP waterproof ratings, the camera can work properly under
- Do not install the camera at places where rain and snow can hit the lens directly.
- The camera may work in extremely cold conditions as low as -25°C. Because when it is powered on, the camera will produce heat. You may power on the camera indoors for a few minutes before installing it outdoors.

Install the Camera



1. Put the mounting template on the ceiling and drill holes at the
2. Screw the camera to the ceiling. indicated locations.
3. Screw the dome cover off with the mounting wrench.
4. Loosen the two screws on both sides of the camera and adjust the camera viewing angle.



5. Tighten the screws and screw the cover back to the camera.

NOTE: The installation methods take the PoE camera as an example and also apply to the WiFi camera.

Troubleshooting

The camera is not Powering on

If your camera is not powering on, please try the following solutions:

For PoE Camera

- Make sure your camera is powered on properly. The PoE camera should be powered by a PoE switch/injector, a Reolink NVR or a 12V power adapter.
- If the camera is connected to a PoE device as listed above, connect it to another PoE port and check again.
- Try again with another Ethernet cable.

For WiFi Camera

- Plug the camera into a different outlet and see if it works.
- Power on the camera with another working 12V 1A DC adapter and see if it works. If these won't work, contact Reolink Support.

The picture is not clear

If the picture from the camera is not clear, please try the following solutions:

- Check the camera dome cover for dirt, dust or spiderwebs, please clean the dome cover with a soft, clean cloth.
- Point the camera to a well-lit area, the lighting condition will affect the picture quality a lot.
- Upgrade the firmware of your camera to the latest version.
- Restore the camera to factory settings and check it out again.

Specification

Hardware Features

- Infrared Night Vision: Up to 30 meters
- Day/Night Mode: Auto switchover
- The angle of View: Horizontal: 90°~31°, Vertical: 67°~24°

General

- Dimension: $\Phi 133 \times 100$ mm
- Weight: 685g
- Operating Temperature: $-10^{\circ}\text{C} \sim +55^{\circ}\text{C}$ ($14^{\circ}\text{F} \sim 131^{\circ}\text{F}$)
- Operating Humidity: 10% ~ 90%
- For more specifications, visit <https://reolink.com/>.

Notification of Compliance

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The following notes are only for the WiFi cameras. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF warning statement:

The device has been evaluated to meet the general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Simplified EU Declaration of Conformity

Reolink declares that the WiFi camera is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU, the PoE camera is in compliance with Directive 2014/30/EU.

Correct Disposal of This Product

This marking indicates that this product should not be disposed of with other household wastes. throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product

for environmentally safe recycling.

Limited Warranty

This product comes with a 2-year limited warranty that is valid only if purchased from Reolink Official Store or a Reolink authorized reseller. Learn more: <https://reolink.com/warranty-and-return/>.

NOTE: We hope that you enjoy the new purchase. But if you are not satisfied with the product and plan to return, we strongly suggest that you reset the camera to factory default settings before returning it.

Terms and Privacy

Use of the product is subject to your agreement to the Terms of Service and Privacy Policy at reolink.com. Keep out of reach of children.

End User License Agreement



By using the Product Software that is embedded on the Reolink product, you agree to the terms of this End User License Agreement (“EULA”) between you and Reolink. Learn more: <https://reolink.com/eula/>.

ISED Radiation Exposure Statement (For WiFi Version)

The WiFi camera complies with RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. OPERATING FREQUENCY (For WiFi Version) (the maximum transmitted power)

- 2412MHz — 2472MHz (19dBm)
- 5150MHz — 5350MHz (18dBm)
- 5470MHz — 5725MHz (18dBm)

Documents / Resources

	reolink RLC-842A IP camera [pdf] Instruction Manual RLC-842A IP camera, RLC-842A, IP camera, camera
	reolink RLC-842A IP Camera [pdf] User Guide 2201E, 2AYHE-2201E, 2AYHE2201E, RLC-842A, RLC-542WA, RLC-842A IP Camera, RLC-842A, IP Camera, Camera

References

- [ce.com](https://www.ce.com)
- [Reolink: Global Innovator in Smart Home Security and Camera Solutions](#)
- [Reolink: Global Innovator in Smart Home Security and Camera Solutions](#)
- [Reolink: Global Innovator in Smart Home Security and Camera Solutions](#)
- [Reolink® Deutschland: Zuverlässige Sicherheitslösungen im DIY-Stil](#)
- [Garantie & Rückgabe – Reolink](#)
- [Reolink: un innovatore globale nel campo della sicurezza per la casa intelligente e delle soluzioni di videosorveglianza](#)
- [Reolink: un innovatore globale nel campo della sicurezza per la casa intelligente e delle soluzioni di videosorveglianza](#)
- [Garanzia e reso – Reolink](#)

- [🔗 Warranty & Return – Reolink](#)
- [🔗 Reolink Support - Official Reolink Help Center](#)

Manuals+