



## REXING V1 Max Real 4K UHD Single Channel Wi-Fi Dash Camera User Guide

[Home](#) » [Rexing](#) » REXING V1 Max Real 4K UHD Single Channel Wi-Fi Dash Camera User Guide 

REXING V1 Max Real 4K UHD Single Channel Wi-Fi Dash Camera User Guide



## Contents

- 1 Overview
- 2 What's in the box
- 3 Camera Overview
- 4 Screen Icons
- 5 Installation
- 6 Basic Operation
- 7 Documents / Resources
  - 7.1 References
- 8 Related Posts

## Overview

Thank you for choosing REXING! We hope you love your new product as much as we do.

If you need assistance, or have any suggestions to improve it, please contact us. You can reach us via [care@rexingusa.com](mailto:care@rexingusa.com) or call us at (203) 800-4466. Our support team will respond you as soon as possible.

**Always a surprise in Rexing. Check us out here.**

<https://www.facebook.com/rexingusa/>



<https://www.instagram.com/rexingdashcam/>



<https://www.rexingusa.com/support/registration/>




## What's in the box

## 1. Rexing V1 Max Dashboard Camera


1.




## 2. Car Power Connector (12ft)




## 3. 3M Adhesive Mount



## 4. USB Cable




#### 5. User Manual



#### 6. Safety Guide



#### 7. Cable Management Tool



## Camera Overview





1. OK (Confirm) Button / Emergency Lock Button
2. Up Navigation Button / Record Button\*
3. Power Button / Screen Toggle Button
4. Down Navigation Button / Mic Button\*\*
5. Menu Button / Mode Button
6. Micro SD Card Slot
7. Reset Button
8. USB Charging Port
9. Rear Camera Port (Not Support )
10. GPS Logger Port (Built-in GPS Logger)

The camera is recording when the LED is flashing red

The device is charging or powered on when the LED is solid white.


## Screen Icons



## Installation

### Step 1: Install the Dash Cam


Place the 3M tape on the Mount and properly orient the Mount square to the roof and hood line of the vehicle. Important! Ensure the T-interlock on the Mount is oriented in the correct direction.



Firmly press the Mount onto the windshield. Wait at least 20 minutes before mounting the camera.

On the illustration Orient the mount as shown.

### Step 2: Insert the Memory Card




The Rexing V1 Max accepts [Class 10/UHS-1 or higher] Micro SD memory cards up to 256GB. You will need to insert a memory card before you can begin recording. Before inserting or removing a memory card, first ensure you've powered down the device. Gently push the memory card in until you hear a click, and allow the spring release to push the card out.

### Step 3: Power the Camera and Format the Memory Card

Power the camera by connecting the charger to the car cigarette lighter and camera. To ensure the V1 Max records to your memory card properly and without error. Before you start using a new memory card, you must format the card within the camera using the format function. Always backup important data stored on the memory card before formatting.

To format the memory card, make sure you have inserted your memory card, then turn on the device by connecting to a power source. Press REC to stop recording. Then press the MENU button twice to enter the System Setup Menu. Use the REC and MIC buttons and go to the Format setting. Press the OK button to confirm the selection.

You may now disconnect from power. The camera will shut down after 3 seconds. The camera should begin recording automatically the next time it is powered on.



#### Step 4: Installing the Camera onto the Windshield




Place the camera on the mount and carefully route the power cable around the windscreen and tuck in under the trim.

Plug the Car Charger Cable into a 12V DC power outlet or the car cigarette lighter.

Connect car charger to the camera. The camera will auto-start recording once powered on.






## Basic Operation

### Device Power

The device is automatically powered on when plugged into a 12V accessory socket or cigarette lighter and received a charge (i.e.: the vehicle is started).

To turn the device on manually, press and hold the Power button until the welcome screen appears.

The camera will automatically start recording when power on.




### Menu Settings

Power the camera On. If the camera is recording, press the REC button to stop recording.

Hold the MODE button and toggle to the desired mode. Press the MENU button once to enter the settings menu for a Mode. Press the MENU button twice to enter the System Settings (Set up).

## Video Recording

The camera will automatically start recording when the device receives charge. The LED lights and red dot will blink red device when recording. Press the REC button to stop recording.



## EMR Mode

To use the Emergency Record Mode, press the “OK/EMR” button to manually record a 20 second video that is automatically saved and locked.

View EMR recordings by pressing the menu/playback button.

## Video Playback


Playback of videos can be done on the device or a computer.

To playback a video on the device, toggle to the Playback mode. Use the REC and MIC buttons to toggle to the desired video. Press the OK button to play.

During playback use the OK (pause), REC (rewind) and MIC (fast forward) buttons to control the video playback.

**To playback a video on the computer** either use an SD card adapter or connect the device to the computer directly using the USB cable

**To playback a video using an SD card adapter**, remove the memory card and insert it into an SD card adapter. Place the adapter in the computer.



**To playback a video using USB cable**, connect the USB Cable to the device and the computer. After the device powers up, press the OK Button to select Mass Storage.


On the computer, navigate to device drive. The videos are stored at: the “Front xxx” subfolders respectively. Locked videos can be found on the memory card under the “front emr” folder.

### Wi-Fi Connect

Download “Rexing Connect” app from the App Store/Google Play Store.



1. To access or exit the Wi-Fi feature, press the menu button/ play back button twice to access system settings. Find “Wifi” from the list, tap OK Button , set the Wi-Fi feature “ON” and “OFF”. Find “SSID” from the system setting > About.
2. Open Wi-Fi settings on your phone, find “SSID” from the list, tap to connect. (Default password: 12345678)
3. Open the Rexing Connect app, tap “Connect” to enter the realtime video streaming page.



4. Once connected, the dash cam screen will switch to the camera view and will display “WiFi Connected” message. Using the Rexing Connect app, you can view a live preview of the dash cam screen, start / stop recording, as well as view and save your captures with your mobile device.

For further instruction regarding the Wi-Fi Connect feature, please visit [www.rexingusa.com/wi i-connect/](http://www.rexingusa.com/wi-i-connect/).

## GPS Logger

When connected to the camera, it will record the speed and location of your vehicle as you drive.

You can then access this information while playing back your recordings using the GPS Video player (For windows and Mac, available at [rexingusa.com](http://rexingusa.com)).

The dash cam will automatically search for the GPS signal once it's connected to the power source. Press the MENU button twice and go to System Settings. Toggle the GPS Speed Unit setting, and select your favorite speed unit.

After a GPS signal is found, the screen icon will turn from not connected to active – as per the below icons.



GPS function active




GPS Signal  
(not connected)

## Taking Photos

To take a photo, stop video recording and hold down the REC button.

To view a photo, stop video recording and hold on MENU button to the Playback Mode.




### Toggle to the Playback mode and select a photo to view

Press the REC and MIC Buttons to toggle through your photos.

To delete a photo, stop video recording and toggle to the Playback Mode and toggle through the videos and photos to the one you want to delete.

Hold the MENU to toggle the Delete option.


Press the OK Button and select Delete Current or Delete All.









### Toggle to the Delete option



## Documents / Resources

 The image shows the cover of a 'REXING V1 Max Quick Start Guide'. The top part has the 'REXING Dash Cam' logo in white on a black background. Below that, 'V1 Max' is written in a larger font, followed by 'Quick Start Guide'. At the bottom, there are four small icons representing different features: a camera, a Wi-Fi symbol, a GPS symbol, and a car icon.	<p><a href="#">REXING V1 Max Real 4K UHD Single Channel Wi-Fi Dash Camera</a> [pdf] User Guide</p> <p>V1 Max, Real 4K UHD Single Channel Wi-Fi Dash Camera</p>
---	--

## References

-  [Rexing USA | Your Roadside Eyewitness](#)
-  [Dash Cams from Rexing USA - Top Rated Front, Rear and Internal facing Dash Cameras w/ GPS, Wifi Support and more.](#)
-  [Wi-Fi Connect](#)
-  [Wi-Fi Connect](#)
-  [Yuhe Sun \(@rexingdashcam\) • Instagram photos and videos](#)
-  [Rexing USA](#)