



## RGMT RG8051 Locust Automatic Watch Instruction Manual

[Home](#) » [RGMT](#) » RGMT RG8051 Locust Automatic Watch Instruction Manual 

# RGMT

RG8051 Locust Automatic Watch  
Instruction Manual



### LOCUST

#### AUTOMATIC WATCH

This timepiece is equipped with a self-winding Mechanical Automatic movement. It does not need a battery.


It is powered by the motions of the user's own wrist during the wear of the watch. You may also choose to wind the watch manually.

For more details on operating this timepiece please refer to the enclosed booklet or visit : [IM.RGMT.CO](http://IM.RGMT.CO)

## Contents

- [1 RG8051 Locust Automatic Watch](#)
- [2 WINDING THE MAINSPRING](#)
- [3 HOW TO SET THE TIME](#)
- [4 WATER RESISTANCE](#)
- [5 HOW TO CHANGE THE STRAPS TO NATO STRAP](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

## RG8051 Locust Automatic Watch






**PLEASE READ THE FOLLOWING BEFORE UNSCREWING THE CROWN:**


#### **SCREW-DOWN CROWN**

Screw-down crowns are used to ensure water resistance. **ALWAYS** be certain that your crown is securely screwed down ( Position [0] is secured. Positions [1], [2] and [3] are not secured for water resistance ). Do **NOT** unscrew your crown while you are in any environment where moisture is present.




**USING THE SCREW-DOWN CROWN**

DO **NOT** PULL THE CROWN UNLESS IT IS FIRST:



**TO UNSCREW:** Turn the crown anti-clockwise until it turns freely without tension. GENTLY pull the crown out to the other desired positions for watch setting (see specific operating instructions on the following pages).



**TO SCREW:** Push the crown ALL THE WAY IN (towards the watch) THEN begin to turn clockwise until it is securely screwed down.


**NOTE:** Failure to SECURELY screw down the crown after setting the watch may affect its water resistance.

**BEFORE YOU USE THIS WATCH, IT IS RECOMMENDED THAT YOU MANUALLY WIND THE MAINSPRING TO START IT MOVING.**


THIS WATCH IS AN AUTOMATIC WATCH EQUIPPED WITH A MANUAL WINDING MECHANISM.

## WINDING THE MAINSPRING


1. Unscrew the crown by turning it anti-clockwise.



2. When it is in position [1], turn the crown clockwise to wind. Wind 5-10 times and it will start to move naturally after shaking slightly.




3. Push the crown in then screw it securely.



\* This watch **MUST** be worn for at least 8 (Eight) hours each day to ensure it is fully wound. An automatic watch will only wind when the watch is on your wrist and your arm moves. Winding the watch by the crown will put power on the spring but not enough to allow the watch to function fully. If your watch stops overnight or loses time it means it is not being fully wound.

## HOW TO SET THE TIME

1. Unscrew the crown and pull it out to position **[3]**-(2nd click).
2. Turn the crown clockwise to set the correct time.
3. Push the crown in then screw it securely.




\* Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.

\* Always be certain that your crown is **SECURELY SCREWED**; this will prevent moisture from entering in.

## HOW TO SET THE DATE

1. Unscrew the crown and pull it out to position **[2]**-(1st click).
2. Turn the crown anti-clockwise to set the correct date.
3. Push the crown in then screw it securely.



\* Do not set the date between 9:00 P.M. and 4:00 A.M.

## WATER RESISTANCE

The water resistance indicated on your timepiece serves only as a guide. Actual water resistance may vary depending on a number of important factors including temperature, water salinity, and actual use under water. The water resistance of your timepiece may eventually be compromised over time with general wear and tear and the use of your watch under adverse conditions.


Always remember to employ the screw down crown (if available) to maintain the water resistance of your timepiece. Warranty may be voided if the screw down crown has not been properly employed.

Note that you should **NEVER** wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch.

The steam may cause condensation inside your watch, which may affect and damage the inner workings of your watch – which would also not be covered by the warranty.

## HOW TO CHANGE THE STRAPS TO NATO STRAP

1.




2.




3.



5.



4.




7

8

## HOW TO USE A DEPLOYANT CLASP


6.



8.




7.



9.



9





Press the buttons on the clasp sides.



10

## HOW TO RESIZE METAL BRACELET



On the inside of the bracelet, you will see some small arrows engraved on removeable links.





11







12



13



14



15

16



<http://im.rgmt.co>

# RGMT

## Documents / Resources



[RGMT RG8051 Locust Automatic Watch](#) [pdf] Instruction Manual  
RG8051 Locust Automatic Watch, RG8051, Locust Automatic Watch, Automatic Watch, Watch

## References

- [User Manuals - rgmt.co](#)