

Sagemcom Broadband FAST 5290 Fiber Wireless Router **Installation Guide**

Home » Sagemcom Broadband » Sagemcom Broadband FAST 5290 Fiber Wireless Router Installation Guide Table 15

Contents

- 1 Sagemcom Broadband FAST 5290 Fiber Wireless Router
- **2 INSTALLATION AND SAFE USAGE INSTRUCTIONS**
- **3 FEDERAL COMMUNICATIONS COMMISSION (FCC)**
- **STATEMENTS**
- **4 RADIOFREQUENCY INTERFERENCE STATEMENT**
- **5 FCC RADIATION EXPOSURE STATEMENT**
- 6 Documents / Resources
- **7 Related Posts**



Sagemcom Broadband FAST 5290 Fiber Wireless Router



INSTALLATION AND SAFE USAGE INSTRUCTIONS

- 1. Place the router in a vertical orientation on a flat surface.
- 2. Connect the manufacturer supplied AC to DC power adapter. The FAST 5290 router requires the use of a 12VDC, 4.1A power adapter. Only use a manufacturer supplied and approved power adapter, power cord and Ethernet cable. Always first plug the mains adapter lead into the FAST 5290, then the mains lead into the mains adapter, and finally the mains lead into the mains socket. If you do not follow this order of connection, you may get an electric shock. Make sure that the mains lead is properly inserted into the power supply unit, and that it is correctly pushed into the recess. It is very important to push the mains lead until the recess bottom. If it is incorrectly connected this may cause a risk of fire or electric shock.
- 3. Connect the "FAST 5290" to the AC Mains in accordance with the installation instructions in this booklet, and the markings on the identification label (voltage, current, and frequency of electricity network).
- 4. According to installation method required by your ISP:
- 5. Connect the Ethernet cable (provided) to the RJ45 port labeled "wan" on one end and to the Internet access device provided by your ISP on the other end.
- 6. Connect the MoCA cable (provided by ISP) to the coaxial port labeled "MoCA" on one end and to the Internet access device provided by your ISP on the other end.
- 7. For connection of a computer Ethernet cable use one of the RJ45 ports on the product marked «1», «2». Then connect the other end of the Ethernet Cable to the Ethernet port of a computer. Repeat as necessary with the other available Ethernet ports.
- 8. **Battery:** Use to connect to the battery with USC Link cable provided by dedicated battery vendor. This port only used to transmit the signal data.

When using this device, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons including the following:

- Do not use this product near water and avoid contact with moisture. For example, does not use near a bathtub, wash bowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool. Care should be taken so that liquids are not spilled on this equipment.
- 2. This equipment is for indoor use only, do not place or install in an outdoor location.
- Ethernet ports are intended to be connected to indoor cable circuits that are exclusively located within the building where the product FAST 5290 is installed, and don't terminate on a remote equipment earthed to a different earthing network.
- 4. The devices connected to the telephone interfaces must be kept indoor use only.
 - **Caution:** To reduce risk of electric shock, fire or damage to the equipment, do not connect telephone or telecommunications public network into "PHONE" port.
- 5. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- 6. Do not use the telephone to report a gas leak in the vicinity of the leak.
- 7. Make sure the power socket to which you connect the power cord is easily accessible and as close as possible to the equipment so that the appliance can be unplugged quickly in case of a problem.
- 8. Place your product on a firm, solid surface, no obstacle at a minimum distance of 50cm (1.64 feet). If you put it on something unsteady, it may fall and be damaged. If you place it on a soft surface, such as rug, sofa or cushion, the vents may be blocked, causing the product to overheat.
- 9. Never insert objects into the vents of this equipment as this can result in the risk of electrical shock or fire.
- 10. As the power adapter is the only way to connect to the electrical network, the product must be installed near an easily accessed power outlet.
- 11. This equipment should only be operated with the type of power supply (Voltage and Current) indicated on the marking label.
- 12. Do not overload wall outlets or extension cords. Doing so can result in the risk of fire or electrical shock.
- 13. Avoid blocking any vent openings or exhaust exits on this equipment. Do not place equipment in a built-in installation such as a cabinet that may impede the flow of air through the ventilation openings.
- 14. The equipment should be situated away from heat sources such as radiators, heat registers, stoves, or other heat producing appliances and equipment.
- 15. To disconnect this equipment from AC power, unplug the power supply from the AC wall socket.
- 16. Care should be taken to ensure that the power cord is routed, so it is not likely to be walked on or pinched by items placed upon or next to it.
- 17. Unplug this equipment before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning only.
- 18. This equipment is not user serviceable and is to be serviced by qualified personnel only. Do not disassemble this equipment. If service is required, disconnect all power from the equipment and consult qualified service personnel.
- 19. To disconnect this equipment from AC power, unplug the power supply from the AC wall socket.
- 20. Use the product in the environment specified as below:
- 21. Air temperature between 0°C (32 F) and +45°C (113 F).
- 22. Relative humidity between 20% and 90%.
- 23. Altitude: 2743 meters (9000feet) maximum.

FEDERAL COMMUNICATIONS COMMISSION (FCC) STATEMENTS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

MODIFICATIONS

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

FCC Responsible Party: Sagemcom USA

• 14651 N. Dallas Parkway Suite 900

• Dallas, TX 75254 Phone: 972-674-4100

RADIOFREQUENCY INTERFERENCE STATEMENT

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1. Reorient or relocate the receiving antenna.
- 2. Increase the separation between the equipment and receiver.
- 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.

FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This device produces radio frequency energy in the 2.4GHz, 5GHz and 6GHz spectrum. The antenna must be positioned to keep a minimum distance of 50cm(1.64 feet) from the radiating element to any nearby person. North American Cable installer: This reminder is provided to call the your attention to Section 820.93 of the National Electric Code (Section 54 of the Canadian Electrical code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the c able ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

FCC regulations restrict the operation of this device to indoor use only.

The operation of this device is prohibited on oil platforms, cars, trains, boats, and aircraft.

Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or Communications with unmanned aircraft systems.

- Issued by Sagemcom Broadband SAS
- Sagemcom Broadband
- 250, route de l'Empereur 92500 RUEIL MALMAISON
- FRANCE
- © Sagemcom Broadband SAS 2022
- All rights reserved. Subject to availability.
- · Rights of modifications reserved.

• www.sagemcom.com

Documents / Resources



<u>Sagemcom Broadband FAST 5290 Fiber Wireless Router</u> [pdf] Installation Guide FAST5290V2, VW3FAST5290V2, FAST 5290 Fiber Wireless Router, FAST 5290, FAST 5290 R outer, Fiber Wireless Router, Wireless Router, Fiber Router

Manuals+,