


sengled BT006 Intelligent Lighting Module



sengled BT006 Intelligent Lighting Module User Manual

[Home](#) » [Sengled](#) » sengled BT006 Intelligent Lighting Module User Manual 

Contents

- 1 [sengled BT006 Intelligent Lighting Module](#)
- 2 [Product Information](#)
- 3 [Product Usage Instructions](#)
- 4 [Introduction](#)
- 5 [General information](#)
- 6 [Definition of Pins](#)
- 7 [FCC Statement](#)
- 8 [OEM Guidance](#)
- 9 [FAQ](#)
- 10 [Documents / Resources](#)
 - 10.1 [References](#)

sengled

sengled BT006 Intelligent Lighting Module



Product Information

Specifications

- **Frequency Range:** 2402 ~ 2480 MHz
- **BLE Speed:** 1Mbps
- **Memory:** 64kBytes SRAM, 512KBytes Flash
- **TX Power:** 5.33dBm
- **Antenna:** PCB antenna, Gain: 2.0dBi

Product Usage Instructions

Installation

- Ensure the module is securely connected to the appropriate device or circuit following the pin definitions.

Pairing

- Enable Bluetooth on your smart device and search for available devices. Pair the BT006 module by following the on-screen instructions.

Control

- Utilize the module for LED lighting control, smart device switching, remote controlling, or other smart home applications.

Maintenance

- Keep the module away from water or moisture. Clean with a dry cloth if necessary.


Introduction

- BT006 intelligent lighting module is a Bluetooth low-power module based on the PHY6222QC chip.
- The Bluetooth module with BLE mesh networking function, Peer to peer satellite network communication, using Bluetooth broadcast for communication, can ensure timely responses in case of multiple devices.
- It is mainly used in intelligent light control. It can meet the requirements of low power consumption, low delay and short distance wireless data communication.
- Use for LED Lighting control, Smart Devices Switch, Remote Control or other Smart Home device.

General information

1. **The frequency range** is 2402 ~ 2480 MHz
2. **BLE 1Mbps** , Built-in 64kBytes SRAM, 512KBytes Flash,
3. **Class 1 supported with** 5.33dBm maximum TX power
4. **Host Controller Interface (HCI)** over UART
5. **PCB antenna, Gain:** 2.0 dBi

Definition of Pins



Pin NO.	Name	Type	Description
1	GND	P	Ground
2	IO3	I/O	GPIO3, i2c_SCL
3	IO2	I/O	GPIO 2, i2c_SDA
4	IO1	I/O	GPIO 1
5	RX2	I/O	RX2_P0
6	TX2	I/O	TX2_P2
7	IO	I/O	i2c_SCK_P3
8	VDD	P	3.3v Power
9	GND	P	Ground
10	VDD	P	3.3v Power
11	IO	I/O	ADC_P11
12	IO4	I/O	GPIO 4
13	IO5	I/O	GPIO5
14	N/C	I	I
15	IO	I/O	i2c_SDA_P20
16	GND	P	Ground

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

Caution: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

FCC Label Instructions

If using a permanently affixed label, the modular transmitter must be labeled with its own FCC identification number, and, if the FCC identification number is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module. This exterior label can use wording such as the following: "Contains FCC ID: 2AGN8-BT006". Any similar wording that expresses the same meaning may be used. The Grantee may either provide such a label, an example of which must be included in the application for equipment authorization, or, must provide adequate instructions along with the module which explain this requirement.

ISED RSS Warning/ISED RF Exposure Statement

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference,
2. This device must accept any interference, including interference that may cause undesired operation of the device.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

OEM Guidance

Applicable FCC rules

- This device complies with part 15.247 of the FCC Rules.
- **The specific operational use conditions**
- This module can be used in IoT devices. The input voltage to the module is nominally 3.3 V
- DC. The operational ambient temperature of the module is 0 °C ~ 40 °C.
- The external antenna is allowed, such as a PCB antenna.
- **Limited module procedures**

- N/A

- **Trace antenna designs**

- N/A

RF exposure considerations

- The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.
- If the equipment is built into a host for a portable usage, the additional RF exposure evaluation may be required as specified by 2.1093.

Antennas

- **Antenna type:** PCB antenna; Peak antenna gain: 2 dBi

Label and compliance information

- An exterior label on OEM's end product can use wording such as the following: "Contains Transmitter Module FCC ID: 2AGN8-BT006" or "Contains FCC ID: 2AGN8-BT006"

Information on test modes and additional testing requirements

- The modular transmitter has been fully tested by the module grantee on the required number of channels, modulation types, and modes, it should not be necessary for the host installer to re-test all the available transmitter modes or settings.
- It is recommended that the host product manufacturer, installing the modular transmitter, perform some investigative measurements to confirm that the resulting composite system does not exceed the spurious emissions limits or band edge limits (e.g., where a different antenna may be causing additional emissions).
- The testing should check for emissions that may occur due to the intermixing of emissions with the other transmitters and digital circuitry or due to the physical properties of the host product (enclosure).
- This investigation is especially important when integrating multiple modular transmitters where the certification is based on testing each of them in a stand-alone configuration.
- It is important to note that host product manufacturers should not assume that because the modular transmitter is certified, they do not have any responsibility for final product compliance.
- If the investigation indicates a compliance concern, the host product manufacturer is obligated to mitigate the issue. Host products using a modular transmitter are subject to all the applicable individual technical rules as well as to the general conditions of operation in Sections 15.5, 15.15, and 15.29 to not cause interference. The operator of the host product will be obligated to stop operating the device until the interference has been corrected.
- The final host/module combination needs to be evaluated against the FCC Part 15B criteria for unintentional radiators to be properly authorized for operation as a Part 15 digital device.


Additional testing, Part 15 Sub part B disclaimer

- The host integrator installing this module into their product must ensure that the final composite product complies with the FCC requirements by a technical assessment or evaluation of the FCC rules, including the transmitter operation and should refer to guidance in KDB 996369. For host products with certified modular transmitter, the frequency range of investigation of the composite system is specified by rule in Sections 15.33(a)(1) through (a)(3), or the range applicable to the digital device, as shown in Section 15.33(b)(1), whichever is the higher frequency range of investigation.
- When testing the host product, all the transmitters must be operating. The transmitters can be enabled by using publicly available drivers and turned on, so the transmitters are active.
- In certain conditions it might be appropriate to use a technology-specific call box (test set) where accessory 50 devices or drivers are not available.
- When testing for emissions from the unintentional radiator, the transmitter shall be placed in the receive mode or idle mode, if possible.
- If receive mode only is not possible, then the radio shall be passive (preferred) and/ or active scanning.
- In these cases, this would need to enable activity on the communication BUS (i.e., PCIe, SDIO, USB) to ensure the unintentional radiator circuitry is enabled.
- Testing laboratories may need to add attenuation or filters depending on the signal strength of any active beacons (if applicable) from the enabled radio(s). See ANSI C63.4 and ANSI C63.10 for further general testing details.
- The product under test is set into a link/association with a partnering device, as per the normal intended use of the product.
- To ease testing, the product under test is set to transmit at a high duty cycle, such as by sending a file or streaming some media content.

FAQ

- **Q: What should I do if the module is not connecting to my smart device?**
 - **A:** Make sure the module is powered on and in pairing mode. Check your smart device's Bluetooth settings and try again.
- **Q: Can I control multiple devices with one BT006 module?**
 - **A:** Yes, the BT006 module supports BLE mesh networking for communication with multiple devices.

Documents / Resources

	<p>sengled BT006 Intelligent Lighting Module [pdf] User Manual BT006, 2AGN8-BT006, 2AGN8BT006, BT006 Intelligent Lighting Module, BT006, Intelligent Lighting Module, Lighting Module</p>
---	---

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.