



# sensi PMS 2151 C Temperature and Humidity Sensor Instruction Manual

[Home](#) » [sensi](#) » sensi PMS 2151 C Temperature and Humidity Sensor Instruction Manual 

## Contents

- [1 sensi PMS 2151 C Temperature and Humidity Sensor](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Connecting your sensor is quick and easy](#)
- [5 FCC STATEMENT](#)
- [6 CONTACT](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)



**sensi PMS 2151 C Temperature and Humidity Sensor**



## Product Information

The product is a sensor that can be connected to a thermostat for temperature and humidity control. It allows users to prioritize specific rooms or sensors for temperature and humidity settings. The sensor complies with FCC RF radiation exposure limits and Industry Canada license-exempt RSS standards.

## Product Usage Instructions

### Connecting the Sensor

- On the thermostat, select the Menu button in the top left corner.
- Select Remote Sensors.
- Click Add Sensor in the upper right-hand corner.
- Follow the step-by-step instructions.

### Placing the Sensors

- Position the sensor in one of three ways.
- Avoid placing it in areas that receive direct sunlight or near vents, doors, and drafty windows.
- If wall mounting, try to avoid exterior walls.

### Controlling the Sensors

- After installing the sensors, by default, there will be a checkmark next to each sensor and the thermostat in the mobile app.

- This means that temperature settings will heat and cool to an average reading across all selected devices.
- To prioritize the temperature and humidity of a certain room or sensor, ensure only the sensors you want to prioritize are selected in the mobile app.

## Reading the Sensors

- The temperature and humidity shown on the top of your mobile app screen will display the balanced reading across all selected devices in your home.


If you need further assistance, visit [sensihelp.com](https://sensihelp.com) for support.

## Connecting your sensor is quick and easy

1. On your thermostat, select the Menu button in the top left corner
2. Select Remote Sensors
3. Click Add Sensor in the upper right hand corner
4. Follow the step-by-step instructions

## PLACING YOUR SENSORS

You can position your sensor one of three ways:




- Mount on the wall using the enclosed hardware.
- Assemble the enclosed stand by sliding the sensor onto the base and snapping into place
- Simply place the sensor on a flat surface such as a table or shelf

**Tip:** Make sure not to place in an area that receives direct sunlight or near a vent, doors and drafty windows. If wall mounting, try to avoid the exterior walls of your home.

## CONTROLLING YOUR SENSORS

- After installing your sensors, by default, there will be a checkmark next to each sensor and the thermostat in the mobile app. This means that your temperature settings will heat and cool to an average reading across all selected devices.
- To prioritize the temperature and humidity of a certain room or sensor, ensure only the sensors you want to prioritize are selected in the mobile app.

## READING YOUR SENSORS



- The temperature and humidity shown on the top of your mobile app screen will display the balanced reading across all selected devices in your home.

## We're here to help

- Visit: [sensihelp.com](https://sensihelp.com)

The Sensi logo is a trademark and service mark of Emerson Electric Co. ©2022

## FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **RF EXPOSURE**

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter and must be installed to provide a separation distance of at least 20cm from all persons. The FCC grant can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: 2A4JN-RS01-SG5468

## **IC NOTICE**

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference
2. this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

**IC ID:** 28229-RS01SG5468

## **INK COLORS**



- PMS 2151 C


**ALL OTHER COLORS:** CMYK

CONTACT

- 0037-7871003
- [sensihelp.com](https://sensihelp.com)



Documents / Resources

	<a href="#">sensi PMS 2151 C Temperature and Humidity Sensor</a> [pdf] Instruction Manual 2A4JN-RS01-SG5468, 2A4JNRS01SG5468, PMS 2151 C Temperature and Humidity Sensor, Temperature and Humidity Sensor, Humidity Sensor, Sensor
---	--

References

- [S Sensi Thermostat & Product Support | Sensi US](#)