



Sharper Image 3×3 Portable Smartphone Printer 207126 User Manual

[Home](#) » [Sharper Image](#) » Sharper Image 3×3 Portable Smartphone Printer 207126 User Manual 




Thank you for purchasing the Sharper Image 3×3 Portable Smartphone Printer. Please read this guide and store it for future reference.

Note: *This printer has a built-in battery. Charge the printer before using.*

Contents

- 1 HOW TO CHANGE CARTRIDGE
- 2 INSTALLATIONAndroid devices
- 3 CONNECTING TO PRINTER
- 4 PRINTING IN THE APP
- 5 LED INDICATOR
- 6 TROUBLESHOOTING
- 7 WARRANTY / CUSTOMER SERVICE
- 8 Related Posts

HOW TO CHANGE CARTRIDGE



INSTALLATION

Android devices

A TYPE *NFC Support for Android devices only

1. Turn NFC on in your smartphone
2. Turn the printer on by pressing the power button
3. Tap the phone icon on the top of the printer. The Google Play Store app installation page will show up
4. Install the app on your smartphone from the store



B TYPE

1. Go to the Google Play Store on your smartphone
2. Search "SI Portable Printer"
3. Install "SI Portable Printer" on your smartphone

APPLE DEVICES

1. Go to the App Store on your iPhone, iPod touch or iPad

2. Search "SI Portable Printer"
3. Install "SI Portable Printer" on your smartphone


CONNECTING TO PRINTER

Wi-Fi Access Point (AP) *Apple and Android devices

1. Turn on Wi-Fi on your smartphone
2. Go to Wi-Fi settings and find "SI Portable Printer" *Printer names may vary. They are alphanumeric and 4 characters long
3. Password is "12345678"
4. Select the Wi-Fi network and connect the printer

NFC and Wi-Fi Direct *NFC, Wi-Fi Direct support devices only

1. Turn on NFC and Wi-Fi on your smartphone *Set the NFC setting as P2P mode
2. Tap your device on the printer where the logo is
3. Within 20 seconds the app will automatically connect to Wi-Fi Direct




PRINTING IN THE APP



APP LAUNCH



SELECT CHOOSE PHOTO



CHOOSE PHOTO



SELECT PRINT NUMBER




SELECT PRINTER



** SELECT SNS IF YOU WANT TO PRINT THE PHOTO FROM IT

LED INDICATOR

STATUS	
POWER ON	WHITE
POWER OFF (2SEC)	OFF
PRINTING	WHITE FLICKERING
F / W UPGRADE	PINK FLICKERING
NO CARTRIDGE	RED FLICKERING
ERROR (PAPER JAM, ETC.)	RED FLICKERING
WAITING / COOLING	WHITE

TROUBLESHOOTING

STATUS	
CHARGING	RED
CHARGING COMPLETE	GREEN

SYMPTOM	CAUSE / SOLUTION
PAPER JAM	POWER OFF AND POWER ON AGAIN. PAPER WILL BE AUTOMATICALLY EJECTED. IF NOT, PLEASE CONTACT CUSTOMER SERVICE.
IMAGE QUALITY IS NOT GOOD	PRINT QUALITY COULD BE LESS IF YOUR PHOTO SOURCE HAS LOW RESOLUTION. OVER 1280 X 2448 PIXELS IS RECOMMENDED FOR BEST IMAGE QUALITY.
PRINTER IS NOT RESPONDING	PRESS RESET BUTTON WITH A SHARP TOOL LIKE A PIN.

WARRANTY / CUSTOMER SERVICE

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 (877) 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

SHARPER IMAGE

The SHARPER IMAGE® name and logo are registered trademarks.

©Sharper Image. All Rights Reserved.

[Sharper-Image-3x3-Portable-Smartphone-Printer-207126-Manual](#)

Optimized PDF

[Sharper-Image-3x3-Portable-Smartphone-Printer-207126-Manual-Original](#)

Download