



Shenzhen Mifang Network Technology ID205G Smart Watch User Guide

[Home](#) » [Shenzhen Mifang Network Technology](#) » Shenzhen Mifang Network Technology ID205G Smart Watch User Guide 

Contents

- 1 [Shenzhen Mifang Network Technology ID205G Smart Watch](#)
- 2 [Getting Started](#)
- 3 [Setting up Your Watch](#)
- 4 [Disassembling/Assembling Your Watch](#)
- 5 [Wearing Your Watch](#)
- 6 [Using Your Watch](#)
- 7 [App Interfaces](#)
- 8 [Getting to Know Your Watch](#)
- 9 [Function Introduction](#)
- 10 [FAQS](#)
- 11 [Important Safety Instructions](#)
- 12 [Documents / Resources](#)
- 13 [Related Posts](#)


SHENZHEN

Shenzhen Mifang Network Technology ID205G Smart Watch



Getting Started

What's in the box



What's in this document


This manual gets you started quickly with setting up your watch. Setup ensures that your watch can synchronize its data with the VeryFitPro app, where you can get detailed information on your stats, view historical trends, log sleep, and more. As soon as setup is complete, you're ready to start moving. The remainder of the manual walks you through every function on your ID205G.

Setting up Your Watch

Charging your watch

Please fully charge your watch before initial use.

1. Insert the USB plug of the charging cable into the USB port on your computer or a UL-certified USB wall charger.
2. Hold the other end of the charging cable near the port on the back of the watch until it attaches magnetically.
3. Make sure the pins on the charging cable lock securely with the port. The connection is secure when the watch vibrates and the battery icon with percent charged appears on the screen.



4. When the watch shows that the battery is low, connect the watch to a USB port with 5V-500mA. While the watch charges, there is a battery progress bar on the screen and you can tap the touch key to check the battery level.

20% Remove the watch from the power supply once fully charged. USB charger requirement: DC USB port (5V-500mA) Charging time: 1.5-2 hours



Disassembling/Assembling Your Watch

Disassembly

1. To remove the wristbands, turn over the watch and find the quick-release lever.
2. While pressing the quick-release lever inward, gently pull the wristband away from the watch to release it.



3. Repeat on the other side.

Assembly

1. To reattach the wristbands, slide the pin (the side opposite the quick-release lever) into the notch on the watch. Attach the wristband with the clasp to the top of the watch.



2. While pressing the quick-release lever inward, slide the other end of the wristband into place.




3. When both ends of the pin are inserted, release the quick-release lever.

Wearing Your Watch


All-day wear and exercise

For all-day wear when you're not exercising, wear the device on your wrist horizontally, a finger's width below your wrist bone and lying flat, the same way you would put on a watch. For optimized heart rate tracking, keep these tips in mind:

1. Experiment with wearing the watch higher on your wrist during exercise. Because the blood flow in your arm increases the farther up you go, moving the watch up a couple of inches can improve the heart rate signal. Also, many exercises such as bike riding or weight lifting require you to bend your wrist frequently, which is more likely to interfere with the heart rate signal if the watch is lower on your wrist.



2. Do not wear your watch too tight. A tight band restricts blood flow, potentially affecting the heart rate signal. This being said, the watch should also be slightly tighter (snug but not constricting) during exercise than during all-day wear.



Using Your Watch

App Installation

Use the watch with our customized VeryFitPro app. You can download VeryFitPro from Apple Store/ Google Play or scan the QR codes below to download.



Notes:

- The VeryFitPro app is only compatible with smartphones not tablets or PCs.
- Smartphone operating system should be iOS 8.0/ Android 4.4 or higher; the Bluetooth version should be 4.2 or

higher.

Smart Phone System Requirements

- iOS 8.0 & higher
- Android 4.4 & higher
- Bluetooth 4.2 & higher

App Interfaces




Home page
(Swipe down the page to sync data from the watch to your phone)



Details




Device



User


Pairing the Watch with Your Phone

Please pair the watch with your phone in the VeryFitPro app, NOT in the Bluetooth settings of your phone.



Pair the watch with your smartphone in the VeryFitPro app Do NOT pair the watch with your smartphone in your phone's Bluetooth settings

1. Enable the Bluetooth of your smartphone.
2. Open the VeryFitPro app on your smartphone and go to the "Device" page, tap "Pair device", then your smartphone starts searching devices.
3. In the list of found devices that appear on your smartphone, tap "ID205G" to connect the watch to your smartphone. (If your phone failed to find ID205G, please search the watch on your smartphone again.)



Notes:

- Once the watch is connected to your app, the watch will automatically search and reconnect itself if the connection is lost or when Bluetooth is restarted after manual disconnection.
- If the watch is unbound from the app, the information on the watch will be reset, and the information on the app will be geared.
- Please do not unbind the connection unless there is an issue that will require a reset.
- The watch can only pair with one smartphone at a time. When pairing, please ensure the watch and your smartphone is within 0.5 meters distance.

Getting to Know Your Watch

Function Button



- Press the function button to wake the screen or return to the previous interface.
- Press and hold the function button to turn on the watch.

Watch Interfaces

- This is a touch screen; swipe the screen to go to different
- interfaces, and tap to enter the function.

The home screen is the clock. On the clock:

- Swipe down to see notifications.
- Swipe up to see yOur dany slais.
- Swipe left to see the function list.
- Swipe right to see the status bar (automatic heart rate monitoring, wrist sense, non disturb mode, find phone).



fig. 1

After the watch is bound to the app, the home screen will display the time and date as shown in fig. 1.



You can customize the home screen by following the steps Below

1. Tap and hold the home screen
2. Swipe down to choose one and tap to com.

Note:

Besides the 3 default home screen choices on the watch, you can also customize your home screen by choosing one in the app or from your phone album ('Device" page "Dial setting")

Wake a Dimmed Screen

To conserve power, the watch has a standby mode in which the screen turns off. To wake the screen, turn your wrist towards you or press the function button.

Function Introduction



Sport Heart rate Relax Tracks your exercise data in up to 14 sports modes, heart rate automatically Choose the modes that Track your real-time Guides your breathing for relaxation.



and continuously. you want to display on the watch in the app. Alarm Music Controller Timer Set alarms in the app to have the watch vibrate Control the music Timing and countdown. playing of your smartphone.



to wake you up, take pills, and more Sports Recond Setting Weather Weather forecast for the last Your recent sports record. Some basic settings of the watch. three days. Weather data is obtained through your phone's network. Connect the watch to your phone to timely update weather data.

Tracking Sports

The watch tracks your exercise data in up to 14 sports modes. You can set up to 8 different sports modes from among 14 sports modes in the app to display on the watch screen ("Device" page "More" "Activity display").

Start a sport

Tap “Sport” Swipe the screen to view sports modes Tap the sport you choose to start.

During sports

Swipe the screen left/right to flip through exercise data. Press the function button to pause/resume the sport.



End the sport

Press and hold the function button to end the sport Tap “” to confirm. (For swimming, press the function button to pause and then press and hold the function button to end.) Exercise data is displayed after the exercise has ended. Swipe up the screen to flip through exercise data:



Notes:

The watch automatically recognizes and records your run and walk. When the function is enabled in the app (“Device” page “Enable/disable activity mode” “Automatically detect activity”) and the watch recognizes your run/walk, the watch will prompt you to confirm. When confirmed, the watch enters the running/walking sports mode. Data of exercises less than 1 minute will not be saved.

Using GPS

The watch includes a GPS receiver to track your route during several activities, including Outdoor run, Outdoor walk, Outdoor cycle, and Hiking. On your watch, GPS data is shown in a map view along with the stats tracked during the activity. When you select a run or exercise that uses GPS, the watch begins searching for a GPS signal. As with any GPS device, a signal is likely to be discovered more quickly if you are outside in an open area and standing still. For best results, wait for the signal to be discovered before you start your activity. If you don’t want to wait for the GPS signal to be discovered, tap the skip icon” to move to the activity screen and get started. But your movement route cannot be displayed before successful positioning. Sport starts after successful positioning or skipping, positioning



Notes:

- GPS is required for calculating your distance in the Outdoor cycle, Please wait for successful GPS positioning before starting cycling.
- You can also use your phone’s GPS to track your pace and distance during walks, runs, rides or hikes, while mapping out your route on your phone (take your phone with you to use your phone’s GPS during exercise).



In the app, tap and will pop up. Tap to enter running mode directly or tap to choose another sports mode. After entering the running mode, the app will track and map your run distance (using your phone's GPS). After the exercise, you can effortlessly check your exercise data in both the app and the watch.

Add a virtual running competitor

In the Outdoor run mode, you can set a virtual running competitor and the competitor's running pace, and check the gap between yourself and the competitor in real-time to improve your running performance more effectively.

1. Swipe to the function list and tap "Sport".
2. Find "Outdoor run" and tap to choose it. The watch starts GPS positioning.
3. Wait for GPS positioning to succeed.
4. Tap "Customise" to set the competitor's pace and running duration as prompted.
5. Tap "to start your running with a competitor. You can view the running pace of you and the competitor on the watch during the exercise.
6. Press and hold the function button to end the sport Tap "" to confirm.



Monitoring Heart Rate

The watch tracks your real-time heart rate automatically and continuously. You can also view your detailed heart rate data on the watch screen or in the app.

Notes:

To monitor heart rate more accurately, wear the watch on the upper position of your wrist and a bit tighter than usual when you exercise. In addition, complete your profile in the app. Automatic heart rate monitoring is ON by default, monitoring heart rate all day automatically. You can disable/enable automatic heart rate monitoring on the watch (swipe the watch screen right to come to the status bar), or in the app ("Device" page "Heart Rate Detection").



Notes:


- To monitor heart rate more accurately, wear the watch on the upper position of your wrist and a bit tighter than usual when you exercise. In addition, complete your profile in the app.
- Automatic heart rate monitoring is ON by default, monitoring heart rate all day automatically. You can disable/enable automatic heart rate monitoring on the watch (swipe the watch Screen right to come to the status bar), or in the app ("Device" page "Heart Rate Detection").

Relaxing



Tap to start the relaxing Press the function button to end the relaxing Tap "" to confirm.

Controlling Phone Music



1. Go to the "Device" page in the app and tap "Music Control".
2. Enable the function and tap "" to save your settings.
3. Tap "Music Controller on the watch screen to enter the function and control the music playing on your phone.

Note:

You can only control the music player that's running on your smartphone.

4. Setting Alarms

1. Go to the "Device" page in the app and tap "Alarm Alert".
2. Tap "+" to add an alarm.
3. Tap the alarm, then set the alarm type, repeat type and time.
4. Tap "" to save your settings. You can tap the alarm you set on the watch screen to enable/disable the alarm.

5. Tracking Sleep

The watch automatically tracks your sleep duration (Deep Sleep, Light Sleep, and Waketime) and consistency with a comprehensive analysis of sleep quality data so you can see your sleep trends and improve your routine. You can check your detailed sleep data in the app.

More Functions

Call Notification When there is an incoming call, the watch vibrates to alert you, and the screen displays the caller ID. Tapon the watch screen to reject the call,



Notes:

- Only when “Call alert” is enabled in the app (Device” page Call Alert) will calls be notified. (After enabling/disabling the Call Alert function, tap”* to save your settings.) When “Nondisturb mode” is enabled in the app (“Device” page “More “Non disturb mode”), calls will not be notified on the watch during the do-not-disturb period.

Message Notification



When messages (SMS, Facebook, WhatsApp, Twitter, Instagram, Facebook Messenger, Linkedin, Email, Mail, Calendar, and more) come in, the watch vibrates to alert you, and the screen displays the message content.

Notes:

Only when “SNS Alert” is enabled in the app (“Device” page “SNS Alert”- “Allow notifications”), will messages be notified. (After enabling/disabling the SNS Alert function, tap “” to save your settings.) When the “Non disturb mode” function is enabled in the app (“Device” page “More “Non disturb mode”) or on the watch (Status bar the watch during the do-not-disturb period.the watch during the do-not-disturb period. messages will not be notified on

Women’s Health Tracking

The watch reminds you of your important days like your menstrual period and safe period at the time you set when you enable the function in the app (‘Device” page -“Health care”).

Sedentary Reminder

The watch vibrates to remind you to get up and move around when you have been sitting too long (“Device” page “Sedentary Alert”, enable the Sedentary Alert function and set the remind interval.)

Note:

You can use the find phone function only when it is enabled in the app.

Find Phone

You can use the watch to locate your phone by making your phone vibrate or ring when the distance between your phone and the watch is within 10 meters (33 feet).

1. Go to the "Device" page "More" "Find my Phone" in the app and enable the function.
2. Swipe the watch screen right to come to the status bar and tap to use the function.

Basic Specifications

- Model No. I0205G
- Sync: Bluetooth 4.2
- Screen: 1.3" TFT LCD
- Battery Capacity: 210mAh
- Working Voltage: 3.8V
- Working Temperature: -10C to 40C
- Weight: 1.27oz (36g)
- Waterproof Rating: 5ATM
- Working Time: about 5-7 days not using GPS
- about 8 hours using GPs
- Standby Time: about 30 days when fully charged

FAQS

1. Failure to find the watch when pairing

Make sure your smartphone's Bluetooth is enabled and your smartphone's system meets the requirements of Android 4.4 or higher, iOS 8.0 or higher, and Bluetooth 4.2 or higher.

2. Make sure the distance between your smartphone and the watch does not exceed 0.5 meters and that Bluetooth communication is also within range (10 meters max).
3. Make sure your watch has enough battery life. If there is still a problem after being fully charged, please contact us.
4. Occasional failure to connect with Bluetooth Reboot your smartphone or restart your smartphone's Bluetooth.
5. Failure to receive SMS/ calls notifications The calls/SMS notification function works when the watch connects to your smartphone via the app. Please kindly refer to

the following tips:

1. Go to your smartphone Settings, find the VeryFitPro app and enable the Location and all Notifications.
2. Enable your phone's Bluetooth and go to the VeryFitPro app to bind the watch.
3. Enable the Call / SNS Alert function, and tap to save your settings.

Failure to connect to a smartphone

The watch will disconnect from your smartphone in the following cases:

1. Smartphone Bluetooth is off or exceeds the Bluetooth connection range (the maximum Bluetooth connection

range is 10 meters and can easily be reduced by walls, furniture, etc.)

2. The VeryFitPro app is closed on the phone. (This can occur automatically under certain circumstances.) To reconnect the watch to your smartphone, please kindly take the following steps:
3. Go to your smartphone system Settings, find the VeryFitPro app and enable the Location and all Notifications.
4. . Clear all running/ background processes on your smartphone. Go to the VeryFitPro app and swipe down "Mainpage", then the watch will reconnect to your smartphone and update data. You can also restart your smartphone and Bluetooth, then rebind the watch in the app.
5. GPS signal missing Environmental factors, including tall buildings, dense forest steep hills, and even thick cloud cover, can interfere with your phone's ability to connect to GPS satellites. For best results, stand outside in an open area and standing still to wait for your phone to find the signal before you start your workout

Warranty

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of a defect, so we are happy to offer a ONE-year hassle-free warranty on all our devices as vwe continue to make amazing products, Please contact us if you have any questions about our devices.

Important Safety Instructions

The device contains electrical equipment that may cause injury if not used properly. For example, prolonged contact may contribute to skin allergies for some users. To reduce irritation, please read the safety guidelines on the following pages to ensure proper use and care.

- Do not expose your device to liquid, moisture, humidity or rain while charging; do not charge your device when it is wet, as this may result in electrical shock and injury. Keep your device clean and dry. Do not use abrasive cleaners to clean your device. Consult your doctor before use if you have any preexisting conditions that might be affected by using this device.
- Do not wear it too tight. If your device feels hot or warm, or if it causes any skin irritation or other discomforts, please discontinue using your device and consult your doctor.
- Do not expose your watch to extremely high or low temperatures.
- Do not leave your watch near open flames such as cooking stoves, candles, or fireplaces.
- This product is NOT a toy- never allow children or pets to play with this product. Always store the product out of the reach of children. The devices themselves or the many small parts they contain may cause choking if ingested.
- Never try to abuse, crush, open, repair or disassemble this device, Doing so will void the warranty and can result in a safety hazard.
- If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us.
- Do not use your device in a sauna or steam room.
- Dispose of this device, the device's battery and its package in accordance with local regulations.
- Do not check any notifications, GPS, or any information on your device's display while driving or in other situations where distractions could cause injury or hazard. Always be aware of your surroundings while exercising.

Battery Warnings

- A lithium-ion battery is used in this device. If these guidel ines are not followed, batteries may experience a

shortened life span or may cause fire, chemical burn, electrolyte leakage, and/or injury.

- Do not disassemble, modify, remanufacture, puncture or damage the device or batteries.
- Do not remove or attempt to remove battery. the non-user-replaceable
- Do not expose the device or batteries to fire, explosion, or other hazards.

Health Warnings

- If you have a pacemaker or other internal electronic device, consult your physician before using a heart rate monitor.
- The optical wrist heart rate monitor emits green light and flashes occasionally. Consult your physician if you have epilepsy or are sensitive to flashing lights.
- Always consult your physician before beginning or modifying any exercise program.
- The device, accessories, heart rate monitor, and related data are intended to be used only for recreational purposes and not for medical purposes and are not intended to diagnose, monitor, treat, cure, or prevent any disease or condition.
- The heart rate readings are for reference only, and no responsibility is accepted for the consequences of any erroneous readings.
- While the optical wrist heart rate monitor technology typically provides the best estimate of a user's heart rate, there are inherent limitations with the technology that may cause some of the heart rate readings to be inaccurate under certain circumstances, including the user's physical characteristics, fit of the device, and type and intensity of activity.
- The smartwatch relies on sensors that track your movements and other metrics. The data and information provided by these devices are intended to be a close estimation of your activity and metrics tracked, but may not be completely accurate, including step, sleep, distance, heart rate, and calorie data. If you have eczema, allergies or asthma, you may be more likely to experience skin irritation or allergies from a wearable device.
- Whether you have the conditions above or not, if you start to experience any discomfort or skin irritation on your wrist, remove your device. If symptoms persist longer than 2-3 days of not using your device, contact your doctor. If you sweat for more than two hours while wearing your watch, be sure to clean and dry your band and your wrist to avoid skin irritation.
- Prolonged rubbing and pressure may irritate the skin, so give your wrist a break by removing the band for an hour after extended wear,

Maintenance

- Regularly clean your wrist and the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent which may adhere to the internal side of the watch.
- Do not wash the watch with a household cleanser. Please use soapless detergent, rinse thoroughly and wipe with a soft towel or napkin.
- While the watch is water-resistant, wearing a wet band is not good for your skin.
- If your bands get wet-for example after sweating or showering-clean and dry them thoroughly before putting them back on your wrist.
- Be sure your skin is dry before you put your bands back on.
- Do not bring your device into contact with any sharp objects, as this could cause scratches and other damage. For light-colored armbands, minimize direct contact with dark-colored clothing, as color transfer can occur.

Documents / Resources



[Shenzhen Mifang Network Technology ID205G Smart Watch](#) [pdf] User Guide
ID205G, 2AR5EID205G, ID205G Smart Watch, ID205G, Smart Watch

[Manuals+](#)