

SIGMA ROX 2.0 GPS Cycle Computer User Manual

Home » SIGMA » SIGMA ROX 2.0 GPS Cycle Computer User Manual



Contents

- 1 SIGMA ROX 2.0 GPS Cycle
- **Computer**
- 2 REMARKS
- **3 CONTENTS**
- **4 INSTALLATIONBUTTON**
- **FUNCTIONS**
- **5 FIRST START**
- **6 TRAINING**
- **7 MENU OVERVIEW**
- **8 SETTINGS**
- 9 E-BIKE CONNECTION
- 10 SIGMA RIDE APP
- 11 CHARGING AND DATA TRANSFER
- 12 TECHNICAL INFORMATION
- 13 Documents / Resources
 - 13.1 References
- **14 Related Posts**



SIGMA ROX 2.0 GPS Cycle Computer



REMARKS


This manual is a quick guide. You can access the detailed instructions by following this link: ${\color{red} \underline{goto.sigmasport.com/rox2-0}}$



CONTENTS



INSTALLATION



BUTTON FUNCTIONS

1. START/STOP/MENU Button

- 1. Start training
- 2. Stop training

- 3. Confi rm input
- 4. One menu level down
- 5. Switch on the device (press for 3s)

2. PLUS Button

- 1. One page forward
- 2. Increase value

Press and hold button:

1. Save and reset training values



FIRST START

- 1. Press START Button for 5s to Wake-Up.
- 2. Choose YES to pair a Smartphone, choose NO to manually set the device.
- 3. Download SIGMA RIDE App and follow App instructions to confi gure your device.
- 4. OR set device and user settings manually.
- 5. Enjoy your device and start your fi rst ride!





TRAINING

- 1. Press START button for 3s to start the device.
- 2. Don't move and search for clear sky location for fast GPS fix.
- 3. Wait for "GPS OK". Press START button to start the training session.
- 4. Press START button to stop the training session.
- 5. Hold "+" button to reset training values and save your training.
- 6. Sync with Smartphone for full data analysis and sharing.



MENU OVERVIEW

MAIN MENU

- 1. Hold START button, when training is NOT started.
- 2. You have access to the main menu with all the functions of the ROX 2.0.



SHORT CUT MENU

- 1. Hold START button, when training is active or in auto pause.
- 2. You can edit the most important settings during training.



SETTINGS

- 1. Choose Settings in main menu to set the device.
- 2. You can edit Device settings and Totals.
- 3. Choose a setting you want to edit and press START button to set.
- 4. Press "+" button to increase a value or to toggle through options.
- 5. Press START button to confirm the settings
- 6. Use the App to set your training views.
- 7. Use the App or SIGMA DATA CENTER to update your firmware.



E-BIKE CONNECTION

- 1. Choose Main Menu > Connection > E-Bike to pair a new E-Bike or manage paired Bike.
- 2. Make sure that E-Bike is switched on!
- 3. Press START button to pair E-Bike.



- 1. Set Device and Training Views
- 2. Firmware Update
- 3. Analyze your training
- 4. Share your data and many more...




goto.sigmasport.com/

rox2-0-updates

CHARGING AND DATA TRANSFER

- 1. Open USB Cover.
- 2. Insert USB-C cable. Check that the cable and port are dry!
- 3. Charge with 5V max. 1000mA.
- 4. Connect to PC for data transfer.

IMPORTANT: Please ensure that the USB cover is always closed before starting a training session.



TECHNICAL INFORMATION

ROX 2.0	
Battery type	Rechargeable 350 mAh, 3.7 V Battery
Operation temperature	0 °C to 60 °C
Operation frequency	ANT+ 2.4 GHz @ 1 dBm nominal Bluetooth 2.4 GHz @ 1 dBm nominal G PS 1575.42 MHz (receiver only) GLONASS 1602 MHz (receiver only)
Transmission power	<4 dBm
Water and Dust rating	IPX7

Important: You can find the CE declaration at: ce.sigmasport.com/rox20

SIGMA-ELEKTRO GmbH Dr. – Julius- Leber- Straße 15 67433 Neustadt/Weinstraße Germany **kundenservice@sigmasport.com**



www.sigmasport.com

Documents / Resources



SIGMA ROX 2.0 GPS Cycle Computer [pdf] User Manual ROX 2.0, GPS Cycle Computer, ROX 2.0 GPS Cycle Computer, 081050-2

References

- <u>k</u> ce.sigmasport.com/rox20
- <u>agoto.sigmasport.com/</u>
- ♣ ROX 2.0 SIGMA SPORT
- ▲ E-BIKE COMPATIBILITY SIGMA SPORT
- ♣ ROX 2.0 SIGMA SPORT
- A SIGMA SPORT Bike Computer, Bike Lights, Data World

Manuals+, home privacy