



SIMING AUTOMOTIVE RE_SMPS02 TPMS Sensor with Clamp-In Valves Instruction Manual

[Home](#) » [SIMING AUTOMOTIVE](#) » SIMING AUTOMOTIVE RE_SMPS02 TPMS Sensor with Clamp-In Valves Instruction Manual 

SIMING AUTOMOTIVE RE_SMPS02 TPMS Sensor with Clamp-In Valves



Contents

- [1 Package Content](#)
- [2 Installation](#)
- [3 Installation](#)
- [4 FCC Statement](#)
- [5 Customer Support](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Package Content

1. Screw

①



2. Sensor

②




3. Valve Stem

③



4. Nut

④



5. Valve Cap

⑤



Installation

Caution:

1. Please make sure to use Siming' s valves and accessories to guarantee optimal function.
2. Please follow the instruction of car manufacturer for the safety and correct operation.

Installation

1. Put down the screw nut;



2. Slide the valve stem through the valve hole of the rim. Tighten the screw-nut with 4.0 Nm with the help of the Torque tool.



3. Assemble the tire, be sure that sensor would not touched with the rim and tire.



Note: Use different way to re-learn according to the different vehicle.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Customer Support

Europe:

Siming Europe GMBH

Nordring 6B , 42579 Heiligenhaus


Tel: +49 160 / 75 50 544

Email: d.bettchen@siming-group.eu

Web: www.siming-china.com



Documents / Resources

	<p>SIMING AUTOMOTIVE RE_SMPS02 TPMS Sensor with Clamp-In Valves [pdf] Instruction Manual</p> <p>2A82G-RESMPS02, RE_SMPS02, Sensor with Clamp-In Valves, RE_SMPS02 Sensor with Clamp-In Valves, RE_SMPS02 Sensor, Sensor, RE_SMPS02 TPMS Sensor with Clamp-In Valves, RE_SMPS02 TPMS Sensor, TPMS Sensor</p>
---	---