



# SLEIPNER GW-1 S-Link Gateway User Manual

[Home](#) » [SLEIPNER](#) » SLEIPNER GW-1 S-Link Gateway User Manual 



## Contents

- [1 GW-1 S-Link Gateway](#)
- [2 Introduction](#)
- [3 CAN Interface](#)
- [4 NMEA0183 Interface](#)
- [5 Responsibility of the Installer](#)
- [6 S-Link Gateway Installation](#)
- [7 GW-1 Gateway Measurements](#)
- [8 Technical Specifications](#)
- [9 Typically NMEA2000 Connection Diagram](#)
- [10 Warranty statement](#)
- [11 Patents](#)
- [12 Documents / Resources](#)
  - [12.1 References](#)

## GW-1 S-Link Gateway

User Manual  
Including Installation For S-Link Gateway GW-1  
Keep this manual onboard!



SLEIPNER GROUP  
P.O. Box 519  
N-1612 Fredrikstad  
Norway

[www.sleipnergroun.com](http://www.sleipnergroun.com)

To download your language go to [www.sleipnergroun.com](http://www.sleipnergroun.com)

DOCUMENT ID: 3057

REVISION: 10

DATE: 2023

LANGUAGE: EN


Failure to follow the considerations and precautions can cause serious injury, damage and will render all warranties given by Sleipner Motor as VOID. MC\_0411

## Introduction

! Please refer to the graphic for special considerations relating to your model !

S-Link gateway GW-1 is a NMEA2000® Certified device for connecting NMEA2000® CAN bus equipment to the S-Link bus. Connect an S-Link spur cable from the gateway to S-Link backbone, and non S-Link equipment to the CAN Interface M12 male connector or NMEA0183 GPS antenna to the NMEA0183 connector.

Power to the gateway is supplied from the S-Link so no external power is required.




## CAN Interface

### Connection

The GW-1 does not feed any power to the CAN-bus and connected devices has to be power feed from elsewhere. The GW-1 does not include any termination resistor on the M12 male connector output, so terminating resistors is required on the CAN-bus. CAN-L & CAN-H are galvanic isolated. Use standard NMEA 2000® micro cable to connect to the CAN interface connector. Sleipner Motor AS do not provide NMEA 2000® micro cables.

### CAN INTERFACE



M12 Input Male Connector  
(View into connector)

Pin 1 NC  
Pin 2 NC  
Pin 3 GND  
Pin 4 CAN-H  
Pin 5 CAN-L

### Supported NMEA2000® PGN's

Navigation PGN's:	
GPS Position – Rapid Update	PGN 129025
GPS COG & SOG – Rapid Update	PGN 129026
GPS System Time	PGN 126992
GPS GNSS Position Data	PGN 129029
Engine and transmission PGN's:	
Engine Parameters, Rapid Update	PGN127488
Transmission Parameters, Dynamic	PGN127493
Autopilot PGN's:	
Vessel Heading	PGN 127250


### LED indication

TX LED off:	Not sending any messages.
TX LED flashing:	Flashing at max 100ms on and 100ms off when sending messages.
RX LED off:	Not receiving any messages.
RX LED flashing:	Flashing at max 100ms on and 100ms off when receiving messages

### NMEA0183 Interface

#### Connection

The V OUT pin can feed power to a single GPS antenna with maximum 100mA, and it is internally fused. V OUT is S-link bus voltage. RX A(+) & TX B(-) are galvanic isolated



### Baud rate

4800 baud and 38400 baud is supported, and are set automatically.

Supported NMEA0183 sentences

\$GxRMC sentences from all positioning systems is supported.

LED indication

LED off: No valid NMEA0183 GPS signals.

LED flashing: Flashing 100ms on and 100 off for each valid GPS message received.

– Valid GPS antenna message at 38400 baud normal flashing on/off (100ms/100ms).

– Valid GPS antenna message at 4800 baud normal flashing on/off (100ms/900ms)

GNSS Antenna Prioritization

GNSS antennas priority sequence is 1. NMEA0183 with 100ms update rate 2. NMEA2000@ 3. NMEA0183 with 1000ms update rate.

GW-1 will only forward one of the NMEA2000@ GPS antenna signal to S-link if more than one antennas is present on the NMEA2000@ bus.

If more than one GW-1 have GNSS signal(s) then GW-1's will prioritize on antenna type from the list above and only one GW-1 will broadcast GNSS signals on the S-link bus.

All this requires GW-1 firmware V1.021 or newer.

LED off:	No power to the device.
LED on:	S-Link communication and power OK.
LED flashing (on/off (500ms /500ms)):	No S-Link communication but power is OK.

## Responsibility of the Installer

The installer must read this document to ensure necessary familiarity with the product before installation.

Instructions in this document cannot be guaranteed to comply with all international and national regulations. It is the responsibility of the installer to follow all applicable international and national regulations when installing Sleipner products.

The recommendations given in this document are guidelines ONLY, and Sleipner strongly recommends that advice is obtained from a person familiar with the particular vessel and applicable regulations.

This document contains general installation instructions intended to support experienced installers. If you are not skilled in this type of work, please contact professional installers for assistance.

If required by local regulation, electrical work must be done by a licensed professional.

Appropriate health and safety procedures must be followed during installation.

Faulty installation of Sleipner products will render all warranties given by Sleipner Motor AS.


When installing an S-Link™ system connect ONLY original Sleipner S-Link™ products or other authorized control equipment directly to the S-Link™ bus.

Connecting non-authorized third-party equipment, it must always be connected through a Sleipner supplied interface product.

Any attempt to directly control or connect into the S-Link™ control system without a designated and approved interface will render all warranties and responsibilities of all of the connected Sleipner products. If you are interfacing the S-Link™ bus by agreement with Sleipner through a designated Sleipner supplied interface, you are still required to install at least one original Sleipner control panel to enable efficient troubleshooting if necessary.


## S-Link Gateway Installation

1. Place the PHC-3 unit on the welded frame of the hydraulic system and attach using 4 M5x16 screws
2. Attach the required cables to the PHC-3



## GW-1 Gateway Measurements


Measurement code	Measurement description	mm	inch
+H	Total Gateway Height	41	1.6
H	Gateway Height	25.5	1
W	Gateway Width	50	2
L	Total Gateway Length	126.5	5
+L	Gateway Length	100	3.9



## Technical Specifications

Supply Voltage	8-31VDC, Powered from S-Link
Power Consumption	1 W
CAN INTERFACE M12 male connector	CAN 2.0B, baud rate 250Kb
NMEA 2000® LEN (Load Equivalence Number)	1
NMEA 0183 Connector	GPS RX @ 4800 baud or 38400 baud
NMEA 0183 Power Output	Max 100mA (internally fused)
Weight	200g/7.05oz

### Typically NMEA2000 Connection Diagram



Find your local professional dealer from our certified worldwide network for expert service and support.  
visit our website [www.sleipnergrouper.com/support](http://www.sleipnergrouper.com/support)

## Product Spare Parts and Additional Resources

For additional supporting documentation, we advise you to visit our website [www.sleipnergrouper.com](http://www.sleipnergrouper.com) and find your Sleipner product.

## Warranty statement

1. Sleipner Motor AS (The “Warrantor”) warrants that the equipment (parts, materials, and embedded software of products) manufactured by the Warrantor is free from defects in workmanship and materials for purpose for which the equipment is intended and under normal use and maintenance service (the “Warranty”).
2. This Warranty is in effect for two years (Leisure Use) or one year (Commercial and other Non-leisure Use) from the date of delivery/purchase by the end user, with the following exceptions; (a) For demonstration vessels, or vessels kept on the water, the dealer is considered as the end user from 6 months after their launch of the vessel; (b) The warranty period starts no later than 18 months after the first launch of the vessel.  
Please note that the boat manufacturer and dealer must pay particular attention to correct maintenance and service both by the products manuals as well as general good practice for the location the boat is kept in the period the boat is in their care. In cases where the 6 and 18 months grace periods for boat builders and dealers are passed, it is possible to obtain a full warranty upon inspection and approval of the warrantor or such representative.
3. Certain parts, classified as wearable or service parts, are not covered by the warranty. A failure to follow the required maintenance and service work as described in the product manual render all warranty on parts or components directly or indirectly affected by this void. Please also note that for some parts, time is also a factor separately from actual operational hours.
4. This Warranty is transferable and covers the equipment for the specified warranty period.
5. The warranty does not apply to defects or damages caused by faulty installation or hook-up, abuse or misuse of the equipment including exposure to excessive heat, salt or fresh water spray, or water immersion except for equipment specifically designed as waterproof.
6. In case the equipment seems to be defective, the warranty holder (the “Claimant”) must do the following to make a claim: (a) Contact the dealer or service centre where the equipment was purchased and make the claim. Alternatively, the Claimant can make the claim to a dealer or service centre found at [www.sleipnergrouper.com](http://www.sleipnergrouper.com). The Claimant must present a detailed written statement of the nature and circumstances of the defect, to the best of the Claimant’s knowledge, including product identification and serial nbr., the date and place of purchase and the name and address of the installer. Proof of purchase date should be included with the claim, to verify that the warranty period has not expired;  
(b) Make the equipment available for troubleshooting and repair, with direct and workable access, including dismantling of furnishings or similar, if any, either at the premises of the Warrantor or an authorised service representative approved by the Warrantor. Equipment can only be returned to the Warrantor or an authorised service representative for repair following a pre-approval by the Warrantor’s Help Desk and if so, with the Return Authorisation Number visible postage/shipping prepaid and at the expense of the Claimant.
7. Examination and handling of the warranty claim:  
(a) If upon the Warrantor’s or authorised service Representative’s examination, the defect is determined to result from defective material or workmanship in the warranty period, the equipment will be repaired or replaced



at the Warrantor's option without charge, and returned to the Purchaser at the Warrantor's expense. If, on the other hand, the claim is determined to result from circumstances such as described in section 4 above or a result of wear and tear exceeding that for which the equipment is intended (e.g. commercial use of equipment intended for leisure use), the costs for the troubleshooting and repair shall be borne by the Claimant;

(b) No refund of the purchase price will be granted to the Claimant, unless the Warrantor is unable to remedy the defect after having a reasonable number of opportunities to do so. In the event that attempts to remedy the defect have failed, the Claimant may claim a refund of the purchase price, provided that the Claimant submits a statement in writing from a professional boating equipment supplier that the installation instructions of the Installation and Operation Manual have been complied with and that the defect remains.

8. Warranty service shall be performed only by the Warrantor, or an authorised service representative, and any attempt to remedy the defect by anyone else shall render this warranty void.
9. No other warranty is given beyond those described above, implied or otherwise, including any implied warranty of merchantability, fitness for a particular purpose other than the purpose for which the equipment is intended, and any other obligations on the part of the Warrantor or its employees and representatives.
10. There shall be no responsibility or liability whatsoever on the part of the Warrantor or its employees and representatives based on this Warranty for injury to any person or persons, or damage to property, loss of income or profit, or any other incidental, consequential or resulting damage or cost claimed to have been incurred through the use or sale of the equipment, including any possible failure or malfunction of the equipment or damages arising from collision with other vessels or objects.
10. This warranty gives you specific legal rights, and you may also have other rights which vary from country to country.


## Patents

At Sleipner we continually reinvest to develop and offer the latest technology in marine advancements. To see the many unique designs we have patented visit our website [www.sleipnergroupp.com/patents](http://www.sleipnergroupp.com/patents)

© Sleipner Group, All rights reserved The information given in the document was right at the time it was published. However, Sleipner Group cannot accept liability for any inaccuracies or omissions it may contain. Continuous product improvement may change the product specifications without notice. Therefore, Sleipner Group cannot accept liability for any possible differences between product and document. Learn more about our products at [www.sleipnergroupp.com](http://www.sleipnergroupp.com)



## Documents / Resources

	<p><b><a href="#">SLEIPNER GW-1 S-Link Gateway</a></b> [pdf] User Manual GW-1 S-Link Gateway, GW-1, S-Link Gateway, Gateway</p>
---	---

## References

- [↔ Sleipner - Ocean born. Tech bred.](#)
- [↔ Patents - Sleipner Group](#)
- [↔ Support - Sleipner Group](#)
- [User Manual](#)

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.