



SLINGER DC6V Wireless Remote Control User Manual

[Home](#) » [Slinger](#) » **SLINGER DC6V Wireless Remote Control User Manual** 



Contents

- [1 DC6V Wireless Remote Control](#)
- [2 FCC Statement](#)
- [3 Industry Canada statement:](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)

DC6V Wireless Remote Control



User instruction

The remote controller being tested is the modulation ASK working mode with a frequency of 433.92mhz; two buttons; the remote controller is powered by DC6V (CR2016*2), and the corresponding device is controlled by RF.

- Frequency: 433.92mhz
- Working voltage 6V
- Working current $4\text{mA} \pm 1\text{mA}$
- Static current $0\mu\text{A}$
- Code EV1527 Main IC:U1
- Coding Bandwidth 330us
- Oscillation resistance:R2
- Key value Locked 0010 Unlocked 0001
- Distance 28m
- Model: JJ-RC-F8A-AD21
- Name: Remote control

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant

to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate this equipment.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

Industry Canada statement:


This device complies with ISED’s licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

– Instructions for use:

Press the corresponding button, the LED will light up, and the corresponding RF code will be sent at the same time. Let go and the RF transmission will be disconnected.



Documents / Resources

	<p>SLINGER DC6V Wireless Remote Control [pdf] User Manual DC6V Wireless Remote Control, DC6V, Wireless Remote Control, Remote Control</p>
---	---

References

- [User Manual](#)