



SOLAX POWER Pocket LAN V3.0 Monitoring Device User Manual

[Home](#) » [SOLAX POWER](#) » SOLAX POWER Pocket LAN V3.0 Monitoring Device User Manual 

SOLAX POWER Pocket LAN V3.0 Monitoring Device



Contents


- [1 INSTALLATION](#)
- [2 MONITORING](#)
- [3 APPEARANCE AND DIMENSIONS](#)
- [4 TECHNICAL DATA](#)
- [5 SAFETY INSTRUCTIONS](#)
- [6 WARRANTY REGULATION AND LIABILITY](#)
- [7 PROOF OF PURCHASE](#)
- [8 CUSTOMER SUPPORT](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

INSTALLATION





Ensure all power has been turned off at least 5 minutes prior to installation.


- Screw off two components on the Pocket LAN, insert the Internet cable and then make an RJ45 connector for the cable. Tighten those components.



- Remove the cover of DONGLE port at the bottom of the inverter. Ready to install your Pocket LAN.




- Plug the Pocket LAN into the correct port of inverter.



Note that the direction of the buckle needs to be consistent.

- Connect the other side of the network cable to home router. And make sure the home router works in good condition.



MONITORING

- SolaxCloud Registration



Step 1: Use your smart phone to scan below QR code or search for the keyword “SolaxCloud” in browser to download the Monitoring App.

IOS	Google
	

Step 2: Touch the Setting button at upper left corner of the Monitoring App to choose language.

Step 3: Touch “Create a new account” at the bottom of Monitoring App.

Step 4: Type in or scan the Registration No. and type in other information to complete the registration.



(Registration No. example)

- **Monitoring Website**

Step 1: Ensure that your computer or laptop is connected to a network.

Step 2: Open a browser and enter www.solaxcloud.com/

Step 3: Select your display language and read the User guide, then create a new account.


User guide



Step 4: Complete registration, login, add site and other related operations according to the guidelines of the User guide.

Step 5: Click the Warranty Manage and add your installation information to get warranty for your devices.

APPEARANCE AND DIMENSIONS



TECHNICAL DATA

Product Name	Pocket LAN
Model	Pocket LAN V3.0
Supply Voltage	5VDC
Rated Power	0.9 W
Data Upload Intervals	5 min
Bandwidth	10/100 M
Weight	75 g
Dimension	112*45.7*28.5 mm
Degree of Protection	IP 65

SAFETY INSTRUCTIONS

- Prior to installation, ensure all power going to the inverter has been cut off.
- Keep away from flammable, explosive materials.
- Do not dismantle or scrap by force.
- Children should be supervised to ensure that they do not play with this appliance.



Indicates that the product must not be processed with household waste. It must be brought to an electric and electronic waste collection point for recycling and disposal. By ensuring the appropriate disposal of this product you also help in preventing potentially negative consequences for the environment and human health. The recycling of materials helps preserve our natural resources. For further information regarding the recycling of this product, please contact your municipality, local waste disposal center or the store where the products was purchased.

WARRANTY REGULATION AND LIABILITY

Terms and Conditions

SolaX grants a standard 24-month warranty. The terms of this warranty begin from the date marked on the purchase invoice. SolaX will only perform warranty service when the faulty unit is returned to SolaX along with a copy of the invoice and proof of purchase issued by the dealer. In addition, the type label of the unit must be fully legible. If these requirements are not fulfilled, SolaX reserves the right to deny warranty service.

Exclusion of Liability

Warranty claims are excluded for direct or indirect damage due to:

- Use of unit in ways not intended, improper or substandard installation, improper operation and unauthorized modification to the units, or repair attempts.
- Missing warranty card and serial number.
- Operating the units with defective protective equipment.
- Influence of foreign objects and force majeure.
- Inadequate ventilation.
- Non-observance to relevant safety instructions.

PROOF OF PURCHASE


Retain this page as proof of your purchase. See warranty registration notice for more details.

CUSTOMER SUPPORT

SolaX Power Network Technology (Zhejiang) Co., Ltd.
ADD Room 506, West Building A, No.525 Xixi Road,
Hangzhou, Zhejiang Province, China 310007
Tel +86 57156260011
FAX +86 571 56075753
EMAIL service@solaxpower.com
WEB www.solaxpower.com



Documents / Resources

	SOLAX POWER Pocket LAN V3.0 Monitoring Device [pdf] User Manual Pocket LAN V3.0, Monitoring Device, Pocket LAN V3.0 Monitoring Device
---	--

References

- [X Solax Cloud System](#)
- [X Solar PV and Battery Storage Solutions | Solax Power](#)