

STMicroelectronics STSPIN32G0601 3 Phase Inverter Based



STMicroelectronics STSPIN32G0601 3 Phase Inverter Based User Manual


[Home](#) » [STMicroelectronics](#) » STMicroelectronics STSPIN32G0601 3 Phase Inverter Based User Manual 

Contents

- 1 STMicroelectronics STSPIN32G0601 3 Phase Inverter Based
- 2 Product Usage Instructions
- 3 Introduction
- 4 Main features
- 5 Target applications
- 6 Safety and operating instructions
- 7 Operating the evaluation board
- 8 Hardware and software requirements
- 9 Getting started
- 10 Hardware description and configuration
- 11 Board description
- 12 FAQ
- 13 Documents / Resources
 - 13.1 References



STMicroelectronics STSPIN32G0601 3 Phase Inverter Based



Specifications

- **Input Voltage:** 35 VAC (50 VDC) to 280 VAC (400 VDC)
- **Power Output:** ~250 W
- **Phase Current:** 1 ARMS
- **IGBTs Power Stage:** STGD6M65DF2
- **Overcurrent Threshold:** 3.5 Apeak (configurable)
- **Current Sensing:** Three-shunt
- **Supply Voltages:** 15 V VCC, 3.3 V VDD
- **External Connection:** STLINK-V3SET or ST-LINK/V2
- **User Interface:** Buttons and trimmer
- **Compliance:** RoHS

Product Usage Instructions

Safety and Operating Instructions

Before operating the evaluation board, please ensure you follow the safety guidelines provided in the user manual.

Installing the Evaluation Board

1. Ensure installation is done as per the specifications and target application.
2. Protect motor drive converters against excessive strain.
3. Avoid contact with other electronic components and contacts to prevent damage.

Operating the Evaluation Board

Follow the safety rules provided in the manual for the work area, electrical safety, and personal safety.


Hardware and Software Requirements

1. You will need a Windows PC with one of the supported operating systems to install the software package.
2. Connect the EVSPIN32G06Q1S3 board using an STLINK-V3SET or ST-LINK/V2 debugger/programmer.

Introduction

The EVSPIN32G06Q1S3 board is a three-phase complete inverter based on the STSPIN32G0601Q controller, which embeds a three-phase 600 V gate driver and a Cortex®-M0+ STM32 MCU. The power stage features STGD6M65DF2 IGBTs, but can be populated with any IGBT or power MOSFET in DPAK or PowerFLAT 8×8 HV package. The board has a three-shunt sensing topology, and both sensed or sensorless FOC algorithms can be implemented. This allows driving permanent magnet synchronous motors (PMSMs) with fast and accurate current sensing. It provides an easy-to-use solution for the evaluation of the device in different applications such as refrigerator compressors, dishwasher pumps, fans, and industrial appliances. The evaluation board is compatible with a wide range of input voltages and includes a power supply stage with the VIPER06XS in flyback configuration to generate +15 V and +3.3 V supply voltages required by the application. Debug and configuration of the FW can be performed with standard STM32 tools through the STLINK-V3SET or ST-LINK/V2 debugger/programmer. SWD and UART TX/RX connectors are also available.

Figure 1. EVSPIN32G06Q1S3 evaluation board



Main features

The EVSPIN32G06Q1S3 has the following features:

- Input voltage from 35 VAC (50 VDC) to 280 VAC (400 VDC)
- Suitable for ~250 W applications, 1 ARMS phase current
- STGD6M65DF2 IGBTs power stage featuring:
 - $V(BR)_{CES} = 650 \text{ V}$
 - $V_{CE(sat)} = 1.55 \text{ V @ } I_C = 6 \text{ A}$
- The overcurrent threshold is set to 3.5 Apeak (value configurable by the user)
- Dual footprint for IGBT/MOSFET packages
 - DPAK or PowerFLAT 8×8 HV
- • Three-shunt current sensing, suitable for:
 - Sensed or sensorless single-shunt vector (FOC) algorithm
- Smart shutdown overcurrent protection
- Digital Hall sensors and encoder input

- Bus voltage sensing
- 15 V VCC and 3.3 V VDD supplies
- External connection through STLINK-V3SET or ST-LINK/V2
- Easy user interface with buttons and trimmer
- RoHS compliant

Target applications

- Residential and industrial refrigerator compressors
- Industrial drives, pumps, and fans
- Air conditioning compressors and fans
- Corded power tools, garden tools
- Home appliances
- Industrial automation

Safety and operating instructions

General Terms

Warning: During assembly, testing, and operation, the evaluation board poses several inherent hazards, including bare wires, moving or rotating parts, and hot surfaces.

Danger: There is a danger of serious personal injury, property damage, or death due to electrical shock and burn hazards if the kit or components are improperly used or installed incorrectly.

Attention: The kit is not electrically isolated from the high-voltage supply AC/DC input. The evaluation board is directly linked to the mains voltage. No insulation is ensured between the accessible parts and the high voltage. All measuring equipment must be isolated from the mains before powering the board. When using an oscilloscope with the demo, it must be isolated from the AC line. This prevents shock from occurring as a result of touching any single point in the circuit, but does NOT prevent shock when touching two or more points in the circuit.

Important: All operations involving transportation, installation and use, and maintenance must be performed by skilled technical personnel able to understand and implement national accident prevention regulations. For the purposes of these basic safety instructions, “skilled technical personnel” are suitably qualified people who are familiar with the installation, use, and maintenance of power electronic systems.

Intended use of evaluation board

The evaluation board is designed for demonstration purposes only, and must not be used for electrical installations or machinery. Technical data and information concerning the power supply conditions are detailed in the documentation and should be strictly observed.

Installing the evaluation board

- The installation and cooling of the evaluation board must be in accordance with the specifications and target application.
- The motor drive converters must be protected against excessive strain. In particular, components should not be bent nor should isolating distances be altered during transportation or handling.
- No contact must be made with other electronic components and contacts.
- The board contains electrostatically sensitive components that are prone to damage if used incorrectly. Do not mechanically damage or destroy the electrical components (potential health risks).

Operating the evaluation board

To properly operate the board, follow these safety rules:

1. Work area safety:

- The work area must be clean and tidy.
- Do not work alone when boards are energized.
- Protect against inadvertent access to the area where the board is energized using suitable barriers and signs.
- A system architecture that supplies power to the evaluation board must be equipped with additional control and protective devices in accordance with the applicable safety requirements (i.e., compliance with technical equipment and accident prevention rules).
- Use a non-conductive and stable work surface.
- Use adequately insulated clamps and wires to attach measurement probes and instruments.

2. Electrical safety:

- Remove the power supply from the board and electrical loads before taking any electrical measurements.
- Proceed with the arrangement of measurement setup, wiring, or configuration paying attention to high voltage sections.
- Once the setup is complete, energize the board.
- **Danger:** Do not touch the evaluation board when it is energized or immediately after it has been disconnected from the voltage supply as several parts and power terminals containing potentially energized capacitors need time to discharge.

Do not touch the boards after disconnection from the voltage supply as several parts, like heat sinks and transformers, may still be very hot.

The kit is not electrically isolated from the AC/DC input. The USB interface of the board does not insulate the host computer from high voltage. When the board is supplied at a voltage outside the ELV range, a proper insulation method such as a USB isolator must be used to operate the board.

3. Personal safety:

- Always wear suitable personal protective equipment such as, for example, insulating gloves and safety glasses.
- Take adequate precautions and install the board in such a way to prevent accidental touch. Use protective shields such as, for example, an insulating box with interlocks, if necessary.

Hardware and software requirements

Using the EVSPIN32G06Q1S3 evaluation board requires the following software and hardware:

- A Windows PC (XP, Vista, Win 7, Win 8, Win 10, or Win 11) to install the software package.
- A STLINK-V3SET or ST-LINK/V2 debugger/programmer to connect the EVSPIN32G06Q1S3 board to the PC.
- The STM32 Motor Control Software Development Kit (available on www.st.com).
- A 3-phase brushless PMSM motor with compatible voltage and current ratings.
- AC mains power supply or external DC power supply.

Warning: The kit is not electrically isolated from the AC/DC input. The USB interface of the board does not insulate the host computer from high voltage. When the board is supplied at a voltage outside the ELV range, a proper insulation method such as a USB isolator must be used to operate the board.

Getting started

The maximum ratings of the board are as follows:


- Power stage supply voltage between 35 VAC (50 VDC) and 280 VAC (400 VDC).
- Overcurrent protection set to 3.5 Apeak (value configurable by the user).

To start your project with the board:

1. Check the jumper position according to the target configuration (see Section 5).
2. Connect the motor on the connector J2 keeping in mind the motor phase sequence.
3. Supply the board through AC mains connector J3. The LD1 LED (green) turns on. Develop the application using the code examples provided or the STM32 FOC MC library. Refer to the relevant user manual for details.

Hardware description and configuration

The following figure shows the position of the main circuitry blocks of the board.



The following figure shows the position of the connectors and jumpers of the board.

Figure 3. Main components and connector positions




Table 1. Hardware jumper settings

Jumper	Permitted configurations	Default condition
JP1	Selection PA2 connected to Hall 3	CLOSED
JP2	Selection PA1 connected to Hall 2	CLOSED
JP3	Selection PA0 connected to Hall 1	CLOSED
JP4	Selection Hall encoder power supply to VDD	CLOSED
JP5	Selection Encoder sensor power to VDD (1-2 CLOSED), VCC (2-3 CLOSED) or +5 V (2-4 CLOSED)	2-4 CLOSED
JP6	Auxiliary +5 V supply for Hall sensors	OPEN
JP7	Selection of Boot from Flash or System/SRAM if nBOOT_SEL = 0 (flash option bit, legacy mode)	OPEN
JP8	Selection VBUS feedback partition value	CLOSED
JP10	Selection VCC connected to internal power supply (1-2 CLOSED) or external supply (VCC = pin 2 GND = pin 3, jumper removed)	1-2 CLOSED

Table 2. Connectors

Na me	Pin	Label	Description
J1	1	A+/H1	Hall/encoder sensors connector
	2	B+/H2	
	3	Z+/H3	
	4	VDD	Hall sensors/encoder supply
	5	GND	
J2	1	OUT3	3-phase BLDC motor phase connector
	2	OUT2	
	3	OUT1	
J3	1 – 2	AC MAINS ~	AC mains power supply
J4	1 – 2	VDD	ST-LINK/V2 connector
	4 – 6 – 8 – 10 – 12 – 14 – 16 – 18 – 20	GND	
	7	SWD_IO	
	9	SWD_CLK	
	15	NRST	
J5	3	VDD	ST-LINKV3SET connector
	4	SWD_IO	
	5 – 7 – 11	GND	
	6	SWD_CLK	
	12	NRST	
	13	UART1_RX	
	14	UART1_TX	
J6	1	GND	SPI interface or customizable GPIOs
	2	SPI1_MOSI	
	3	SPI1_MISO	
	4	SPI1_CLK	

Na me	Pin	Label	Description
J6	5	SPI1_NSS	SPI interface or customizable GPIOs
J7	1	PD1	GPIO connector
	2	PB10	
	3	PD2	
	4	PB11	
	5	PB8	
	6	PA12	
	7	PB9	
	8	EMUL_DAC	
	9	GND	
	10		
J8	1	VDD	Auxiliary connector for SWD mode debugging/programming
	2	SWD CLK	
	3	GND	
	4	SWD IO	
J9	1	GND	I2C1 / UART1
	2	I2C1_SCL/UART1_T X	
	3	VDD	
	4	I2C1_SDA/UART1_ RX	
J10	1	GND	UART2
	2	UART2_RX	
	4	VDD	
	4	UART2_TX	
JP9	1	E3V3 (onboard regul ator output)	VDD/VBAT/VREF+ power supply connector Connect E3V3 to VDD with a jumper if no external supply is avail able External supplies for VBAT (pin3) and VREF+ (pin4) after removal of R27 and R32 respectively.
	2	VDD (digital power s upply)	
	3	VBAT	
	4	VREF+	
	5	GND	

Table 3. Test points

Name	Description
TP1	NRST
TP2	PC13
TP3	High-side gate 3
TP4	OUT 3
TP5	High-side gate 2
TP6	OUT 2
TP7	High-side gate 1
TP8	OUT 1
TP9	PGND – power ground

Name	Description
TP10	EMUL_DAC (emulated DAC)
TP11	Low-side gate 3
TP12	SENSE3
TP13	Low-side gate 2
TP14	SENSE2
TP15	Low-side gate 1
TP16	SENSE1
TP17	OD – SmartSD timing Open Drain output, unlatch, and restart input
TP18	SGND – signal ground
TP19	CIN – comparator positive input

Board description

Sensorless

By default the evaluation board is configured in sensorless mode. The reading of amplified shunt currents is made through ADC channels available at PA5, PA6 and PA7 pins. No additional configuration is required.

Hall/encoder motor speed sensor

The EVSPIN32G06Q1S3 evaluation board supports the digital Hall and quadrature encoder sensors for motor position feedback. The sensors can be connected to the STSPIN32G0601Q through the J1 connector as listed in the following table.

Table 4. Hall/encoder connector (J1)

Name	Pin	Description
A+/H1	1	Hall sensor 1/encoder out A+
B+/H2	2	Hall sensor 2/encoder out B+
Z+/H3	3	Hall sensor 3/encoder Zero feedback
VDD	4	Sensor supply voltage
GND	5	Ground

- A protection series resistor of 1.8 k Ω is mounted in series with sensor outputs.
- For sensors requiring external pull-up, three 10 k Ω resistors are already mounted on the output lines and connected to VDD voltage when JP4 is closed.

The jumper JP5 selects the power supply for sensor supply voltage:

- JP5 pins 1-2 closed: Hall sensors powered by VDD (3.3 V)
- JP5 pins 2-3 closed: Hall sensors powered by VCC (15 V)
- JP5 pins 2-4 closed: Hall sensors powered by +5 V supply


The MCU of STSPIN32G0601Q can decode Hall/encoder sensor outputs configuring jumpers as follows:

- JP3 closed, PA0 connected to Hall 1
- JP2 closed, PA1 connected to Hall 2
- JP1 closed, PA2 connected to Hall 3

Overcurrent detection and current sensing measurement

The EVSPIN32G06Q1S3 evaluation board implements overcurrent protection based on the STSPIN32G0601Q integrated comparator. Each shunt resistor measures the load current bringing the voltage signal associated to the load current to the CIN pin (TP19). When the peak current in the phases exceeds the selected threshold, the integrated comparator is triggered and all the power switches are disabled. Power switches are enabled again when the current falls below the threshold and the output disable time expires, thus implementing a current limitation control.

Figure 4. Current sensing and disable time circuitry



By default, the evaluation board has an overcurrent threshold set to $I_{OC_typ} = 3.5\text{ A}$ and a restart time after fault detection of $\sim 590\text{ }\mu\text{s}$. The overcurrent threshold can be modified by changing the R79 bias resistor, R52, R58 and R81 loop resistors, and R85, R86 and R89 shunt resistors according to the following formulas:

- $V_{REF_typ} = 460\text{ mV}$
- $V_{DD} = 3.3\text{ V}$
- $R_{SHUNT} = R_{85} = R_{86} = R_{89} = 220\text{ m}\Omega$
- $R_{PU} = R_{79} = 10\text{ k}\Omega$
- $R_{LOOP} = R_{52} = R_{58} = R_{81} = 2.2\text{ k}\Omega$

If $R_{SHUNT} \ll R_{LOOP}$:

$$I_{OC_typ} \cong V_{REF_typ} \cdot \frac{(3R_{PU} + R_{LOOP})}{R_{SHUNT} \cdot R_{PU}} - V_{DD} \cdot \frac{R_{LOOP}}{R_{SHUNT} \cdot R_{PU}}$$

The output disable time can be monitored on the OD pin (TP17) and is determined mainly by the time required to recharge the C38 capacitor up to the VSSDh threshold, according to the following formulas:

- $V_{SSDh} = 4 \text{ V}$
- $V_{SSDl} = 0.56 \text{ V}$
- $V_{OD} = V_{CC} = 15 \text{ V}$

$$t_2 \cong C_{38} \cdot R_{63} \cdot \ln\left(\frac{V_{SSDl} - V_{OD}}{V_{SSDh} - V_{OD}}\right)$$

Taking into account also the contribution of the OD internal current source I_{OD} (typical value $5 \mu\text{A}$) the previous equation becomes:

$$t_2 \cong C_{OD} \cdot R_{OD_ext} \cdot \ln\left(\frac{V_{SSDl} - V_{OD} - I_{OD} \cdot R_{OD_ext}}{V_{SSDh} - V_{OD} - I_{OD} \cdot R_{OD_ext}}\right)$$

Bus voltage circuit

The EVSPIN32G06Q1S3 evaluation board provides the bus voltage sensing. This signal is set through a voltage divider from the motor supply voltage (VBUS) (R22, R30 and R36, R43), and sent to PB1 GPIO (channel 9 of the ADC) of the embedded MCU.

- JP8 closed (by default) allows the bus voltage divider to be set to 146.
- JP8 open allows the bus voltage divider to be set to 126.

Hardware user interface

The board provides a hardware user interface as follows:

- A potentiometer R74 setting, for example, the target speed
- **Switch SW1:** reset STSPIN32G0601Q MCU
- **Switch SW2:** user button 2
- **Switch SW3:** user button 1
- **LED DL1:** turned on when user 1 button is pressed
- **LED DL3:** turned on when user 2 button is pressed
- **LED DL2:** turned on when VDD is on (MCU stage powered)
- **LED LD1:** turned on when VCC supply from flyback is on (gate driver stage powered)

Debug

The EVSPIN32G06Q1S3 evaluation board embeds an STLINK-V3SET or STLINK/V2 debugger/programmer.

Some of the features supported by STLINK are:

- USB 2.0 high-speed compatible interface
- Direct firmware update support (DFU)
- Virtual com port interface on USB connected to PB6/PB7 pins of the STSPIN32G0601Q (UART1)
- SWD and serial wire viewer (SWV) communication support

Just plug the provided flat cable on the J5 connector (STDC14 STM32 JTAG/SWD and VCP) or J7 connector to start programming/debugging the board through the preferred IDE. The firmware can be generated using the

Using an external DC power supply

The EVSPIN32G06Q1S3 evaluation board generates VDD = 3.3 V and VCC = 15 V through a flyback converter by default.

Optionally, it can be configured to provide VDD and VCC through an external power supply:

- VCC is provided by removing the jumper JP10 between VCC & Vcc_F and connecting pin2 to a suitable supply (i.e. 15 V or 12 V) and pin3 to GND.
- VDD can be provided by removing the jumper between E3V3 & VDD of connector JP9 and connecting pin2 to 3.3 V and pin5 to GND.

References

This user manual provides information on the hardware features and use of the EVSPIN32G06Q1S3 evaluation board. For additional information refer to:

- EVSPIN32G06Q1S3 data brief (schematics, bill of materials, layouts)
- STSPIN32G0601Q datasheet
- STGD6M65DF2 datasheet
- UM2448 STLINK-V3SET debugger/programmer for STM8 and STM32 user manual
- STM32 Motor Control Software Development Kit (MCSDK)

Revision history

Table 5. Document revision history

Date	Version	Changes
18-Apr-2024	1	Initial release.

IMPORTANT NOTICE – READ CAREFULLY

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgment. Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers’ products. No license, express or implied, to any intellectual property right is granted by ST herein. Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product. ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document. © 2024 STMicroelectronics – All rights reserved

FAQ

Q: What are the target applications for the EVSPIN32G06Q1S3 board?

A: The target applications include residential and industrial refrigerator compressors, industrial drives, pumps, fans, air conditioning compressors, fans, corded power tools, garden tools, home appliances, and industrial

automation.


Q: Can the overcurrent threshold be configured by the user?

A: Yes, the overcurrent threshold on the STGD6M65DF2 IGBT power stage can be configured by the user.

Q: How should I handle electrostatically sensitive components on the board?

A: Avoid mechanically damaging or destroying the electrical components to prevent potential health risks.

Documents / Resources

	<p>STMicroelectronics STSPIN32G0601 3 Phase Inverter Based [pdf] User Manual STSPIN32G0601 3 Phase Inverter Based, STSPIN32G0601, 3 Phase Inverter Based, Phase In verter Based, Inverter Based, Based</p>
---	--

References

- [User Manual](#)

Manuals+ Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.