




## Supersonic Gate Door Automation MCT-3 3-Channel Visor Transmitter Instruction Manual


[Home](#) » [Supersonic Gate Door Automation](#) » Supersonic Gate Door Automation MCT-3 3-Channel Visor Transmitter Instruction Manual 

MCT-3 DNT00089 ACT-31B ACP00879 MCT-11 DNT00090 318mhz Remote




**To Add or Remove a Remote Control**

## PREPARING TO ADD A REMOTE



1. Press the operator's LEARN button. The red LEARN light will glow. The red light will stay on for about 15 seconds. **A remote must be added or removed while the red LEARN light is still on.**
2. Send a signal from a remote. The opener's light and the red light will flash once if a remote was added, or the opener's light and the red light will flash four times if a remote was removed.
3. Repeat Steps 1 & 2 for any additional remote controls.

## To Remove all Remote Controls



1. Press and hold the operator's LEARN button for ten seconds or more.
2. Release the LEARN button. **The red LEARN light will blink three times signaling that all of the remotes in the operator's memory were erased.** The red

LEARN light will turn off, then turn on for 15 seconds.

The remote control can be entered during this time using Step 2 above.


## Testing

1. Before testing the remote control, straighten out the operator's white antenna wire so it points up.
2. **Stand clear of the door**, press the remote control's button and verify that the operator starts. **PRESS**

**THE REMOTE CONTROLS BUTTON AGAIN TO STOP THE DOOR MID-TRAVEL.**


3. Set the open and close limits as described in the next section before any further testing.

### Replacing a Remote Control's Batteries



When the red light on the remote glows dimly, or fails to light at **all** when the remote is activated, the battery needs replacing.

1. Open the remote's case and remove the circuit board.
2. Replace old battery.
3. Re-assemble the remote.



### FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Contents

1 Documents / Resources

2 Related Posts

Documents / Resources

	<p><a href="#">Supersonic Gate Door Automation MCT-3 3-Channel Visor Transmitter</a> [pdf] Instruction Manual</p> <p>MCT-3, MCT3, 2AQXW-MCT-3, 2AQXWMCT3, ACT-31B, ACT31B, 2AQXW-ACT-31B, 2AQXW ACT31B, MCT-3 3-Channel Visor Transmitter, MCT-3, 3-Channel Visor Transmitter</p>
---	---