



Sysgration BSI37 TPMS Sensor User Guide

[Home](#) » [Sysgration](#) » Sysgration BSI37 TPMS Sensor User Guide 

Sysgration BSI37 TPMS Sensor User Guide



Contents

- [1 Safety Instruction](#)
- [2 Limited Warranty](#)
- [3 Installation Guide](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Safety Instruction

Read all installation, and safety instructions and review all illustrations before installing the sensor. For reasons of safety and for optimal function, manufacturer recommends that any maintenance and repair work is carried out by trained experts only and according to the guidelines of the vehicle manufacturer. The valves are safety-relevant

parts which are intended for professional installation only. Failure to follow installation instructions may result in the failure of the vehicle TPMS sensor to operate properly. Manufacturer does not assume any liability in case of incorrect, faulty or incomplete installation of the product.



Caution

- The manufacturer assemblies are replacement or maintenance parts for vehicles that have a factory installed TPMS.
- Make sure to program sensor by manufacturer programming tool for your specific vehicle make, model and year before installation.
- In order to guarantee optimal function, the sensor may only be installed with valves and accessories by manufacturer.
- Upon completion of installation, test the vehicles TPMS system using procedures described in the original manufacturer's user guide to confirm proper installation.

Limited Warranty

Manufacturer warrants to the original purchaser that the TPMS sensor complies with manufacture product specifications and shall be free from defects in material and workmanship under normal and intended use for a period of twelve (12) months from the date of purchase. The warranty shall be void if any of the following occur:

1. Improper or incomplete installation of products
2. Improper usage
3. Induction of defect by other products
4. Mishandling of product and/or any modifications to the products
5. Incorrect application
6. Damage due to collision or tire failure
7. Racing or competition

Manufacturer's sole and exclusive obligation under this warranty will be to repair or replace at manufacturer's discretion, without charge, any merchandise that does not conform to this above warranty and is returned with a copy of the original sales or satisfactory evidence of date of purchase, to the dealer whom the product was originally purchased or to manufacturer. Notwithstanding the foregoing, in the event that the product is no longer available, manufacture's liability to original purchaser shall not exceed the actual amount paid for the product.

Manufacturer expressly disclaims all other warranties, express or implied, including any warranty of merchantability. For fitness for a particular purpose. Under no circumstance shall manufacturer be liable to any party or person for any other amounts including but not limited to labor charges for installation or reinstallation of products nor shall manufacturer be liable for any other damages including but not limited to glivestnie Thin limited to state. It is exclusive and in lieu of all other obligations, liabilities or warranties whether express or implied.

Installation Guide



WARNING: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS OR THE USE OF IMPROPER TPMS SENSORS MAY RESULT IN THE MOTOR VEHICLE TPMS SYSTEM FAILURE CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

Each time a tire is serviced or dismounted or if sensor is removed, it is MANDATORY to replace the nut, and valve

to ensure proper sealing. The TPMS sensor nut must be properly installed and tightened for proper installation. Carefully follow instructions and use a torque wrench to ensure proper installation. Failure to torque the TPMS sensor nut properly will void the warranty and the TPMS may not function properly.

1. Loosening the tire

Remove the valve cap and core and deflate the tire. Use the bead loosen to unseat the tire bead.




2. Dismount the tire from the wheel



3. Dismount the original sensor

With a screwdriver remove the fastening screw and sensor from the valve stem. Then loosen the nut and remove the valve.



4. Mount the Sensor and valve

Slide the valve stem through the valve hole of the rim. Tighten the nut with 4.0 Nm by torque wrench. Assemble the sensor and the valve against the rim and tighten the screw.




5. Mounting the tire


Clamp the rim onto the tire charger so that the valve faces the assembly head at an angle of 180°.



Sensor with Metal Bracket



Sensor with Metal Strip



Warning:

Correct nut torque: 40 inch-pounds; 4.6 Newton-meters. TPMS SENSOR AND/OR VALVE BROKEN BY OVERTORQUE ARE NOT COVERED UNDER WARRANTY. FAILURE TO ACHIEVE THE NECESSARY TPMS SENSOR NUT TORQUE MAY RESULT IN AN INADEQUATE AIR SEAL, RESULTING IN TIRE AIR LOSS.

FCC Notice:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Place of Repair:

Address:

Phone:

Vehicles owner name:
Sensor Installation Date:
Address:
Motor Vehicle Make:
Model:
VIN:

Documents / Resources



[Sysgration BSI37 TPMS Sensor](#) [pdf] User Guide
HQXB SI37, BSI37 TPMS Sensor, BSI37, TPMS Sensor, Sensor

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.