

System Loco HGC4 Asset GPS Tracker LocoTrack User Guide

Home » System Loco » System Loco HGC4 Asset GPS Tracker LocoTrack User Guide 🖺



Quick Start Guide LocoTrack HGC4.



Document Version: 0.0.1 04/08/2024 © Copyright System Loco Ltd 2024

Contents

- 1 Introduction.
- 2 Device Characteristics.
- 3 Getting Started at HQ.
- 4 Getting Started in the Field.
- 5 Certifications.
- 6 Recycling of the LocoTrack HGC4.
- 7 Disposing of the LocoTrack HGC4.
- 8 Further Guidance.
- 9 Safety Statements.
- 10 Documents / Resources
 - 10.1 References

Introduction.

How the System Works

The LocoTrack HGC4 is a non-rechargeable battery-operated device designed for supply chain, asset tracking – On the Road, Rail, Air or Ocean as well as various under roof applications.


The LocoTrack HGC4 provides location reporting as well as monitoring accurate temperature (NIST traceable), movement, and also reports any LocoTag information that is within reporting range. The LocoTrack HGC4 will regularly report it's location, upload sensor data and is capable of being remotely controlled for shut off commands. With reports while moving at 15-minute intervals and 1 hour during stationary, the LocoTrack HGC4 will operate for 60 days. This duration can be split among multiple on/off sequences, allowing the unit to be used for multiple transits if so desired.

Installation and Asset Association

The LocoTrack HGC4 is pre-configured with default settings. All that is needed is to turn on the device and associate the device with the asset or shipment to which it is attached. To simplify this association process, each LocoTrack HGC4 has a unique identifier that is presented as a number and a barcode on its label.

Association is completed by scanning this barcode and entering a name for the asset on the LocoAware platform. Once associated, the LocoAware platform allows a user to search for a specific asset by asset name or by device ID.

Device Characteristics.





Certifications / Info Label

Getting Started - at HQ.

Step 1 Access the LocoAware platform



Access LocoAware (<u>www.locoaware.com</u>) and login with the credentials provided to your company's administrator.

Step 2 Create device profiles

Create suitable profiles for how you intend to use your devices.

For help with creating device profiles, please see our Knowledge Base article here: https://systemloco.zendesk.com/hc/en-us/articles/360017778920-Profiles

Getting Started – in the Field.

Step 1
Turn on the LocoTrack HGC4



The all-in-one Power Button/LED/Light Sensor are on the face of the device in the top-right corner

Press the Power Button to turn the device on. The LocoTrack HGC4 will gather and communicate data according to the profile you have created and assigned to it.


Depending on how your administrator has configured the device's button behaviour; typically:

- a) A button press will cause the light to flash green to indicate that it is on
- b) If your administrator has disabled the button, no lights will flash


If the administrator has configured the button as an on-off toggle button:

- a) Green indicates the device has been turned on
- b) Red indicates the device has been turned off


Step 2
Confirm on LocoAware that the device has reported to the server



Find your device on www.locoaware.com by entering the Device ID / Barcode number into the search field.



Select the device from the list of search results.




Confirm that the last report time is current with the device's details page.

Step 3
Attach the device to an asset or shipment



The LocoTrack HGC4 can be attached to a single asset or placed inside a box with multiple assets.

Step 4 Monitor the device



Monitor the device from within the LocoAware platform or via the API if integration has been completed.

For information on API integration please visit: https://locoaware.com/apidocs/index

Certifications.

Countries

This product has been certified to the following standards: FCC, UKCA, IC/ISEDC, CE, RoHS, WEEE, NOM/NYCE/IFETEL

Recycling of the LocoTrack HGC4.

System Loco operates a US based recycling & rebate program. Please contact us for a return authorisation and ship to:

System Loco Services 45 Park Ridge Drive Fletcher NC 28732 USA



Disposing of the LocoTrack HGC4.

The HGC4 is a single use device. After use, it can be disposed of according to your local environmental regulations for electronics products containing alkaline batteries. Please check with local authorities to ensure correct disposal.

Further Guidance.

For more help and information with the LocoTrack HGC4 or the LocoAware platform, please see our online Knowledge Base.

https://systemloco.zendesk.com/hc/en-us

Safety Statements.

FCC Rules and Industry Canada (IC) regulatory imformation

Compliance Statement (Part 15.19)

The equipment device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received including interference that may cause undesired operation.

Warning (Part 15.21)

Changes or modifications not expressly approved could void the user's authority to operate the equipment. Manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment.

Compliance Statement (Part 15.105(b))

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna Increase the separation between the equipment and receiver Consult the dealer or an experienced radio/TB technician for help.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Class B digital device notice "CAN ICES-3 (B)/NMB-3(B)"

RF Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set fourth for mobile transmitting devices operation in an uncontrolled environment. End users must follow the specific operating instructions to satisfy RF exposure compliance. The equipment should only be used where there is normally at least 20cm separation between the antenna and all persons/users.

This transmitter must not be co-located or operation in conjunction with any other antenna or transmitter. Any changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Document Version: 0.0.1 www.systemloco.com 04/08/2024



System Loco HGC4 Asset GPS Tracker LocoTrack [pdf] User Guide

HGC4 Asset GPS Tracker LocoTrack, HGC4, Asset GPS Tracker LocoTrack, GPS Tracker LocoTrack, Tracker LocoTrack, LocoTrack

References

- <u>A LocoAware Device Management</u>
- ♣ LocoAPI Documentation
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.