

# Talkpod A36plus Multi Band Radio Transceiver User Manual

Home » Talkpod » Talkpod A36plus Multi Band Radio Transceiver User Manual

Talkpod A36plus Multi Band Radio Transceiver User Manual



### **FCC Statement:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAR tests are conducted using standard operating positions accepted by FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. Before a new model is a available for sale to the public, it must be tested and certified to the FCC that is does not exceed the exposure limit established by the FCC. Tests for each product are performed in positions and locations as required by the FCC.

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with and accessory designated for this product or when used with and accessory that contains no metal.

To maintain compliance with FCC RF exposure guidelines hold the transmitter and antenna at least 1 inch (2.5 centimeters) from your face and speak in a normal voice, with the antenna pointed up and away from the face.

The equipment complies with FCC radiation exposure limits set forth for and uncontrolled environment. In order to comply with the FCC RF exposure requirement, the antenna installation must comply with following:

Users must be fully aware of the hazards of the exposure and able to exercise control over their

RF exposure to qualify for the higher exposure limits.

Your wireless hand-held portable transceiver contains a low power transmitter. This product sends out radio frequency (RF) signals when the Push- – to- Talk(PTT) button is pressed.

The device is authorized to operate at a duty factor not to exceed 50%

**Note**: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Thanks for your favor in our product.

This manual is helpful for you to quickly know how to use the product.

This manual is applicable to the following product:

**Multi Band Transceiver** 

### **Contents**

- 1 Welcome to the world of Talkpod technology
- 2 Features
- 3 Important Notice
- 4 General information
- **5 Radio Structure**
- **6 Button Details**
- 7 Specifications
- **8 Attach Battery**
- 9 Assemble Antenna
- 10 Assembling the Belt Clip
- 11 LED Indicator
- 12 Assembling the Accessories
- 13 Powering On/Of
- 14 Button Details
- 15 Side Buttons
- **16 PTT Button**
- 17 Product Care
- 18 Troubleshooting
- 19 Optional Accessories
- 20 Technical Information
- 21 Documents / Resources
  - 21.1 References
- **22 Related Posts**

### Welcome to the world of Talkpod technology

Congratulations on your purchase of a high quality Talk pod product. Your 2-way radio represents state-of-the-art high-tech engineering. Designed for GMRS (General Mobile Radio Service) operation, this compact package is big on performance. It is a quality piece of electronic equipment, skillfully constructed with the finest components. The circuitry is all solid-state and mounted on rugged printed circuit board. Your two way radio is designed for reliable and trouble-fr performance for years to come

### **Features**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device does not cause harmful interference, and (2) this radio must accept any interference that may cause undesired operation. To maintain compliance with FCC's RF exposure guidelines, for body-worn operation, this radio has been tested and meets the FCC RF expos ure guidelines when used with Quanshun Communication Technology Co., Ltd. accessories supplied or designated for this product. Keypad Lock Whisper Function SOS Siren Power HI/LO Settings Speaker / Microphone Jacks Battery Meter / Battery Low Indicator Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

30 GMRS Channels	Monitor Functio
142 Privacy Codes (38 CTCSS / 104 DCS)	Roger Beep Tone
Waterproof JIS4 Standard	Silent Operation
VOX	Keypad Lock
Selectable Call Alert (5 additional Animal Sounds on G XT1050)	Whisper Function
NOAA Weather Radio	SOS Siren
NOAA Weather Alert	Power HI/LO Settings
NOAA Weather Scan	Speaker / Microphone Jacks
Dual Watch	Battery Meter / Battery Low Indicator
Vibrate Alert	

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device does not cause harmful interference, and (2) this radio must accept any interference that may cause undesired operation. To maintain compliance with FCC's RF exposure guidelines, for body-worn operation, this radio has been tested and meets the FCC RF expos ure guidelines when used with Quanshun Communication Technology Co., Ltd. accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

### **Important Notice**

### FCC LICENSE REQUIRED FOR GMRS OPERATION

(Only Applicable for GMRS Radio Use in the United States) The radios operates on GMRS (General Mobile Radio Service) frequencies which require an FCC (Federal Communications Commission) license. You must be licensed prior to operating on channels 1-7 or 15-22, which comprise the GMRS channels of the radios. Serious penalties could result from unlicensed use of GMRS channels, in violation of FCC rules, as stipulated in the Communications Acts Sections 501 and 502 (amended).

You will be issued a call sign by the FCC which should be used for station identification when operating the radio on GMRS channels. You should also cooperate by engaging in permissible transmissions only, avoiding channel interference with other GMRS users, and being prudent with the length of your transmission time.

To obtain a license or ask questions about the license application, contact the FCC at 1 888-CALLFCC or go to the FCC's website: <a href="http://www.fcc.gov">http://www.fcc.gov</a> and request form 605. Exposure To Radio Frequency Energy

**IMPORTANT:** Changes or modifications to this unit not expressly approved by Quanshun Communication Technology Co., Ltd could void your right to operate this unit. Your radiois set up to transmit a regulated signal on an assigned frequency. It is against the law to alter or adjust thesettings inside the COMMUNICATOR to exceed those limitations. Any adjustment to your radio must be made by qualified technicians.

### **General information**

### Preface

Thanks for your favor in our product. This manual is helpfulfor you to quickly know how to use the product

This manual is applicable to the following product: A36plus, A36, ÿA36P, ÿA361, ÿA37, ÿA371, UV-37, UV-A37,

### **RF Radiation Profile**

Radio Frequency (RF) is a frequency of electromagnetic radiation in the range at which radio signals are transmitted. RF technology is widely used in communication, medicine, food processing and other fields. It may generate radiation during use.

### **RF Radiation Safety**


In order to ensure user health, experts from relevant industries including science, engineering, medicine andhealth work with international organizations to develop standards for safe exposure to RF radiation. These standards consist of:

- United States Federal Communications Commission, Code of Federal Regulations; 47CFR part 2 sub-part J;
- American National Standards Institute (ANSI)/Instituteof Electrical and
- Electronic Engineers (IEEE) C95. 1-1992;
- Institute of Electrical and Electronic Engineers (IEEE) C95. 1 − 1999;
- International Commission on Non-Ionizing Radiation Protection User Manual 03 (ICNIRP) 1998;

### **EU Regulatory Conformance**

As certified by the qualified laboratory, the product is in compliance with the essential requirements and other relevant provisions of the Directive 1999/5/EC. Please note that the above information is applicable to EU countries only.

### **Radio Structure**



### **Button Details**

NO	Icon	Name	Description
1		LED Light	Green: RX Red: TX
2		PTT	Press to Talk
3		Side Button 1	Programable Side button
4	0	Side Button 2	Programable Side button (Better use Long p ress S2 for SOS)
5		Accessory Jack	For Headsets, Program Cable
6		Power Knob	Turn clockwise to power on and increase the volumeTurn counterclockwise to power off the power and decrease the volume
7		SOS button on the top	One click on SOS alarm
8		Keyboard	Multifunction keyboard

# **Specifications**


Regular	
Model Name	A36plus
	TX/RX:462.5500-462.7250MHz,
	462.5625-462.7125MHz
	467.5500-467.7250MHz,
Frequency Range	467.5625-467.7125MHzFM broadcast Receiving:65-1 08MHz
	AM Receiving:108-136MHz
	NOAA Receiving: 161.65-163.275MHz
	VHF Receiving:136-260MHz
	UHF Receiving:350-520MHz
	Scanning:136-520MHz
Number of channels	30 channels(GMRS)
Work Mode	Analog
Frequency Stability	2.5ppm, 5.0ppm
SOS Alarm	
Weight	210g
Size	108*52*28(mm)
Program Key	
Battery	Standard 1500mAh 7.4V
Antenna Impedance	50Ω
IP Rating	IP54
Working Temperature	-30°C ~ +50°C

The above specifications are tested according to applicable standards. Due to the continuous development of technology, the above index data is subject to change without notice.

Receive		
Receiving sensitivity	<0.20uv(12dB SINAD)	
Squelch sensitivity	<0.2uV	
Intermodulation anti-interference	65dB	
Audio distortion	<5%	
Audio power	1W	
Receive current	≤380mA	
Audio Response	+1 ~ -3dB	
Clutter resistance	≥65dB	

launch Part		
Emission current	≤1.3A	
Maximum deviation frequency	≤5KHz/≤2.5KHz	
Stray power	≤ 7.5uW	
Adjacent channel power	≤-65dB	
QT/DQT Frequency deviation	0.7± 0.1KHz/0.4±0.1KHz	
Signal-to-noise ratio	≥-45dB/≥-40dB	
Modulation sensitivity	8-12mV	
Output Power	462MHz Main Channels:34.21dBm 462MHz interstiti al Channels:34.56dBm 467MHz Main Channels:34.1dBm467MHz interstitial Channels:24.2 4dBm	


# **Attach Battery**



### Note

- Turn off the radio before removing the battery.
- If not assembled with battery specified by Company, the radio will give alarm tone to remind you when powering on. Afterwards, it will operate normally.


### **Assemble Antenna**




### Note

Do not swing the radio when holding it by the antenna, so as to avoid lowering the performance and shortening the life span of the antenna.

# Assembling the Belt Clip




### **LED Indicator**



LED Status	Product Status
Steady Green	Receiving
Steady Red	Transmitting


# **Assembling the Accessories**




Powering On/Of



**Button Details** 




### **Side Buttons**



According to different models and user habits, side buttons can be set to group/member/friend selection,SOS or to broadcast current groups.

### **PTT Button**



In different interfaces, press PTT button to make group call, single call, private call.

Multi-Band Portable Transceiver User Manual 11 menu description

No	Function functi on	Secondary menu	Setting instructions
1	SQL	0 9	The lower the squelch level, the easier it is to interfere,t he higher the level, the worse the sensitivity, and the se tting should be moderate
		2.50K	
		5.00K	
		6.25K	
		10.00K	
2	STEP	12.50K	In the frequency mode, press the up and down keys to change the step value of the frequency
		20.00K	
		25.00K	
		30.00K	
		50.00K	
3	MEMCH	000,,256	Indicate the channel number to be stored while store channel. If 'CH' in front of number means this channel already has a channel parameter.
4	DELCH	000,,256	Delete the channel parameters of the specified channel . If there is no CH- means that the channel has no para meters and the operation is invalid.
	R-CTCSS	OFF	None CTCSS
5		67.0HZ,,254.1HZ	Standard CTCSS. Input standard or nonstandard CTCS S via keypad.
_		OFF	None DCS
6	R-DCS	D023N,,D754I	Standard DCS
	T-CTCSS	OFF	None CTCSS
7		67.0HZ,,254.1HZ	Standard CTCSS. Input standard or nonstandard CTCS S via keypad.

No	Function function	Secondary menu	Setting instructions
8	T-DCS	OFF	None DCS
0	1-003	D023N,,D754I	Standard DCS
		OFF	
		Encryption 1	
9	VOICEPRI	Encryption 2	
		Encryption 3	
		Encryption 4	
10	CH-NAME	COMMOM NAME LIST	
11	тот	30,60,480s	The number is from 30 to 480s, and the maximum time for PTT transmission is indicated in 30s steps.
	SAVE	OFF	Off Battery Saving
12		1	Off Battery Saving
12		2	Normal Saving
		3	Super Saving
13	ROGER	OFF	Turn Off
		ON	Turn On
14	RESET	VFO	Menu back to factory setting
1-7	nloe!	ALL	Menu and channel back to factory setting

No	Function function	Secondary menu	Setting instructions		
		OFF	Turn off VOX function, transmitting without PTT pressing.		
15	VOX	1,2,9	Activate the sound pressure intensity of voice control, level 1 issensitive.	the	most
16	W/N	WIDE	Wide mode		
10	VV/IN	NARR	Narrow mode		
17	VOICE	OFF	Turn off voice prompt		
17	VOICE	ON	Turn on voice prompt		
18	BEEP	OFF	Turn off operation prompt		
10	DEEF	ON	Turn on operation prompt		
19	LANGUAGE	ENGLISH	English		
	LANGONGE	CHINESE	Chinese		
20	BCL	OFF	OFF		
20	BOL	ON	ON		
		ON	Background light is always on.		
21	ABR	5s,10s,3min	Time between the background light ON to automate.	atically	y OF
22	OFFSET	00.000,,99.995	In frequency mode, the difference between the transfer and receiving frequencies.	ansmi	tting

No	Function function	Secondary menu	Setting instructions
	SC-REV	то	Time scanning, the walkie-talkie pauses scanning when it detects a signal, and after staying stopped for about 5 seconds, the walkie-talkiewill continue scanning even if the signal is still there.
23		CO	Carrier scanning, the two-way radio pauses scanning w hen a channel is detected and keeps it on the same fre quency until the signal disappears. There is a 2 second delay between the disappearance of the signal and the resumption of scanning to allow time for the response t o begin transmission.
		SE	Search scanning, the walkie-talkie exits scanning when it detects a signal and stays at this frequency.
24	PF2		
25	PF2 LONG PRE SS		
26	PF3		
	SFT-D	OFF	In frequency mode, turn off the difference between the t ransmitting and receiving frequencies.
27		+	In frequency mode, the TX frequency=RX frequency pl us frequency difference
		_	In frequency mode, the TX frequency=RX frequency mi nus frequency difference
28	SCAN CTCSS		

No	Function function	Secondary menu	Setting instructions
29	SCAN DCS		
		ALL	ALL
30	ODE SAVE M	RX	Receiving
		TX	Transmitting
31	POWER ON MS	LOGO	Photo
	G	VOL TAGE	Battery voltage
32	ANI NAME	NUM1NUM60	No.1—No.50 radio. The radio name of 51-60 can be se t
33	S-CODE	1,2,315	
		OFF	Turn off
34	DTMF CODE	вот	Press PTT to transmitting DTMF
34		EOT	Release PTT to transmitting DTMF
		вотн	вотн
35	AUTOLK	OFF	Turn off auto keypad look
33	AUTOLK	5s,10s,3min	Turn on the keypad timing automatic lock function

No	Function function	Secondary menu	Setting instructions
		OFF	No DTMF prompt when press key to transmitting DTMF
		DT-ST	DTMF prompt when press key to transmitting DTMF
36	DTMFST	ANI-ST	DTMF prompt when automatically transmitting DTM
		DT+ANI	DTMF prompt when automatically transmitting DTMF a nd press key to transmitting DTMF
37	SCAN ADD		
38	TONE	1000,1450,1750,2100Hz	
39	PTT-LT	0,100,,1000	Delay time before automatic DTMF transmitting
40	MENU EXIT TIM	5,10,60s	Control the time of menu automatically exit
41	VOX DELAY	0.5SEC 2.0SEC	Due to the delay of the repeater, noise appears when r eceive instant signal.
42	RP_STE	OFF	OFF: Adjust to eliminate the tail. If want to ensure if the repeater is workor not, set OFF.
		1,2,3,4,5,10s	
43	RPT-RL	OFF	OFF: Adjust the length of time the tail sound appears, if not needed, set it to off.
		1,2,3,4,5,10s	

No	Function function	Secondary menu	Setting instructions	
44	ANI FUNCTION	OFF	Turn off	
		ON	Turn on	
45	MDF-A	FREQ	A band displays as frequency in channel mode	
		СН	A band displays as channel in channel mode	
		NAME	A band displays as channel name in channel mode	
46	MDF-B	FREQ	B band displays as frequency in channel mode	
		СН	B band displays as channel in channel mode	
		NAME	B band displays as channel name in channel mode	
47	TX-A/B	OFF	In dual standby mode, transmitting current frequency b and	
		А	In dual standby mode, press PTT to transmitting A ban d for cross-band TX/RX	
		В	In dual standby mode press PTT to transmitting B band for cross-band TX/RX	

No Function function		Secondary menu	Setting instructions	
48	TDR	OFF	Turn off	
			Turn on	
49	STE	OFF	After releasing the PTT, the radio will send a turn-off cod e to suppress the instant noise of the receiver.	
			After releasing the PTT, the radio will send a turn-off cod e to suppress the instant noise of the receiver.	
50	AL-MOD	SITE	On-site Emergency	
		SOUND	Send emergency voice	
		CODE	Send emergency code	
51	DISPLAY	OFF	Turn off	
31		ON	Turn on	
52				
53				

### **Product Care**



Do not pierce or scrape the product with any edged instruments or hard objects.



Keep the product far away frpm substances that can corrode the circuit.



Do not hold the product by its antenna directly



Do not hold the product by its earpiece cable directly.

Attach the accessory jack cover when the product is not in use Keep the product far away frpm substances that cancorrode the circuit.

### **Troubleshooting**

Phenomen	Analysi	Solution	
	The battery may be improperly inst alled.	Remove the battery and reassembl e it.	
Power-on Fallure	The battery power may be used up	Remove or replace the battery.	
	The battery is poorly connected du e to dirtied or damaged battery cont acts	Clean the battery contacts. If the problem cannot be solved, contact you r dealer or authorized service center for inspection and repair.	
	Low battery voltage	Recharge or replace the battery.	
	Low volume leve	Increase the volume by rotating the Volume Control knob.	
During receving, the voice is weak, discontinuous or totally inactive.	The antenna may be loosened or i mproperly installed.	Reassemble the antenna after turning off the radio.	
	The speaker may be blocked or da maged	Clean the surface of the speaker.If the problem cannot be solved, contact your dealer or authorized service center for inspection and repair.	
	The frequency or signaling may be inconsistent with that of other members	Set your TX/RX frequency and sign aling to the same as that of other m embers	
Unable to communicate with other members.	The channel type(digital/anaiog)ma y be set inconsistently	Make sure all members are on the s ame digital/analog channel.	
	You may be interrupted by radios u sing the same frequency	Change the frequency or adjust the squelch level.	

Phenomena	Analysis	Solution
Irrelevant comm	You may be interrupted by radio using the same frequency.	Change the frequency, or adjust the squelch lev el.
unication or noi se is heard on t he channel.	The radio may be set with no signaling.	Set signaling for all member radios to avoid infer ence at the same frequency. And change the sig naling settings for all portable radios at the same time.
	You may be too far away from otjer memb ers.	Move towards other members.
The noise is too loud.	You may locate in an unfavorable position. For example your communication may be blocked by high buildings or frusta rted in the underground areas.	Move to an open and flat area, and restart the ra dio to try again.
	You may suffer from external disturbance( such as electromagnetic interference).	Stay away from equipment that may cause interf erence.

### **Optional Accessories**

The following items are main optional accessories for the radio. For more information of other accessories, olease consult your local dealer

### Note

The following items are main optional accessories for the radio. For more information of other accessories, olease consult your local dealer. accessories.

# Protective case Semi-packed nylon cover / adhesive type / with oblique lanyard / small Semi-packed leather holster / button type / oversized iron back clip / with diagonal strap / medium All-inclusive leather holster / button type / thick leather pattern / with diagonal strap / large Wearable chest bag protector / all black Wearable chest bag protective cover / fluorescent strip

Data line / write frequency line

Waterproof bag



Universal K head dual hole USB to serial port programming cable

/ N4 / N5 / D4 / B3 universal

USB to Micro cable / OD3.8PVC / common to all series

2-Wire Earloop with On-MIC PTT
2-Wire D-Ring Earphone with On-MIC PTT
2-Wire Acoustic Tube with On-MIC PTT
Earloop with In-line Microphone
D-Ring Earphone with In-line Microphone
Acoustic Tube with In-line Microphone
3-Wire Acoustic Tube Surveillance Kit (Black)
Rotatable ear-hook type oval clip PTT headset
Right earhook type oval clip PTT headset
C-type ear-hook oval clip PTT headset
Ear hook + earplug type oval clip PTT headset

# Back clip



2 Series / 3 Series Belt Clip / Spring Type / 7CM

# Hand microphone Speaker Microphone

Speaker Microphone With Volume Control

Power Adap	ter	
	Power adapter / 12V2A / GB	
	Power adapter / 12V2A / European regulations	
	Power adapter / 12V2A / British regulations	
	Power adapter / 12V2A / Australia regulations	
7	Power adapter USB interface / 5V2A	
	Power adapter USB interface / 5V1A	
	Power adapter / 12V1A / GB	
	Power adapter / 12V1A / European regulations	
	Power adapter / 12V1A / British regulations	
	Power adapter / 12V1A / Australia regulations	

### **Technical Information**

Channel Type	Channel Number	Frequency (MH z)	Channel Type	Channel Num ber	Frequency (MHz)
	1	462.5500	467 MHz Main C hannels	1	467.5500
	2	462.5750		2	467.5750
	3	462.6000		3	467.6000
	4	462.6250		4	467.6250
462 MHz Main Channels	5	462.6500		5	467.6500
	6	462.6750		6	467.6750
	7	462.7000		7	467.7000
	8	462.7250		8	467.7250
	1	462.5625	467 MHz interstitial channels	1	467.5625
	2	462.5875		2	467.5875
	3	462.6125		3	467.6125
462 MHz	4	462.6375		4	467.6375
channels	5	462.6625		5	467.6625
	6	462.6875		6	467.6875
	7	462.7125		7	467.7125

### **Documents / Resources**



<u>Talkpod A36plus Multi Band Radio Transceiver</u> [pdf] User Manual GMRS1, 2ADQZGMRS1, A36plus Multi Band Radio Transceiver, A36plus, Multi Band Radio Tr ansceiver, Radio Transceiver, Transceiver

### References

• F© Federal Communications Commission | The United States of America

Manuals+,