

TECHMADE Move everyone everywhere User Manual

Home » **TECHMADE** » **TECHMADE** Move everyone everywhere User Manual



Contents

- 1 TECHMADE Move everyone everywhere User Manual
- **2 READ CAREFULLYAND KEEP**
 - 2.1 MAINTENANCE AND WARRANTY
 - 2.2 WARRANTY SERVICE
 - **2.3 INTERNATIONAL WARRANTY**
 - 2.4 Product warranty
 - 2.5 Safety related
 - 2.6 Environmental (temperature, humidity)
 - 2.7 Cleanliness level
 - 2.8 Battery charging
 - 2.9 Waterproof
 - 2.10 Drying
- 2.11 WEEE instructions
- **3 INSTRUCTIONS**
 - 3.1 DECLARATION OF CONFORMITY
- 4 Read More About This Manual & Download PDF:
- **5 Documents / Resources**
- **6 Related Posts**

TECHMADE Move everyone everywhere User Manual



READ CAREFULLYAND KEEP

We thank you for your preference by choosing a TECHMADE product. Please read the instructions in this manual carefully. Your TECH MADE smartwatch is guaranteed by Techmade S.r.l. for a period of two years from the date of purchase under the terms and conditions of the warranty. As proof of purchase, a copy of the receipt and the stamp of the authorized dealer on the warranty certificate are required in the space provided. The warranty covers material and manufacturing defects. Your smartwatch will be repaired free of charge by our Service Center. The warranty will be void if the smartwatch is tampered with or repaired by people not part of the Techmade S.r.l. service network. In Italy. During the warranty period, for material and manufacturing defects, the only components covered by the warranty are the display, the touch and the internal electronic components of the smartwatch. A component covered by the warranty will be repaired free of charge or the smartwatch will be replaced if manufacturing or material defects are found under normal conditions of use. In case of replacement, Techmade S.r.l. cannot guarantee that you will receive a smartwatch of the same model. If the requested model is not available, it will be replaced with a smartwatch of equal value and similar style.

This warranty does not cover the following:

• Damage and / or improper operation resulting from incorrect use, lack of care, accidents, normal wear and tear or from liquid materials (eg water). In the event that warranty interventions are required, please send the smartwatch, a copy of the retailer's receipt, the warranty certificate and a description of the problem to the nearest authorized service center (for more information write to the assistenza@techmade.eu).
For repairs not covered by this warranty, the service center can carry out the requested services at a cost that will depend on the model of the smartwatch and the type of intervention required. These charges are subject to change. These expenses will be communicated and must be accepted before the execution of the services. Shipping costs and other costs other than repairs under warranty are the responsibility of the owner of the smartwatch. The battery, in the case of the smartwatch, is inserted at the time of manufacture. As a result, its duration may be less than the technical specifications illustrated in our instruction booklet. All smartwatches are made of aluminum alloy, magnetic stainless steel and plastic produced in P. R.C. Smartwatches are produced with hypoallergenic materials in full compliance with current Italian and international regulations.

MAINTENANCE AND WARRANTY

All Techmade smartwatches are built with highly professional technical criteria, using innovative materials, quality tested. Techmade smartwatches are resistant to fresh water but are not suitable for diving and water sports, as the effectiveness of the seals could be compromised. For all models it is recommended not to press the buttons/ not to remove the crown in direct contact with water.

WARRANTY SERVICE

To obtain warranty service, the customer must present a copy of the retailer's receipt, a description of the problem and the duly completed, stamped and dated warranty certificate from the retailer from whom the smartwatch was purchased. The insurance postage costs for sending the smartwatch to an authorized service center are exclusively borne by the owner of the smart watch.

INTERNATIONAL WARRANTY

Your smart watch is guaranteed for twenty-four months with effect from the date of purchase according to the conditions specified in this document. This warranty is internationally valid and covers any material and manufacturing defects.

THE WARRANTY IS VALID ONLY IF COMPLETED CORRECTLY AND COMPLETELY WITH: THE DATE OF PURCHASE, THE STAMP AND SIGNATURE OF THE OFFICIAL DEALER AND THE PROOF OF PURCHASE. The following are excluded from the guarantee: the battery, the strap, the bracelet, the breakage of the display and the touch panel and any damage caused by improper use, negligence, bumps, accidents and normal wear and tear.

TECHMADE S.r.I.

Product Code / Ref.: TM-MOVE

F.C.: ID205G

Description: Smartwatch Trademark: Techmade S.r.l.

All essential test series have been performed and the aforementioned product complies with all legal requirements. This device complies with the essential requirements and other relevant provisions of the RED 2014/53/EU Directive. All essential radio test series have been performed.

Limitations in Intended Use or Foreseeable Misuse

- 1. Do not disassemble the device. If repairs are required, contact a nearest sales center or authorized service center (for more information write to assistenza@techmade.eu).
- 2. It is recommended to keep away from electrical appliances.
- 3. Do not subject the device to shocks, impacts or vibrations.
- 4. Keep away from heat sources (eg radiators or cookers).
- 5. Do not hold the device with wet hands while it is charging. This could cause electric shocks or seriously damage the appliance.
- 6. In the event of immersion in salt water, immediately rinse with fresh water to avoid any damage. Therefore, we do not recommend immersing the device in salt water whenever possible to avoid damage to the metal components (case, buckle, etc.) due to the corrosive agents contained in it.
- 7. If the device is dropped or bumped, the water guards may be damaged.
- 8. Do not recharge the device near flammable materials, which could catch fire due to the developed heat.
- 9. Take care of the battery charging socket/ connection. The battery can be recharged hundreds of times before it needs to be replaced.
- 10. TECHMADE is not responsible for performance problems caused by applications from suppliers other than

TECHMADE.

- 11. Do not modify the product in any way. TECHMADE is not responsible for performance or incompatibility issues caused by changing registry settings or operating system software. Attempting to customize the operating system may cause the product or applications to malfunction.
- 12. This product is not a toy. Keep it out of the reach of children and pets. Product composed of small parts. If ingested they could cause a choking hazard.

Identification of the characteristics of the personnel who will use the machine (physical, competence) and level of training required for users

No particular training for use. Read the instruction booklet.

Product warranty

24 months warranty for the final consumer and 12 months for the professional operator. Opening or attempting to open the product will void the warranty and may constitute a safety hazard.

Safety related

RF output: 0 dBm Handle the device gently. Protect the device from bumps and falls.

Environmental (temperature, humidity)

Working temperatures: -10°Crv45°C/14°Frv 113°F

Cleanliness level

Use a soft, dry cloth. Do not use alcohol or other cleaning solutions.

Battery charging

To charge the battery, use only the supplied cable. Do not try to clean the unit with chemical solvents, it could damage the finish. Wipe with a clean, dry or slightly moistened cloth.

Waterproof

5 ATM waterproof smartwatchs (the smartwatch can support a pressure equivalent to 50 meters deep) are suitable for showering and swimming on the surface, as long as there are no large differences in pressure and temperature (the high temperature of the water may raise the pressure to which the smartwatch is subject). The SATM is also resistant to sweat, splashes of water and rain. It is absolutely not recommended to dive, dive from great heights, dive in hot water, swim and dive in salt water.

Drying

Do not attempt to dry the product using a microwave oven, traditional oven, hairdryer or other sources of heat. Use a dry cloth or mild detergent.





The European Directive 2012/19/EU on waste electrical and electronic equipment (WEEE) provides that these

appliances must not be disposed of in the normal municipal solid waste stream, but that they are collected separately to optimize the flow of recovery and recycling of the materials that make them up and prevent potential damage to health and the environment due to the presence of potentially dangerous substances. The crossed out bin symbol is featured on all products as a reminder. The waste can be delivered to the appropriate collection centers, or it can be delivered free of charge to the distributor upon purchase of a new equivalent equipment or with no obligation to purchase equipment smaller than 25cm. For further information on the correct disposal of these devices, please contact the relevant public service.

INSTRUCTIONS

1. Instructions for charging Charge the device before use. To recharge the device, insert the USB port into a charger (SV =-=-= IA) or PC and correctly position the magnetic connector on the back of the smartwatch.






- 1. Use the charging cable only on a dry, flat and stable surface.
- 2. If there is an obstacle between the smartwatch and the charging cable, the smartwatch may not charge properly.
- 3. After charging the smartwatch, disconnect the power (do not leave the device in charge for whole nights). To avoid damaging the device, use only the supplied cable.
- 4. Do not use if the charging cable is damaged.
- 5. Disconnect the charging cable when cleaning the smartwatch, during a thunderstorm or during an extended period of non-use.
- 6. Do not try to disassemble or modify the smartwatch and the charging cable.
- 7. Do not twist or pinch the charging cable.
- 8. Do not attempt to remove or replace the battery. The substances contained in this product and the battery can cause harm to the environment or health. Please dispose of it properly.

2. Download app

Scan the following QR code to download the app:



3. Bluetooth connection




Note

- Before connecting the device, make sure that the battery is fully charged and that the Bluetooth of the smartphone is turned on.
- Before pairing the device make sure that a previous connection is not already active; if necessary, disconnect the previous connection and re-pair exclusively through the app.
- Make sure that the distance between the smartphone and the smartwatch is not too great and that there is no interference between the two devices.
- Some functions and/ or features may not be available for all smartphones (Android and Apple) on the market.

4. Touch screen actions

- 1. Long press to turn on the device; Press briefly to turn on/off the screen or to return to the previous interface.
- 2. Sensor (on the back)
- 3. Charging compartment (on the back) Touch actions: Scroll left/right and up/down to scroll through the different menu items.




5. Quick menu

Scroll right to access the menu and then three times down to view all the other functions: Sport, Heart rate, Relax, Alarm, Music player, Stopwatch, Weather, Sport history, Settings.




Scroll left again to view the settings menu where you can activate/deactivate the following functions: Continuous heart rate, Wrist Sense, Do not disturb, Phone search.



Scroll down to view the daily data collected: Steps, Distance, Calories, Weekly report, Menstrual report (only if activated via the App).



Scroll up to view the notifications that have arrived.



6. Main Menu and Functions.

These functions cannot replace medical instruments. This product is not a medical device. It must not be used for any diagnosis or other medical applications. Sport: Click on the screen to choose the desired sport among the 8 presets (Outdoor Run, Indoor Run, Outdoor Walk, Indoor Walk, Hiking, Outdoor Cycling, Yoga, Other). Through the App it will be possible to customize the list of sports, replacing those present with others of your choice (Indoor Cycling, Swimming in the pool, Cricket, Elliptical, Rowing machine).

- Once the sport is selected, the smartwatch will automatically start the countdown. During training, it will be possible to suspend / resume training by briefly pressing the button.
- To end the workout, long press the button and select confirm.
- Outdoor sports are equipped with GPS function.



Heart rate: Measurement of heartbeats.



Relax: Breathing exercises. Inhale and exhale following the instructions on the smartwatch



Alarm/Reminder: Open, close and view the alarm/reminder. To add a new alarm/reminder, use the App.



Weather: Will show today's and next day's weather forecast. They will update automatically after connecting to the App.



Stopwatch: Activate the stopwatch or a countdown.



Music player: After connecting to the App, you can listen to and control your music via the smartwatch.



Sport History: Record your recent movements and workouts.



Menstrual Report: Records menstrual cycle information. Available only if activated in the App.



Other functions: Sedentary reminder, Wrist sense, Find device, 3 preset Watchfaces + 1 editable Watchface + Watchfaces downloadable via app.

7. Troubleshooting

- I can't connect the smartwatch
- 1. Check that the GPS and Bluetooth of the smartphone are active.
- 2. Make sure that the smartwatch and the smartphone are not too far apart. The connection must be made within approximately 10 meters.
- 3. Check if the smartphone is in airplane mode. In airplane mode, the smartwatch cannot be connected.
- 4. Make sure the smartwatch is not linked to another account or smartphone.
- 5. Make sure your smartphone's operating system is Android 5.0 or later, iOS 9.0 or later.
- 6. Make sure that a previous connection is not already active; if necessary, disassociate it and re-pair it exclusively through the app.
- I can't synchronize the clock data
- 1. Check that the GPS and Bluetooth of the smartphone are active.
- 2. Make sure that the smartwatch and the smartphone are not too far apart. The connection must be made within

approximately 10 meters.

- 3. Check if the smartphone is in airplane mode. In airplane mode, the smartwatch cannot be connected.
- 4. Make sure the smartwatch is connected to the smartphone via the app.
- · I can't get notifications
- 1. Make sure that notification permissions on the app are active.
- 2. Make sure that the smartwatch and the smartphone are not too far apart. The connection must be made within approximately 10 meters.
 - The alarm / schedule reminder does not work Make sure the settings have been "saved" after they have been changed in the app.
 - The heart rate value is not accurate or cannot be detected

Make sure the heart rate sensor is clean and wear the device securely. Do not move while tracking, sit down and maintain a correct position in order to have a more accurate heart rate value.

DECLARATION OF CONFORMITY

MODEL: TM-MOVE Description: Smartwatch

We, Techmade S.r.l. We declare under our sole responsibility that the product to which this document refers complies with the following standards:

SAFETY EN 62368-1:2014+All:2017;

EMC EN 301 489-1 V2.2.3;

EN 301 489-17 V3.I.1; EN 301 489-19 V2.1.1.;

RADIO EN 300 328 V2.2.2;

EN 303 413 VI.1.1;

HEALTH EN 62479: 2010;

EN 50663: 2017;

We hereby declare that all essential radio and test series have been performed and that the aforementioned product complies with all essential requirements of RED 2014/53/EU and RoHS 2011/65/EU

plus RoHS (EU) 2015/863



Made in China

TECHMADE products are guaranteed for 2 years for all malfunctions and manufacturing defects. For any information please contact your reseller or visit the website www.techmade.eu Product imported by TECHMADE Sri – Via Liberta, 25

- 80055 Portici (NA). Tel. +39 0823 609112 PBX Fax

+39 0823 214667 e-mail: info@techmade.eu

Read More About This Manual & Download PDF:

Documents / Resources



Manuals+,