

TENAMIC HB Series Digital Keypad Safe Box Instruction Manual

Home » TENAMIC » TENAMIC HB Series Digital Keypad Safe Box Instruction Manual



Contents

- 1 TENAMIC HB Series Digital Keypad Safe
- **2 OPENING YOUR SAFE FOR THE FIRST** TIME
- **3 OPENING DOOR**
- **4 AUTOMATIC LOCK and ALARM SYSTEM**
- **5 MOUNTING METHOD**
- **6 CUSTOMER SUPPORT**
- **7 WARRANTY**
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



TENAMIC HB Series Digital Keypad Safe Box



WARNINGS

To prevent damage to your TENAMIC unit or injury to yourself or to others, read the following safety precautions before using this unit.

- DO NOT PLACE OR STORE THE KEYS INSIDE THE SAFE AT ANT TIME.
- DO NOT expose to extreme heat or cold. Battery power may be affected.
- If the battery fails, you will be unable to open the safe.
- Always check to make sure door has latched when closing.

INSERTING THE BATTERIES


- · Open the door with key.
- Insert 4 * AA batteries into the battery compartment.
- If the red light is on , it means the voltage is low and you should insert new batteries.

CAUTION: Replace 4 fresh batteries by lining them up in a manner as indicated by the "+" and "-" signs. When outage for longer than 30 minutes, you should reset the code.

OPENING YOUR SAFE FOR THE FIRST TIME

- When first opening, user should open the safe with the key.
- Remove the keyhole cover, then insert the key, and turn it counterclockwise gently.
- Turn the knob clockwise to open the door.

CAUTION: Finish operation, pull out the key and keep it in a safe place.



SETTING THE USER CODE

- With the door open, press the reset button, start setting code when the yellow light goes on.
- Input new code (3-8 digits), and press the "*" or "#" button to confirm, it will be confirmed by 2 buzzer beeps and the yellow light flashes twice.
- If the yellow light flashes with 3 buzzer beeps, which means the code changing is not effective, and you need to try again.


SETTING THE MASTER CODE

- With the door open, press "00" and press the reset button, start setting code when the yellow light goes on.
- Input new code (3-8 digits), and press the "*" or "#" button to confirm, it will be confirmed by 2 buzzer beeps and the yellow light flashes twice.
- If the yellow light flashes with 3 buzzer beeps, which means the code changing is not effective, and you need to try again.

OPENING DOOR

- Input the code you set (3 to 8 digits), each pressing results one buzzer beep and yellow light flashes.
- Press "*" or "#" button, the green light will be on.
- Rotate the knob clockwise and pull outwards within 5 seconds, the door is opened.

CAUTION: The user preset code "159". Please input the user code again if the yellow light flashes with 3 buzzer beeps.



CLOSING DOOR

• Turn the knob counterclockwise to close the door.

AUTOMATIC LOCK and ALARM SYSTEM

- Three continuously wrong entries will activate the warning beep for 20 seconds.
- Another three continuously wrong entries will activate the warning beep for 5 minutes.

CAUTION: The keypad will be disabled during the beeping. You can only stop the beeps by opening the safe with emergency key and power-cut by removing the battery.


MOUNTING METHOD

TIP: Make sure you have enough clearance for the lid to open properly before mounting the safe and fix the safe in the place that is not easy to move.

- Drill holes for expansion bolts (or clamping screws) in the right place.
- Turn the expansion bolts counterclockwise to separate.
- Use the expansion bolts (or clamping screws) to secure the case to the wall.
- Make sure the case is mounted in place as required and then tighten all screws.

CAUTION:

- Use the expansion bolt when there is a concrete wall surface. Use the clamping screw when there is a wooden wall surface.
- Do not let the safe door face the floor when you mounting the safe with a vertical direction to avoid your property from damage.



CUSTOMER SUPPORT

Dear customer,

Thank you for trusting us. If you have any questions about the product, please feel free to contact our customer service mailbox: tenamic@aliyun.com. We will try our best to solve every after-sales problem for you. If you are satisfied with our products, please don't forget to share the details with your friends and other customers, and tell us your feelings. We sincerely thank you for your support and understanding. Best wishes!

WARRANTY

WARRANTY (Terms and Conditions)

TENAMIC is committed to building high-quality products and will make every effort to ensure our products are free from any defects. We guarantee your safe will be free od defects in materials or workmanship for a period of one year from the date of purchase. This warranty does not cover abuse, misuse, use in any manner for which is not designed, neglect, modification, damage inadvertently caused by the owner; accidents, and/or tampering. If your safe is determined to be defective and we are responsible for the cause we will have it repaired at our expense, or we will send a new replacement at no cost to you. You will be required to return your existing unit as well as all included accessories to TENAMIC prior to the replacement of the defective unit along with your order of purchase. If it is determined your safe needs to be returned or returned our customer support team will provide you with a return detail. Please have the following information available when contacting us:

- Purchaser's name and mailing address, email address, and phone number
- Online order number
- · Detailed description of problem

NEITHER SELLER NOR MANUFACTURER SHALL BE LIABLE FOR ANY INJURY, LOSS OR DAMAGE, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR THE INABILITY TO USE THE TENAMIC SAFE.

Customer Service Contact:

• tenamic@aliyun.com

Documents / Resources



TENAMIC HB Series Digital Keypad Safe Box [pdf] Instruction Manual HB Series Digital Keypad Safe Box, HB Series, Digital Keypad Safe Box, Keypad Safe Box

References

• User Manual

Manuals+, Privacy Policy