RFX GATEWAY_{TM}



ThermoWorks RFX Wireless Gateway Instruction Manual

Home » ThermoWorks » ThermoWorks RFX Wireless Gateway Instruction Manual



Contents

- 1 ThermoWorks RFX Wireless Gateway Instruction Manual
- 2 Getting Started
- **3 Instrument Operation**
- 4 Battery Information
- **5 LED Status**
- 6 Device Layout (Front)
- 7 Device Layout (Rear)
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts

ThermoWorks RFX Wireless Gateway Instruction Manual





Radiance Instruments Ltd.

Flat 2002, 20/F, CEO Tower, 77 Wing Hong Street Lai Chi Kok, Kowloon, Hong Kong, China.

Phone: +852 2466-8608 Fax: +852 2466-1231

Getting Started

Remove the RFX GATEWAY from the packaging and install the antenna on the top.

Tighten the antenna finger tight. Do not over tighten. Download the ThermoWorks App from the Apple Store or Google Play Store. Open the app and follow in-app instructions to add your RFX GATEWAY to your account.

Instrument Operation

All settings and preferences are set and changed through the ThermoWorks App or ThermoWorks Cloud. You can set and adjust high/low alarms, reset max/min temperatures, rename the device, change units (°C or °F), adjust transmission intervals, and connect the device to your Wi-Fi network.

Battery Information

This device contains a built in, rechargeable, Lithium polymer battery(3.7V/2A). Use a 5V, 3A. USB-A adapter (one has been provided with the RFX GATEWAY, adapter input voltage is 100~240VAC) to charge the unit.

Transmission Interval Rate

Use the ThermoWorks App to set transmission intervals.

LED Status

Blue, solid Device setup in progress
Blue, slow blink Wi-Fi provisioning successful
Green, solid Device on and working normally
Red, slow blink Failed Wi-Fi connect or Wi-Fi connection lost
Red, fast blink Failed to connect to ThermoWorks Cloud
Red, solid Device resetting

Device Layout (Front)



Device Layout (Rear)



Cautions for Ambient Pro-Series® Probes

- The probe can be used in a smoker or oven.
- The cable can be closed in a refrigerator or freezer door.
- Do not pull on the cable. Use the molded mini-handle.
- The cable will withstand temperatures up to 700°F.
- The transition can withstand temperatures up to 644°F.
- Probe can be immersed in water. IP67 rated.
- Clean probe by wiping with damp cloth and kitchen cleaner. Can be immersed but do not clean in a dishwasher.
- Avoid repeated kinking or twisting of the probe cable which can break wires.
- With care, the probe should last a long time. Eventually you may need to replace it. Affordable replacements are available. Use only ThermoWorks Pro-Series Probes.

Go to www.thermoworks.com for additional Product information and more tips for use. Scan the QR Code to get up-to-date manuals and see all compatible accessories.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This

equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This device complies with Industry Canada Licence-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC ID: 2AI67-TX5601 IC: 22116-TX5601

Special Notice

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help

For service or warranty:

1-<u>800-393-6434</u> 1-<u>801-756-7705</u>

techsupport@thermoworks.com

www.thermoworks.com

741 E. Utah valley Dr. American Fork, UT 84003

Read More About This Manual & Download PDF:

Documents / Resources



ThermoWorks RFX Wireless Gateway [pdf] Instruction Manual

TX5601, 2Al67-TX5601, 2Al67TX5601, RFX Wireless Gateway, RFX, Wireless Gateway, Gateway

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.