



TIMEX T100 User Guide

[Home](#) » [Timex](#) » TIMEX T100 User Guide

TIMEX

T100

USER GUIDE

05B096000 11.9.20

Register your product at <https://www.timex.com/product-registration.html>

Contents [[hide](#)]

- [1 EXTENDED WARRANTY](#)
- [2 FUNCTIONS](#)
- [3 BASIC OPERATION](#)
- [4 TIME/DATE](#)
- [5 CHRONO](#)
- [6 TIMER](#)
- [7 ALARM/HOURLY CHIME](#)
- [8 INDIGLO® NIGHT-LIGHT](#)
- [9 BATTERY](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)


EXTENDED WARRANTY

Available in U.S. only. Extend your warranty for an additional 4 years from the date of purchase for \$5. You can pay with AMEX, Discover, Visa or MasterCard by calling 1 800- 448-4639 during normal business hours. Payment must be made within 30 days of purchase. Name, address, telephone number, purchase date, and 5-digit model number required. You can also mail a check for \$5 to Timex Extended Warranty, P.O. Box 1676, Dept. EF, Little Rock, AR 72203. Please read the instructions carefully to understand how to operate your Timex® watch. Your model may not have all of the features described in this booklet.

FUNCTIONS

Real-time calendar clock, Second-time zone, Countdown timer, Five daily alarms, Hourly chime, 150 Lap Chronograph with lap/split storage, Indiglo® night-light.

BASIC OPERATION



When setting, each button has a different function as indicated above. Watch face will indicate when the button changes function.

TIME/DATE

1. In TIME mode, press and hold RST/STP. Seconds will flash.
2. Press + to reset seconds to 00.
3. Press MODE, Hour digits flash.
4. Press + or – to change hour including AM/PM... (Scroll through 12 hours to get to AM/PM).
5. Press MODE, Minutes digits flash.
6. Press + or – to change minutes.
7. Continue pattern to set year, month, day of the month, and 12-hour or 24-hour time display.
8. When DONE, press RST/STP.
9. When in Time mode, press MODE until DT appears to see the second time zone.
10. Continue the above pattern to set the second time zone.

CHRONO

LAP 1 = 7.11	LAP 2 = 7.50	LAP 3 = 7.08	LAP 4 = 7.30
SPLIT 1 = 7.11			
SPLIT 2 = 15.01			
SPLIT 3 = 22.09			
SPLIT 4 = 29.39			

1. Press MODE until CHRO appears.
2. Press ST/LAP to start the Chrono timer. Chrono continues to run even if you exit the mode.
3. Press RST/STP to stop the Chrono from running OR while Chrono is running, press ST/LAP to take a split.

NOTES:

- Split times will appear frozen for 3 seconds.
- While Chrono is stopped, press MODE until DATA is on the screen, then press + or – to scroll through stored lap times. To return to Chrono, press the MODE button until Chrono is on the screen.
- Press RST/STP to reset Chrono.

TIMER

1. Press MODE until TMR appears.
2. Press RST/STP, Hour digits flash.
3. Follow the same pattern as setting Time and Alarm to set hours, minutes and seconds.
4. Press RST/STP to confirm settings.
5. Press ST/LAP to start Timer. The timer will continue to run even if you exit Timer mode.
6. An alarm melody will chime when the Timer reaches zero.
7. Press RST/STP to stop Timer... Press and hold RST/STP to reset.

ALARM/HOURLY CHIME

Setting the Alarm is similar to setting Time.

1. Press MODE until AL appears.
2. Pressing RST/STP repeatedly will show the time setting for all 5 alarms, when you see the appropriate alarm, press and hold RST/STP.
3. The alarm sound is activated and hours digits flash... Press + or – to change hours.
4. Press MODE, minute digits flash... Press + or – to change minutes.
5. Press RST/STP to save Alarm Time.


NOTE:

- To access Hourly Chime, press MODE until AL appears... Then press ST/LAP to turn on/off Hourly Chime.

INDIGLO® NIGHT-LIGHT

Press the INDIGLO® button to activate night-light... Electroluminescent technology used in INDIGLO ® night-light illuminates the entire watch face at night and in low light conditions. While the night light is on pressing any button keeps it on for three seconds.

WATER AND SHOCK RESISTANCE

If your watch is water-resistant, meter marking or () is indicated.

Water-Resistance Depth	p.s.i.a. * Water Pressure Below Surface
30m/98ft	60
50m/164ft	86
100m/328ft	160

*pounds per square inch absolute

WARNING: TO MAINTAIN WATER RESISTANCE, DO NOT PRESS ANY BUTTONS UNDERWATER.

1. Watch is water-resistant only as long as a lens, push buttons and case remain intact...
2. Watch is not a diver watch and should not be used for diving...
3. Rinse watch with fresh water after exposure to saltwater...
4. Shock resistance will be indicated on the watch face or caseback. Watches are designed to pass the ISO test for shock resistance. However, care should be taken to avoid damaging the crystal/lens.

BATTERY

Timex strongly recommends that a retailer or jeweler replace the battery. The battery type is on watch back. If present, push/short internal reset switch after replacing battery. Battery life estimates are based on certain assumptions regarding usage; battery life may vary depending on actual usage.


DO NOT DISPOSE OF BATTERY IN FIRE. DO NOT RECHARGE. KEEP LOOSE BATTERIES AWAY FROM CHILDREN.

TIMEX INTERNATIONAL WARRANTY

<https://www.timex.com/productWarranty.html>

©2020 Timex Group USA, Inc. TIMEX and INDIGLO are registered trademarks of Timex Group and its subsidiaries.

Documents / Resources

	<p>TIMEX TIMEX T100 [pdf] User Guide TIMEX, T100, Watch</p>
---	--