



TomTom Go Discover Navigator Device User Manual

[Home](#) » [TomTom](#) » TomTom Go Discover Navigator Device User Manual 

Contents

- 1 TomTom Go Discover Navigator Device
- 2 GET GOING
- 3 CONNECTING A SMARTPHONE
 - 3.1 CONNECTING TO A WIRELESS NETWORK
- 4 LANGUAGE AND UNITS
- 5 ADDENDUM
- 6 Environmental and Battery information
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts



TomTom Go Discover Navigator Device



GET GOING

Device mounting

1. Connect your device's USB cable to the mount
2. Connect the other end of the USB cable to the charger
3. Insert the charger into your vehicle's power socket
4. Place your mount on a smooth surface (e.g., your windshield, driver's side window, dashboard)

Make sure that your device does not obstruct your dashboard, vehicle controls, rear-view mirrors, airbags and field of vision. To maintain an optimal satellite signal, ensure that your device remains upright during use.

NOTE: To ensure that your TomTom GO Discover's high definition screen remains sufficiently powered throughout your drives, we advise you to (i) confirm the strength (i.e., voltage) of the power supplied by your vehicle Car Power Adapter or USB port and (ii) use the charger included with your TomTom GO Discover accessories for optimal performance.

Powering on and off

Switch on your device by pressing the On/Off button

Press and hold the On/Off button for two (2) seconds then tap either Turn off or Sleep to switch off your device or to activate sleep mode.

Pressing and holding the On/Off button for more than five (5) seconds will switch off your device.

Sharing information with TomTom

Upon activating your TomTom GO Discover (i.e., during the First Run Wizard), we will ask for your consent to share data about your locations and stored routes.

Doing this will help us improve our products. The collected information will be stored on your device until we retrieve and anonymize it. If you use TomTom Services (e.g. live traffic, speed camera alerts), we will use your location information to deliver these services to you. Once you have set up your information sharing preferences, you can adjust them as follows:

1. Go to Settings in the main menu
2. Tap System
3. Then Your information and privacy
4. Now turn off information sharing

To see more about what we are doing to protect your privacy, please visit tomtom.com/privacy

NOTE: Information sharing allows for the smooth operation of TomTom Services including traffic, speed cameras, fuel pricing information, EV charging POIs, and off-street parking. Withholding consent to share your location information will disable your TomTom Services.

Caring for your TomTom GO Discover

To ensure optimal device performance:

1. Do not open your device's housing. Doing so is dangerous and will invalidate your device's warranty.
2. Use a soft cloth to wipe and dry your device's screen. Avoid using liquid cleaners.

CONNECTING A SMARTPHONE

Linking your device and smartphone

Connecting your iPhone or Android to your device gets you the ease and safety of TomTom Services such as real-time traffic information, speed camera alerts, weather, fuel pricing and off-street parking and EV Charging POIs.

How to connect with Bluetooth® wireless technology.

1. Switch on Bluetooth on our Smartphone. Make your Smartphone discoverable
2. Go to Settings on your Smartphone and enable Personal Hotspot / Bluetooth-tethering
3. On your TomTom device go to Settings, then Bluetooth and then Add phone
4. Follow the instructions on your TomTom device
5. Select your Smartphone from the list of available devices
6. Accept the pairing request on your Smartphone
7. Select Pair on your TomTom device and you are ready to receive TomTom Services

Unlinking your phone

To safely unlink, go to the Settings menu and select Bluetooth.

Under Paired phones, tap the settings icon next to your phone's name and confirm Forget.

NOTE: You can clear your pairing through the Bluetooth settings on your phone. Resetting your device will also unlink your phone.

Checking your phone's connection

1. Go to the Settings menu and select Bluetooth to see the phone pairing list
2. Select the smartphone you want to connect to.

NOTE: make sure that

- + Smartphone is displayed on your device
- + Bluetooth is switched on
- + Your data plan is active

CONNECTING TO A WIRELESS NETWORK

Connecting to Wi-Fi®

You can update your device's software and map updates wirelessly. To protect your device's security, and to accelerate the speed of downloads, we recommend using an unrestricted (i.e., personal, private) wireless network.

1. Go to Settings in the main menu
2. Select your wireless network you want to connect to and login using your networks password
3. Tap Done then Connect

NOTE: If you do not have access to a wireless network, or if your wireless network is slow, you can update applicable items on your device using your computer's internet connection via a wired USB connection. Map downloads are only available via Wi-Fi.

Disconnecting from Wi-Fi

1. Go to Settings in the main menu
2. Select the wireless network you connected to.
3. Tap Modify then Forget

NOTE: the wireless network that you have disconnected from will remain in your list of available networks, however your device will no longer connect to it automatically.

MAP, SERVICE AND SOFTWARE UPDATES

Why it's important to download updates

To ensure that you are driving with up-to-date road and traffic information, we recommend downloading and installing map region updates, services (e.g., speed cameras) and software updates as soon as they become available.

NOTE: If you stop or cancel a map region update once it has started downloading, go to Settings Map and display > Downloaded maps to start your download again.

Installing a software update

1. Go to Settings > Updates & New Items
 2. From the list, choose the updates you want to install; this list includes items you bought at TomTom's web shop
 3. Sign into your TomTom account following the prompt
- During updates, keep your device connected to a power supply and your device's screen turned off.

Installing a map region

1. Make sure there is an active internet connection via Wi-Fi
2. Then go to Main Menu > Settings > Map and display > Downloaded maps and tap Add

Deleting a map region

1. Go to Main Menu > Settings > Map and display > Downloaded maps and tap Delete
2. Now select the region/s you want to delete

NOTE: Installing and updating map regions must be done via Wi-Fi. If the internet connection to the TomTom server is broken or inactive, the Add buttons will be disabled.

Updating map regions

If there are map region updates available, the status of Downloaded maps in Main Menu > Settings > Map & Display will change from Up to date to Updates available. To download these updates:

1. Go to Main Menu > Settings > Map & Display > Downloaded maps
2. Download and install available updates individually

To speed up the download time you may want to select only the countries you want to update instead of all. Installing multiple countries at the same time might need to be done in several steps.

Resetting map

In case of issues with a map or its regions, you can recover your base map in Main Menu > Settings > System > Reset map

If there is a pending System Update, you will be required to install that update first. The current base map and its installed regions will be deleted from the device and a base map will be reinstalled. You will then be asked to reinstall at least one map region.

MAP & DISPLAY

1. Go to Settings in the main menu
2. Tap Map & Display

Now, you can change the following settings.

- + Day and night colours
- + Menu layout
- + Show on map
- + Arrival info
- + Side bar
- + Zoom & orientation
- + Size of text and buttons
- + Brightness

Show on map

Here you can enable to settings by tapping the toggles of all the features you would like to see on the map.

- + Points of interest (POIs)
- + Lane Guidance on motorways
- + Hill terrain
- + Current street names
- + Map scale bar

NOTE: Your device shows the map view when displaying an alternate route and the guidance view when your vehicle is in motion.

Arrival info

Select Arrival info to change the details shown on the Side bar. You can select either your remaining distance or travel time, to either your final destination or your next stop. You can also adjust your device to switch automatically between your remaining time and distance calculations.

Side bar

To hide the route bar during driving view (so that the bar only pops up when upcoming decisions need to be taken), select Side bar > Hide side bar.

To increase the size of your route bar in guidance view, and see time and distance calculations to traffic congestion along your route, select Side bar > Extra large

To choose POI categories you want to show in the side bar you select POI categories in Side bar > Show in side bar.

Zoom & orientation

Adjust Auto map zoom settings to your preference. Select between:

- + Zoom in at instructions
- + Zoom based on road type
- + No auto zoom

Adjust Map orientation by choosing between 3D, 2D or 2D, north up.

Size of text and buttons

Select Size of text and buttons to adjust text and button sizes. Choose small, medium, or large then tap Apply this change to confirm your changes and to restart your device.

NOTE: This feature is available only on devices with 6-in/15-cm screens and 7-in/18-cm screens.

Brightness

Select Brightness to adjust your display lighting levels. Adjust Day brightness and Night brightness separately, using the individual brightness bars.

Repositioning buttons in the main menu

1. Go to the main menu
2. Press and hold the button you want to move for two (2) seconds
3. Now press either the left or right arrow to move the button
4. Tap Done

NOTE: You can also adjust the positioning of buttons through Edit options in the main menu by tapping on the pencil icon.

ROUTING

Here you can input your routing preferences, including:

- + Preferred route type (Fast, Shortest, Efficient)
- + What to avoid (ferries / car shuttle trains, toll roads, unpaved roads, carpool lanes, motorways, tunnels)
- + Rerouting (Manual, Automatic, None)
- + Switching on/of the route comparison panel

SOUND

1. Go to Settings in the main menu
2. Tap Sounds

Voices

Choose your preferred voice for sharing guidance and alerts from a range of voices available in your chosen language.

Tap on a voice to hear a preview. To confirm your chosen voice, make sure it is selected and then tap the back arrow.

Guidance prompts

Choose whether you would like Arrival time, Early instructions, Road numbers, Road sign info, Street names or Foreign street names read aloud. Tap the toggle of the prompts you would like to be read aloud.

Alerts & sounds

Here you can choose what types of Camera and Safety warning alerts you would like to receive, and when you receive them, for the following features and services:

- + Cameras: Fixed and mobile speed cameras
- + Cameras: Mobile hotspots
- + Cameras: Average speed zones
- + Cameras: Speed enforcement zones
- + Cameras: Red light cameras
- + Cameras: Traffic restriction cameras
- + Safety warnings: Danger zones
- + Safety warnings: Accident black spots
- + Safety warnings: Risk zones
- + Alerts: When speeding
- + Alerts: Traffic jam ahead

You can also choose whether to activate screen touch sounds.

NOTE: you can adjust the frequency of warnings, choosing to turn off warnings altogether, to receive them when you are approaching an incident or speed camera too quickly, or to receive them for every incident and speed camera along your route.

Voice control

Make voice control work for you by selecting if you would like to use it for Alternative Route or Suggested destination.

LANGUAGE AND UNITS

1. Go to Settings in the main menu
2. Tap Language and Units to change the following:

- + Language
- + Country

- + Keyboard layout/language
- + Measurement units
- + Time and date formatting

SYSTEM

1. Go to Settings in the main menu
2. Tap System for:

- + About
- + Reset device
- + Battery settings
- + Your information & privacy

VEHICLE INFO

Go to Settings in the main menu and tap Vehicle Info to input or update your engine or fuel type, to receive services, guidance and information tailored to your vehicle.

MOVING LANE GUIDANCE

Moving Lane Guidance prepares you for merges and exits by highlighting the lane you should stay in based on your planned route. The feature is optional and can be closed and deactivated. To close the Moving Lane Guidance display, tap anywhere on your device's screen.

To disable Moving Lane guidance, go to Main Menu > Settings > Map & Display > Show on map and disable the setting Lane guidance on motorways.

NOTE: Moving Lane Guidance may not be available for the roadway you are traveling on.

MY PLACES

Deleting a location from My Places

1. Go to My Places in the main menu
2. Tap Delete
3. Select the locations you want to delete and tap Delete

Deleting a recent destination from My Places

1. Go to My Places in the main menu
2. Tap Recent destinations
3. Then Edit list
4. Select the destinations you want to remove and tap Delete

MY ROUTES

My Routes provides an easy way to save and retrieve routes and tracks, be it your route to work, planned vacation routes or regular routes taken to visit friends or family. You can create your own routes and find thousands of inspirational RoadTrips on www.mydrive.tomtom.com

SPEED CAMERAS

About TomTom Speed Camera Alerts

TomTom's Speed Camera Alerts service warns you about the locations of the following hazards and traffic enforcement cameras:

- + Fixed and mobile speed cameras: check the speed of passing vehicles
- + Mobile speed camera hotspots: show where mobile speed cameras are often used
- + Average speed camera: measure your average speed between two points
- + Speed enforcement zones: contain multiple speed cameras
- + Red light cameras: check for vehicles' traffic violations at traffic lights
- + Traffic restriction cameras: alert you to roadways that are restricted
- + Accident blackspot locations: places where traffic accidents have frequently occurred

You can access the Speed Camera Alerts service on your TomTom GO Discover through an active internet connection.

NOTE: TomTom's Speed Camera Alerts service may not be available in the country you are driving through. For drivers traveling through France, TomTom provides the Danger and Risk Zone Warnings service. In Switzerland and Germany, the use of devices that alert users to the locations of fixed and mobile speed camera locations are prohibited. In compliance with these laws, speed camera alerts have been deactivated on all TomTom GPS Sat Navs. You can, however, reactivate these alerts for travel outside Germany and Switzerland. Since the legality of speed camera alerts varies throughout the EU, this service is available for use at your own risk. TomTom assumes no liability for your use of these alerts and warnings.

Speed Camera Alert Notifications

Depending on your settings you will be notified of speed camera locations through the following:

- + Speed camera icon in the route bar and along your route on the map
- + Distance to the speed camera in the route bar
- + Speed limit at the camera's location in the route bar
- + Audible alert as you get closer to the camera's location
- + Your speed is monitored when you are approaching a camera's location and when you are driving in an average speed check zone.

If you drive more than 5 km/h (3 mph) over the designated speed limit, the route bar will turn red. If you drive up to 5 km/h (3 mph) over the designated speed limit, the route bar will turn orange.

To see the type of traffic enforcement camera, the maximum speed, and the length of an average speed check zone in the map and guidance views, select one of the speed camera icons in the route bar. In the map view, you can also select a traffic enforcement camera type that appears along your route.

Reporting a speed camera location

If you pass a speed camera location that you did not receive an alert about, please report it. Make sure you are connected to TomTom services and are signed in to your TomTom account. Once you have reported the camera's location, the details will be saved to your device, anonymized and then shared with other drivers. You can report speed camera locations in two (2) ways:

Using the speed panel

1. Tap the speed camera symbol on the speed panel in the guidance view
2. To confirm that your speed camera report has been registered, you will see a message thanking you for the update

Using the quick menu

1. Tap the current location icon or the speed panel in the guidance view
2. Then tap Report speed camera from the pop-up menu
3. To confirm that your speed camera report has been registered, you will see a message thanking you for the update

NOTE: to delete a speed camera report, tap Cancel in the message.

Updating location information for cameras and hazards

Just after you pass the known location of a mobile speed camera, you will be asked in a route bar message if the camera is still there. Tap Yes to confirm or No to update camera location information.

DANGER AND RISK ZONES

TomTom's Danger and Risk Zone Warnings service is configured specifically for travel on roadways throughout France.

Since January 3, 2012, it has been illegal to receive warnings about the locations in France of fixed and mobile speed cameras.

In compliance with this law, your TomTom GO Discover will warn you when you are approaching danger zones and risk zones (as opposed to speed camera locations).

NOTE: danger zones are designated, permanent locations. Risk zones are reported by motorists and are classified as "temporary" danger zones.

Since danger zones and risk zones may contain one (1) or more speed cameras and driving hazards, the danger zone icon will be displayed as you approach either zone. The minimum length of these zones is 300m [0.19 miles] for roads in urban areas, 2000m [1.24 miles] for secondary roads and 4000m [2.49 miles] for motorways.

- + Speed camera locations are now unavailable and have been replaced by a danger zone icon that will be displayed as you approach designated zones
- + The length of the zone depends on the road type and can be 300m, 2000m or 4000m
- + More than one (1) speed camera may be located within each danger zone
- + If speed camera locations are close together within a single danger zone, your danger zone warnings may merge and result in the length of the upcoming danger zone being extended. Please note that outside France, you will receive alerts about speed camera locations.

Inside France, you will receive warnings about danger zones and risk zones.

QUICK DEVICE FIXES

Device does not start or stops responding to commands

If your device is not responding, first check that your device's battery is charged.

Your device will alert you when its battery charges are low and critically low. Low and critically low battery charges will cause your device to lose its connection to TomTom services. If your battery's charge is depleted, your device will switch to sleep mode.

If this doesn't solve the problem, you can perform a restart. To do this, press and hold the On/Off button until you see the TomTom logo and hear the drum roll.

ADDENDUM

Important Safety Notices and Warnings

Global Positioning System (GPS), Global Navigation Satellite Systems (GLONASS) and Galileo The Global Positioning System (GPS), Global Navigation Satellite System (GLONASS) and Galileo systems are satellite-based systems that provide location and timing information around the globe.

GPS is operated and controlled by the Government of the United States of America, which is solely responsible for its availability and accuracy.

GLONASS is operated and controlled by the Government of Russia, which is solely responsible for its availability and accuracy.

GALILEO is operated by the European GNSS Agency (GSA), which is solely responsible for its availability and accuracy.

Changes in GPS, GLONASS or GALILEO availability and accuracy, or in environmental conditions, may impact the operation of this device. TomTom disclaims any liability for the availability and accuracy of GPS, GLONASS or GALILEO.

SAFETY MESSAGES

Important! Read before use!

Death or serious injury could result from failure or partial failure to follow these warnings and instructions. Failure to properly set up, use and care for this device can increase the risk of serious injury or death, or damage to the device.

Use with care warning

It is your responsibility to use best judgment, due care and attention when using this device. Don't allow interaction with this device to distract you while driving. Minimize the time spent looking at the device screen while driving. You are responsible for observing laws that limit or prohibit the use of mobile phones or other electronic devices, for example, the requirement to use hands-free options for making calls when driving. Always obey applicable laws and road signs, especially those relating to your vehicle's dimensions, weight and payload type. TomTom does not guarantee the error-free operation of this device nor the accuracy of route suggestions provided and shall not be liable for any penalties arising from your failure to comply with applicable laws and regulations. The user needs to switch off the device when exposed to areas with potentially explosive atmospheres such as petrol stations, chemical storage depots and blasting operations.

Notice for oversized/commercial vehicles

Devices without a truck or camper map installed will not provide appropriate routes for over-sized/commercial vehicles. If your vehicle is subject to weight, dimension, speed, route or other restrictions on a public road then you must only use a device that has a truck or camper map installed. Your vehicle specifications must be entered accurately on the device. Use this device as a navigation aid only. Do not follow navigation instructions which may put you or other road users in danger. TomTom accepts no liability for damages resulting from your failure to observe this notice.

Proper mounting

Do not mount the device in a way that may obstruct your view of the road or your ability to control the vehicle. Do not place the device in an area that may obstruct the deployment of an airbag or of any other safety feature of your vehicle.

Pacemakers

Pacemaker manufacturers recommend that a minimum of 15cm / 6 inches be maintained between a handheld wireless device and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with independent research and recommendations by Wireless Technology Research.

Guidelines for people with pacemakers:

- You should ALWAYS keep the device more than 15cm / 6 inches from your pacemaker.
- You should not carry the device in a breast pocket.

Other medical devices

Please consult your physician or the manufacturer of the medical device, to determine if the operation of your wireless product may interfere with the medical device.

Device care

- It is important to take care of your device:
- Do not open the casing of your device under any circumstances. Doing so may be dangerous and will invalidate the warranty.
- Wipe or dry the screen of your device using a soft cloth. Do not use any liquid cleaners.

Rating

Device	TomTom GO Discover 5"	TomTom GO Discover 6"	TomTom GO Discover 7"
Rating	5V-2.0A	5V-2.4A	5V-2.4A
	Lithium-ion	Lithium-ion	Lithium Polymer

How TomTom uses your information

Information regarding the use of personal information can be found at: tomtom.com/privacy.

Environmental and Battery information

Your device

Do not disassemble, crush, bend, deform, puncture or shred your device. Do not use it in a humid, wet and/or corrosive environment. Do not put, store or leave the device in a high temperature location, in direct sunlight, in or near a heat source, in a microwave oven or in a pressurised container, and do not expose it to temperatures over 50°C (122°F) or below -20°C (-4°F).

Avoid dropping the device. If the device is dropped and you suspect damage, please contact customer support.

Use the device only with the chargers, mounts or USB cables provided. For TomTom approved replacements, go to tomtom.com.

Operating temperature

This device will remain fully operational within the temperature range 32°F / 0°C to 113°F / 45°C. Prolonged exposure to higher or lower temperatures can cause damage to your device and is therefore advised against. Temperatures: Standard operation: 32°F / 0°C to 113°F / 45°C; short period storage: -4°F / -20°C to 122°F / 50°C; long period storage: -4°F / -20°C to 95°F / 35°C. Important: Before you switch on the device, let the device acclimatise to the standard operation temperature range for at least 1 hour. Do not use the device outside of this temperature range.

Device battery (Non-replaceable)

Depending on the model this product contains a lithium ion or lithium polymer battery. Do not modify or re-manufacture the battery. Do not attempt to insert foreign objects into the battery or immerse or expose to water or other liquids. Do not expose the battery to fire, explosion or any other hazard. Do not short circuit a battery or allow metallic conductive objects to contact battery terminals. Do not attempt to replace or remove the battery yourself unless the user manual clearly indicates that the battery is user replaceable. For TomTom GO Discover, a qualified professional should remove the battery. User replaceable batteries must only be used in systems for which they are specified.

Caution: Risk of explosion if the battery is replaced by an incorrect type. If you have a problem with the battery, please contact TomTom Customer Support. The stated battery life is the maximum possible battery life which is based on an average usage profile and can only be achieved under specific atmospheric conditions. To prolong the battery life, keep the device in a cool, dry place and follow the tips specified in this FAQ: tomtom.com/battery tips. Charging will not occur at temperatures below 32°F / 0°C or over 113°F / 45°C.

Failure to follow these guidelines may cause the battery to leak acid, become hot, explode or ignite and cause injury and/or damage. Do not attempt to pierce, open or disassemble the battery. If the battery leaks and you

come into contact with the leaked fluids, rinse thoroughly with water and seek medical attention immediately.

Battery waste disposal

THE BATTERY CONTAINED IN THE PRODUCT MUST BE RECYCLED OR DISPOSED OF PROPERLY ACCORDING TO THE LOCAL LAWS AND REGULATIONS AND ALWAYS KEPT SEPARATE FROM HOUSEHOLD WASTE. BY DOING THIS YOU WILL HELP CONSERVE THE ENVIRONMENT.

WEEE – e-waste disposal

In the EU/EEA, this product is marked with the wheelie bin symbol on its body and/or packaging as required by Directive 2012/19/EU (WEEE). This product shall not be treated as household waste or be disposed of as unsorted municipal waste. You can dispose of this product by returning it to the point of sale or bringing it to your local municipal collection point for recycling. Outside of the EU/EEA, the wheelie bin symbol may not have the same meaning. More information about national recycling options can be requested from a responsible local authority. It is the responsibility of the end user to comply with local law when disposing of this product.

USA Specific Absorption Rate (SAR) Compliance

THIS WIRELESS DEVICE MODEL MEETS GOVERNMENT REQUIREMENTS FOR EXPOSURE TO RADIO WAVES WHEN USED AS DIRECTED IN THIS SECTION

This GPS Navigation System is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government, Industry Canada of the Canadian Government (IC).

The SAR limit recommended by the Federal Communications Commission (FCC) of the U.S. Government, Industry Canada of the Canadian Government (IC) is 1.6W/kg averaged over 1 gram of tissue for the body (4.0 W/kg averaged over 10 grams of tissue for the extremities – hands, wrists, ankles and feet). Tests for SAR are conducted using standard operating positions specified by FCC/IC with the device transmitting at its highest certified power level in all tested frequency bands.

FCC information for the user

THE DEVICE COMPLIES WITH PART 15 OF THE FCC RULES

Federal Communications Commission (FCC) Statement

This equipment radiates radio frequency energy and if not used properly – that is, in strict accordance with the instructions in this manual – may cause interference to radio communications and television reception.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC Warnings

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Caution: Exposure to Radio Frequency Radiation

1. To comply with the Canadian RF exposure compliance requirements, this device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.
2. To comply with RSS 102 RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons.

FCC Warnings

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This equipment was tested for FCC compliance under conditions that included the use of shielded cables and connectors between it and the peripherals. It is important that you use shielded cables and connectors to reduce the possibility of causing radio and television interference. Shielded cables, suitable for the product range, can be obtained from an authorized dealer. If the user modifies the equipment or its peripherals in any way, and these modifications are not approved by TomTom, the FCC may withdraw the user's right to operate the equipment.

For customers in the USA, the following booklet prepared by the Federal Communications Commission may be of help: "How to Identify and Resolve Radio-TV Interference Problems". This booklet is available from the US Government Printing Office, Washington, DC 20402. Stock No 004-000-00345-4.

	TomTom GO Discover 5"	TomTom GO Discover 6"	TomTom GO Discover 7"
FCC ID*	Contains FCC ID: S4LFF50	Contains FCC ID: S4LFF50	Contains FCC ID: S4LFF50
IC*	Contains IC: 5767A-FF50	Contains IC: 5767A-FF50	Contains IC: 5767A-FF50

FCC Country Code Selection

The Country Code Selection feature is disabled for products marketed in the US or Canada. Per FCC regulations, all Wi-Fi products marketed in US must be fixed to US operation channels only.

Location of FCC ID and IC ID Information on your Device

The FCC ID and IC ID can be found on the bottom of your device.

Emissions Information for Canada

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

Operation is subject to the condition that this device does not cause harmful interference.

This Class B digital apparatus complies with Canadian ICES-003. CAN ICES-3(B)/NMB-3(B)

The Country Code Selection feature is disabled for products marketed in the US or Canada.

IMPORTANT NOTE

IC Radiation Exposure Statement:

- This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.
- End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain with IC RF exposure compliance requirements, please follow the operation instructions in this manual.

Triman logo

Certification for Australia

This product displays the Regulatory Compliance Mark (RCM) to show that it complies with relevant Australian regulations.

Certification for New Zealand

This product displays R-NZ to show it complies with relevant New Zealand regulations.

TomTom MyDrive app

This device is compatible with the TomTom MyDrive mobile application which may be downloaded from the appstores. The use of the TomTom MyDrive mobile application on your smartphone and any integration with your product will require that your smartphone has a wireless data service plan provided by a third-party wireless service carrier. The procurement of and all charges associated with such a connectivity plan are your responsibility. TomTom shall not be liable for any costs or expenses associated with such network connectivity plan (such as the data charges or possible tethering fees which may be imposed by your carrier). Any changes to the availability or reliability of the network connection may impact the operation of certain TomTom services which may be offered on this device.

Responsible Party in North America

TomTom, Inc., 11 Lafayette Street, Lebanon, New Hampshire, NH 03766.

Terms and Conditions: Limited warranty and EULA

Our terms and conditions, including our limited warranty and end user licence terms apply to this product. Visit tomtom.com/legal.

This document

Great care was taken in preparing this document. Constant product development may mean that some information is not entirely up to date. The information is subject to change without notice.

TomTom shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the performance or use of this document.

This document may not be copied without the prior written consent from TomTom N.V.

Model numbers

TomTom GO Discover: 4YB50, 4YB60, 4YB70

CE mark and Radio Equipment Directive for TomTom GO Discover

This device can be used in all EU Member States. The frequency bands and the maximum radio frequency emission power in which this device operates are as follows:

Hereby, TomTom declares that the radio equipment type TomTom GO Discover GPS Navigation system is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: http://www.tomtom.com/en_gb/legal/declaration-of-conformity/

Model	Frequency band (Bluetooth)	Maximum radio frequency emission power	Frequency band (Wi-Fi)	Maximum radio frequency emission power	Frequency band (GPRS 900)	Maximum radio frequency emission power
4YB50	2402 – 2480 MHz	9.98 dBm	2412 – 2472 MHz	18.38 dBm	5180 – 5825 MHz	19.88 dBm
4YB60	2402 – 2480 MHz	9.98 dBm	2412 – 2472 MHz	18.38 dBm	5180 – 5825 MHz	19.88 dBm
4YB70	2402 – 2480 MHz	9.98 dBm	2412 – 2472 MHz	18.38 dBm	5180 – 5825 MHz	19.88 dBm

EU Specific Absorption Rate (SAR) compliance

THIS WIRELESS DEVICE MODEL MEETS GOVERNMENT REQUIREMENTS FOR EXPOSURE TO RADIO WAVES WHEN USED AS DIRECTED IN THIS SECTION

This GPS Navigation System is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Council of the European Union. The SAR limit recommended by The Council of the European Union is 2.0W/kg averaged over 10 grams of tissue for the body (4.0 W/kg averaged over 10 grams of tissue for the extremities – hands, wrists, ankles and feet). Tests for SAR are conducted using standard operating positions specified by the EU council with the device transmitting at its highest certified power level in all tested frequency bands.

Accessories supplied with this device

All devices and models are supplied with a Quick Start Guide, single port car charger and a USB cable.

Copyright notices

© 1992 – 2020 TomTom. All rights reserved. TomTom and the “two hands” logo are trademarks of TomTom N.V. or one of its subsidiaries.

The software included in this product contains copyrighted software that is licensed under the GPL. A copy of that licence can be viewed in the Licence section. You can obtain the complete corresponding source code from us for a period of three years after our last shipment of this product. For more information, visit tomtom.com/gpl or contact your local TomTom customer support team at tomtom.com/support. Upon request, we will send you a CD with the corresponding source code.

Cerence® is a registered trademark of Cerence Operating Company and is used here under license.


The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by TomTom is under licence. Other trademarks and trade names are those of their respective owners.

Wi-Fi® is a registered trademark of Wi-Fi Alliance®.

Apple, iPhone, Mac and Siri are trademarks of Apple Inc. registered in the U.S. and other countries.

Google, Google Play, the Google Play logo, Android and other marks are trademarks of Google LLC.

Documents / Resources

	TomTom Go Discover Navigator Device [pdf] User Manual Go Discover, Navigator Device, Go Discover Navigator Device, Navigation Device, Navigator
---	--

References

- [📍 TomTom “ Mapping and Location Technology](#)
- [📍 Open Source](#)
- [📍 TomTom Legal Information](#)
- [📍 TomTom Privacy and Your Information](#)
- [📍 TomTom Support](#)
- [🌐 TomTom MyDrive](#)
- [📍 TomTom Legal Information](#)