

## Trimble GS075-B-V2 Anti Two Block Switch User Manual

Home » Trimble » Trimble GS075-B-V2 Anti Two Block Switch User Manual

Trimble GS075-B-V2 Anti Two Block Switch User Manual



**Anti-Two-Block Switch** 

GS075-B-V2

Crane Anti-Two-Block sensor

#### **Contents**

- 1 Features:
- 2 Applications:
- 3 General Description:
- 4 Ordering information
- **5 Specifications**
- 6 Absolute maximum ratings
- **7 Certifications**
- 8 Dimensions and installation
- 9 FCC Compliance Statement (USA)
- 10 Industry Canada (IC) Compliance Statement
- 11 Information to the Use
- 12 Documents / Resources
  - 12.1 References

#### Features:

- Anti-Two-Block Switch
- · Sealed switch mechanism
- Mechanism life over 250,000 cycles
- Malleable cast iron and stainless-steel enclosure
- Line of sight radio range of 4000 ft (1300m)
- Two ways radio communications
- Operates from one 'D' cell battery lithium 3.6V or alkaline 1.5V.
- 3 to 4 years battery life for typical applications
- ISM License free band with wavelength and modulation optimized for radio communication in industrial environment.
- Temperature range: -40°C to 65°C (-40°F to 150°F)
- Potted electronics for increase waterproof protection
- Class 1 division 1 option available



Anti-Two-Block switch P/N: GS075-B-V2

## **Applications:**

· Anti-two-block limit switch.

### **General Description:**

The anti-two-block switch comprises of the radio transmitter, battery and switch mechanism. The switch mounts at the boom tip. A weight and chain assembly is attached to the bottom eyebolt of the A2B switch. When the weight assembly is lifted by the ball/block, the internal switch in the A2B will trip an alarm, warning the operator of a two-block event.

The switch mounting bracket design allows the switch to rotate in two axis. The quick slip design of the mounting bracket allows the switch to easily be added or removed from the switch mounting bracket without the need for tools.




Figure: GS075-B-V2 installation on the main boom to limit the height of the hook block

# Ordering information

Model	Description
GS075-B-V2	Anti-Two-Block Switch
GS075-B-CE-V2	868MHz frequency band
GS075-B-CSA-V2	Class 1 Division 1 version of the GS075-B-V2. Intrinsically safe, temperature code T4.
TA011	Replacement sensor antenna
LB011	Anti-Two-Block Switch Mounting Bracket (ordered separately)
LB010	Weight & Chain Assembly
LB012	Fastline Weight & Chain Assembly
TB021	Spare 'D' cell lithium battery 3.6V
TB015	Spare 'D' cell lithium battery 3.6V for class 1 division 1 version

# Specifications

Parameter		<b>Test Condition</b>	Min	Тур	Max	Unit
Switch trave	1					
Length				3/8		In
				(9.5)		(cm)
Radio Power	•					
		GS075-B-V2 (all versions)		0.0054		Watts
				7		dBm
Radio Frequ	ency					
	North American version	GS075-B-V2 (and CSA)	903	916	927	MHz
		CSH				
	European version	GS075-B-CE-V2	868	869	870	MHz
<b>Battery life</b>						
·		'D' cell battery life depends on usage	12	24	28	Months
		'D' cell alkaline battery	8	12	16	Months
Other	****	GG0 <b>55</b> D 110		1.0		
	Weight	GS075-B-V2		10		lbs
				(4.6)		(kg)

## **Absolute maximum ratings**

Parameter	Test Condition	Min	Тур	Max	Unit
Temperature range	Operating	-40		+65	°C
		-40		+150	${}^{\mathrm{o}}\mathrm{F}$

### **Certifications**

FCC/IC/CE certification: FCC Part 15 Subpart C 15.247,15.205, 15.207 & 15.209

ETSI EN 300 220 (AA)

EMI/C - EN 61000-4-3, EN 61000-4-2

CSA certificate number - 80130757


CSA C22.2 No. 60079-0:19, 60079-11:14 (R2018), 61010-1-12, Update 1&2, Amd1:2018 UL 60079-0-2020, UL 60079-11-2018, UL 61010-1-2018


Class I, Division 1, Group A, B, C & D T4 Ex ia IIC T4 Ga Class I, Zone 0, AEx ia IIC T4 Ga

Ambient Temperature: -20°C to 40°C.


WARNING: Only use Tadiran TL-5930 3.6V or Saft LS33600 cell 3.6V text.

### **Dimensions and installation**





A2B Switch (not to scale)



Units are in inches [millimeters]

LB011 footing (not to scale)

Position the sensor mounting bracket (LB011). To ensure that the sensor can pivot securely on the mounting bracket throughout the full range of boom angle, the mounting bracket must be positioned at a 30° from horizontal with the boom parallel to the ground and such that the locking pin of the mounting bracket points up.

Install the GS075-B-V2 on the LB011 (switch bracket) already installed on the crane boom, with the antenna pointing away from the boom. Install a weight and chain assembly to the eye nut. The weight and chain assembly can either be supplied by LSI (as an option) or the original assembly supplied with the crane. If the original assembly is to be used, its total weight must not be more than 13lb.

PMN: GS075-B-V2 HVIN: MB114-01-SD-A

## FCC Compliance Statement (USA)

FCC ID: S9E-GS200E

Compliance Statements: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including, an interference that may cause undesired operation.

#### Caution Statements:

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

## **Industry Canada (IC) Compliance Statement**

IC: 5817A-GS000E

Compliance Statements: This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: 1) This device may not cause interference., 2) This device must accept any interference, including interference that may cause undesired operation of the device.

#### Caution Statements:

- This equipment complies with radio frequency exposure limits set forth by Industry Cananda for an uncontrolled environment.
- This equipment should be installed and operated with a minimum distance of 20 cm between the device and the user or bystanders.

#### Information to the Use

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **Documents / Resources**



<u>Trimble GS075-B-V2 Anti Two Block Switch</u> [pdf] User Manual GS200E, S9E-GS200E, S9EGS200E, GS075-B-V2 Anti Two Block Switch, GS075-B-V2, Anti Two Block Switch, Switch

### References

• User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.