



# Trust TCKT5 Bluetooth Sensor for Undercarriage Components Instruction Manual

[Home](#) » [Trust](#) » Trust TCKT5 Bluetooth Sensor for Undercarriage Components Instruction Manual 

## Contents

- [1 Trust TCKT5 Bluetooth Sensor for Undercarriage Components](#)
- [2 GENERAL SPECIFICATIONS](#)
- [3 MAINTENANCE](#)
- [4 DISPOSAL PROCEDURE](#)
- [5 DISPOSAL/RECYCLE](#)
- [6 FCC Class B Compliance Statement](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



**Trust TCKT5 Bluetooth Sensor for Undercarriage Components**



### **Bluetooth sensor for undercarriage components**

- Bluetooth® 5.1
  - 2.4 GHz transceiver;
  - +4 dBm TX power.
- NTC thermistor.
- Working hours.
- Revolution counter.
- 4 years of operative life.

### **GENERAL SPECIFICATIONS**

- **Battery:** 3.0V CR2450
- **Operating Temp:** -40° to 103 °C

### ***WARNINGS***

- Battery are nonreplaceable, DO NOT try to replace it.
- TCKT5 comes already installed, DO NOT try to uninstall the device from the ITM undercarriage component.


### **MAINTENANCE**

- No maintenance required

### **COSTUMER SERVICE**

- Contact your sales customer service

## DISPOSAL PROCEDURE



- #1 – Remove the seeger
- #2 – Remove the cap
- #3 – Extract the sensor

## DISPOSAL/RECYCLE

Do not replace equipment and its accessories in the trash. Items must be properly disposed of in accordance with local regulations. Please see [www.epa.gov](http://www.epa.gov) or [www.erecycle.org](http://www.erecycle.org) for additional information.

## FCC Class B Compliance Statement

The user is cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna;
- Increase the separation between the equipment and receiver;
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected;

- Consult the dealer or an experienced radio or television technician for help.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

1. this device may not cause harmful interference.
2. this device must accept any interference received, including interference that may cause undesired operation

## Italtractor ITM S.p.A.

- Via Confortino 30, 1-40056 Valsamoggia
- Crespellano – Bologna Italy

## Documents / Resources



[Trust TCKT5 Bluetooth Sensor for Undercarriage Components](#) [pdf] Instruction Manual 000TCKTX, 2A845000TCKTX, TCKT5 Bluetooth Sensor for Undercarriage Components, TCKT5, Bluetooth Sensor for Undercarriage Components, TCKT5 Bluetooth Sensor, Bluetooth Sensor