


UBIQUITI UniFi 6 plus Long Range Access Point User Manual

Home » UBIQUITI » UBIQUITI UniFi 6 plus Long Range Access Point User Manual



6 plus Long Range Access Point User Manual





Contents

- 1 Safety Notices (if appliable)
- 2 Electrical Safety Information (if appliable)
- **3 Radiation Exposure Statement**
- **4 Declaration of Conformity**
- **5 Documents / Resources**
 - 5.1 References
- **6 Related Posts**

Safety Notices (if appliable)

- 1. Read, follow, and keep these instructions.
- 2. Heed all warnings.
- 3. Only use attachments/accessories specified by the manufacturer.

WARNING: Failure to provide proper ventilation may cause fire hazard. Keep at least 20 mm of clearance next to the ventilation holes for adequate airflow.

WARNING: To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

WARNING: Do not use this product in location that can be submerged by water.

WARNING: Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

Electrical Safety Information (if appliable)

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the

- manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment, or pose a fire hazard if the limitations are not followed.
- 2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
- 3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
 - a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
 - b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
 - c. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
 - d. Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
 - e. Protective bonding must be installed in accordance with local national wiring rules and regulations.

Radiation Exposure Statement

- This equipment should be installed and operated with a minimum distance 20 cm between the radiator and your body.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operating Frequency (MHz):	2400-2483.5	5150-5350	5470-5725
Max. RF Output Power:	≤ 20 dBm	≤ 23 dBm	≤ 30 dBm

This device is restricted to indoor use only when operating in the 5150 – 5350 MHz frequency range within all member states. Operation in the 5.8 GHz frequency band is prohibited in non-BFWA member states.

Declaration of Conformity

Hereby, UBIQUITI, declares that this device, U6+LR, is in compliance with the essential requirements and other relevant provisions of Directives 2014/53/EU, 2014/30/EU, 2014/35/EU. The device has software that cannot affect the conformity with the RED, even if the software is changed or replaced. The full text of the EU declaration of conformity and detailed compliance information is available at the following internet address: ui.com/compliance

Ubiquiti International Holding B.V. Ekkersrijt 3102, Son, Netherlands



http://ui.com/qig/u6+lr

Documents / Resources



<u>UBIQUITI UniFi 6 plus Long Range Access Point</u> [pdf] User Manual SWX-U6PLR, SWXU6PLR, u6plr, UniFi 6 plus Long Range Access Point, UniFi 6 plus Long, U niFi 6 Range Access Point, Long Range Access Point, Range Access Point, UniFi 6

References

• Ubiquiti - Compliance

Manuals+,