

# **UBIQUITI UXG-Max Multi WAN Security Gateway Instruction** Manual

Home » UBIQUITI » UBIQUITI UXG-Max Multi WAN Security Gateway Instruction Manual



#### **Contents**

- 1 UBIQUITI UXG-Max Multi WAN Security **Gateway**
- **2 Product Usage Instructions**
- **3 Frequently Asked Questions**
- **4 Safety Notices**
- **5 Documents / Resources** 
  - **5.1 References**
- **6 Related Posts**



**UBIQUITI UXG-Max Multi WAN Security Gateway** 



#### **Product Specifications:**

• Operating Frequency (MHz): 2400-2483.5

• Max. RF Output Power: 20 dBm

#### **Product Information:**

Radiation Exposure Statement – This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. The transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Declaration of Conformity – UBIQUITI declares that the device, UXG-Max, is in compliance with the essential requirements and other relevant provisions of Directives 2014/53/EU, 2014/30/EU, 2014/35/EU. The device's software does not affect conformity with the RED even if changed or replaced.

Manufacturer: Ubiquiti International Holding B.V.

Address: Ekkersrijt 3102, Son, Netherlands

# **Product Usage Instructions**

#### 1. Installation:

• Ensure a minimum distance of 20 cm between the equipment and your body.

#### 2. Operation:

• Avoid co-locating or operating the transmitter with any other antenna or transmitter.

# **Frequently Asked Questions**

# Q: What is the recommended distance between the equipment and the body?

**A:** The equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.


#### Q: Is it safe to operate the transmitter with other antennas or transmitters?

**A:** No, the transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

# **Safety Notices**

# (if applicable)

- 1. Read, follow, and keep these instructions.
- 2. Heed all warnings.
- 3. Only use attachments/accessories specified by the manufacturer.



#### **WARNING:**

- Failure to provide proper ventilation may cause fire hazard. Keep at least 20 mm of clearance next to the ventilation holes for adequate airflow.
- To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
- Do not use this product in location that can be submerged by water.
- Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

#### **Electrical Safety Information (if applicable)**

- 1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment, or pose a fire hazard if the limitations are not followed.
- 2. There are no operator-serviceable parts inside this equipment. Service should be provided only by a qualified service technician.

- 3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
  - Do not substitute the power cord with one that is not the provided approved type.
     Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
  - The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
  - Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
  - Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
  - Protective bonding must be installed in accordance with local national wiring rules and regulations.

#### **Radiation Exposure Statement**

- This equipment should be installed and operated with a minimum distance 20 cm between the radiator and your body.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operating Frequency (MHz): 2400-2483.5

Max. RF Output Power: ≤ 20 dBm

#### **Declaration of Conformity**

Hereby, UBIQUITI, declares that this device, UXG-Max, is in compliance with the essential requirements and other relevant provisions of Directives 2014/53/EU, 2014/30/EU, 2014/35/EU.

The device has software that cannot affect the conformity with the RED, even if the software is changed or replaced.

The full text of the EU declaration of conformity and detailed compliance information is available at the following internet address: <a href="mailto:ui.com/compliance">ui.com/compliance</a>
Ubiquiti International Holding B.V.
Ekkersrijt 3102, Son, Netherlands



# **Documents / Resources**



<u>UBIQUITI UXG-Max Multi WAN Security Gateway</u> [pdf] Instruction Manual UXG-Max, UXG-Max Multi WAN Security Gateway, Multi WAN Security Gateway, WAN Security Gateway, Gateway

#### References

# • User Manual

# Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.