

Ultimaker RFID Reader 1726-A Multiple Machines User Guide


[Home](#) » [Ultimaker](#) » **Ultimaker RFID Reader 1726-A Multiple Machines User Guide** 

Contents


- [1 Ultimaker RFID Reader 1726-A Multiple Machines](#)
- [2 INSTALLATION INSTRUCTIONS](#)
- [3 FCC and ISED Declarations](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Ultimaker

Ultimaker RFID Reader 1726-A Multiple Machines




INSTALLATION INSTRUCTIONS




1726
NFC PCB Antenna


1727
NFC PCB Cable



1726
NFC PCB Antenna

1724
NFC spool holder





FCC and ISED Declarations

This "RFID Reader 1726-A" unit is certified as module as FCC ID: 2AL8M-1726A, IC: 23486-1726A

IMPORTANT NOTE : Compliance Statement (part 15.19) This device complies with part 15 of the FCC Rules and to RSS of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning (Part 15.21)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Information to the User (Part 15.105 (b))

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003


FCC and ISED Radiation Exposure Statement

To comply with FCC and Industry Canada RF radiation exposure limits for general population, the antenna(s) used for this transmitter must be installed such that a minimum separation distance of 20 cm is always maintained between the radiator (antenna) and all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

End-Product Labelling

This device is authorized only for use in the 3D printers of Ultimaker. The end-product must be labelled in visible area with the following: "Contains FCC ID: 2AL8M-1726A, IC: 23486-1726A"

Documents / Resources



[Ultimaker RFID Reader 1726-A Multiple Machines](#) [pdf] User Guide
RFID Reader 1726-A Multiple Machines, RFID Reader 1726-A, Multiple Machines, Machines