



Utopia 360 VR Bluetooth Controller User Manual [TYV-1658]

[Home](#) » [Utopia 360](#) » Utopia 360 VR Bluetooth Controller User Manual [TYV-1658] 

Contents

1 GETTING STARTED

- 1.1 Key Description
- 1.2 Android Instructions:
- 1.3 @ + A Music & Video Mode (One Handed)
- 1.4 @ + B Horizontal Game Mode (Two Handed)
- 1.5 @ + C Vertical Game Mode (One Handed)
- 1.6 @ + D Mouse Mode (One Handed)
 - 1.6.1 Apple IOS Instructions:
- 1.7 @ + A Music & Video Mode
- 1.8 @ + B Game Mode
- 1.9 @ + C VR Mode
- 1.10 Related Posts

GETTING STARTED

(Controller included with ETVRC & EUVRC model only)
Visit www.myretrak.com/vr for a list of recommended apps.

Key Description



1. AAA batteries (not included).
2. Hold down the power button for 3 seconds to turn on the controller repeate to turn off.

3. For the first time, it should start blinking. This means it is from your device and choose Utopia 360 Remote. The LED will stop blinking once paired.

Note: To connect the remote to a new device, the old device should be out of range or the Bluetooth should be turned off on the device. Restart the remote and the remote will go into pairing mode after 5 seconds.

Android Instructions:

1. The switch on the side of the remote should be switched to Android.
2. The device mode can be changed based on the function of the remote change mode, press and hold @ then press any key (A/B/C/D).

@ + A Music & Video Mode (One Handed)

Up/Down = Volume Up/Down
Left/Right = Next Track/Previous Track
C/D = Volume Up/Down
A = Play/Pause
R1 = Back

@ + B Horizontal Game Mode (Two Handed)

Controls app dependent

@ + C Vertical Game Mode (One Handed)

Controls app dependent

@ + D Mouse Mode (One Handed)

360° Rocker = Mouse Movement
C/D = Volume Up/Down
L1 = Select (Screen Press)

Apple IOS Instructions:

1. The switch on the side of the remote should be switched to IOS.
2. The device mode can be changed based on the function of the remote. To change mode, press and hold @ then press any key (A/B/C).

@ + A Music & Video Mode

Down = Next Track (Flick)/Scan Forward (Hold)

A = Play/Pause
B = Home Button
C/D = Volume Up/Down
R1 = Home Button
L1 = Play/Pause

@ + B Game Mode

Controls app dependent

@ + C VR Mode

A/L1 = Mute

B/R1 = Home Button

C/D = Volume Up/Down

3. find compatible apps.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Manuals+.