



velleman VMA402 DC-DC Voltage Step-Up Boost Module User Manual


[Home](#) » [Velleman](#) » velleman VMA402 DC-DC Voltage Step-Up Boost Module User Manual 

Contents

- [1 velleman VMA402 DC-DC Voltage Step-Up Boost Module](#)
- [2 Introduction](#)
- [3 Safety Instructions](#)
- [4 General Guidelines](#)
- [5 What is Arduino®](#)
- [6 Overview](#)
- [7 Pin Layout](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

velleman®

velleman VMA402 DC-DC Voltage Step-Up Boost Module



Introduction

To all residents of the European Union

Important environmental information about this product This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling. This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules.

If in doubt, contact your local waste disposal authorities. Thank you for choosing Velleman®! Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, do not install or use it and contact your dealer.

Safety Instructions

This device can be used by children aged from 8 years and above, and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the device in a safe way and understand the hazards involved. Children shall not play with the device. Cleaning and user maintenance shall not be made by children without supervision. Indoor use only. Keep away from rain, moisture, splashing and dripping liquids.

General Guidelines

- Refer to the Velleman® Service and Quality Warranty on the last pages of this manual.
- Familiarise yourself with the functions of the device before actually using it.
- All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.
- Only use the device for its intended purpose. Using the device in an unauthorised way will void the warranty.
- Damage caused by disregard of certain guidelines in this manual is not covered by the warranty and the dealer will not accept responsibility for any ensuing defects or problems.
- Nor Velleman nv nor its dealers can be held responsible for any damage (extraordinary, incidental or indirect) – of any nature (financial, physical...) arising from the possession, use or failure of this product.
- Due to constant product improvements, the actual product appearance might differ from the shown images.
- Product images are for illustrative purposes only.
- Do not switch the device on immediately after it has been exposed to changes in temperature. Protect the device against damage by leaving it switched off until it has reached room temperature.

- Keep this manual for future reference.

What is Arduino®

Arduino® is an open-source prototyping platform based in easy-to-use hardware and software. Arduino® boards are able to read inputs – light-on sensor, a finger on a button or a Twitter message – and turn it into an output activating of a motor, turning on an LED, publishing something online. You can tell your board what to do by sending a set of instructions to the microcontroller on the board. To do so, you use the Arduino programming language (based on Wiring) and the Arduino® software IDE (based on Processing). Surf to www.arduino.cc and www.arduino.org for more information.

Overview

VMA402

This module converts the microcontroller’s power supply into a higher, adjustable voltage. This is DC-to-DC voltage adjustable module has an input of 3.5~35 V and an output of 5~56V. The output is adjusted via a multi-turn potentiometer. Please ensure that the output voltage higher than the input voltage, so as not to damage the module.

- input voltage 3.5 to 35 VDC
- output voltage 5 to 55 VDC (adjustable)
- max. input current 3 A
- continuous input current 2 A
- chip LM2577
- dimensions 43 x 30 x 12 mm


Pin Layout

- IN+ positive input
- IN- negative input
- OUT+ positive output
- OUT- negative output

More Information

Please refer to the VMA402 product page on www.velleman.eu for more information

Documents / Resources

	velleman VMA402 DC-DC Voltage Step-Up Boost Module [pdf] User Manual VMA402, DC-DC Voltage Step-Up Boost Module, Voltage Step-Up Boost Module, Step-Up Boost Module, Boost Module, VMA402, Module
---	--