



VENTURER VCT9T48 Luna Max 14-Inch Android Tablet with Detachable SpaceMaker Fold-Up Keyboard User Manual

[Home](#) » [VENTURER](#) » VENTURER VCT9T48 Luna Max 14-Inch Android Tablet with Detachable SpaceMaker Fold-Up Keyboard User Manual 

Contents

- [1 VENTURER VCT9T48 Luna Max 14-Inch Android Tablet with Detachable SpaceMaker Fold-Up Keyboard](#)
- [2 Buttons](#)
- [3 Home Screen Icons](#)
- [4 Connections and setup](#)
- [5 Bluetooth](#)
- [6 Basic operation](#)
- [7 Additional information](#)
- [8 Specification](#)
- [9 Important safety instructions](#)
- [10 Limited warranty](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)




VENTURER VCT9T48 Luna Max 14-Inch Android Tablet with Detachable SpaceMaker Fold-Up Keyboard




Charging the battery

Use ONLY the included AC Adapter to charge the battery. The blue indicator blinks on the right of the tablet while the battery is charging and it will stop blinking when it is fully charged.



Battery icon

The battery icon in the upper-right corner shows the battery level or charging status




Prolong the Battery Life

- Here are some tips for how to prolong the life of the battery:
- If you aren't using Wi-Fi, go to Settings ->
- Network & Internet -> Wi-Fi, turn it off.
- Don't leave the Maps or Navigation apps open on the screen when you're not using them.
- Turn down screen brightness and set a shorter screen timeout: Settings -> Display.
- If you don't need it, turn off automatic syncing for all apps: Settings -> Accounts -> Automatically sync data. This means you need to sync manually to collect messages, email, and other recent information, and won't receive notifications when updates occur


Turning your tablet ON

Press and hold the POWER button 4~5 seconds until the logo appears.



Starting for the first time

- When using the tablet for the first time, you will be required to setup the following:
- Select the language, then tap .
- Set the Wi-Fi.
- Tap a network name to see more details or connect to it, and enter a password if necessary.
- When prompted, sign in using the email address and password for your Google Account. If you don't have one yet, go ahead and create one.
- Follow the onscreen instructions to setup the tablet.




Jumping bar

Swipe up to unlock the screen



Getting to know your Tablet



1. **Microphone**

For voice input

2. **Volume +/- button**

3. **Power button**

Press to enter standby/wake up mode, press and hold to switch the unit On/Off.

4. **Charging indicator**

Blue (blinking): Charging

Blue: Fully charged

5. **Docking Pins**

6. **Reset**

Reset the tablet (then press and hold the Power button for 4~5 seconds to turn on the unit).

7. **Headphones jack**

Headphones connection for personal listening.

8. **USB port**

Connects to a USB storage device or a mouse or a wired keyboard

9. **HDMI port**

Connect to a TV or a display device

10. **DC IN jack**

Connects with 12V DC charger.

11. **MicroSD card slot**

Accepts microSD card (up to 128G).

Buttons

Power button

Power the tablet On

Press and hold the Power button for 4~5 seconds to turn on the tablet.

Power the tablet Off

Press and hold the Power button until the "Power off" message displays, then tap the onscreen message and the tablet will be powered off.

Sleep mode

Briefly press the Power button to put the tablet in sleep mode. If you don't operate for some time, the tablet will enter sleep mode automatically.

Tip: You can go to Settings -> Display -> Screen timeout to set the screen timeout.


Wake the tablet from Sleep mode

Press the Power button to wake the tablet from sleep mode. To unlock the tablet, swipe up from the bottom of the screen.


Volume +/- buttons

Press the Volume +/- buttons to increase or decrease the volume.

Tablet docking / undocking



Navigating the Home Screen



Notification & Status Bar

Some indicators informing you about the status of your tablet are shown at the top of the screen. For example, notifications may come from the system, a game, an application such as E-mail, or the music player. When Notifications are available, related icons will appear in the top left corner of the screen. To open the Notification & Status Bar, swipe down from the top of the screen. You can swipe down on the notification panel a second time to expand the details of notifications and access the quick settings icons. Notifications can be deleted by sliding them away to the left or right, or by tapping CLEAR ALL. The quick settings icons allow you to adjust various tablet settings, including WiFi and Bluetooth connections, by tapping the corresponding icon.



Message

Received new message.



Music

The Google Play Music app is running.



Wi-Fi

Has a Wi-Fi Internet connection.



Bluetooth

Bluetooth is on.

Home Screen Icons

• Back

- Tap Back icon to return to the previous screen.
- The Back icon remains on the bottom of the screen at all times, allowing you to navigate back to the previous screen.
- Once you go back to the Home screen, you can't go back any further in your history.

• Home

- Tap Home icon from anywhere on your tablet to return to the Home screen.
- Recent Apps Tap Recent Apps icon to view recently used apps.
- Tap an app to use it again.

- To close an app that may be running in the background, swipe it upward and it will be removed from the Recent Apps list.

- **Volume**


- Tap Volume icon to increase volume.
- Tap Volume icon to decrease volume

Customizing the Home Screen

- From All Apps screen to Home screen: Swipe up from bottom of the Home screen to enter All Apps screen, press & hold an icon slowly to drag it to the location of your choice. This makes it much easier to change your Home screen layout.
- View widgets: Press & hold an empty part of your Home screen, and then tap the Widgets icon. Widgets
- Receive Filesare app information displays that can be placed on your Home screen.
- Move apps or widgets: To relocate an icon or widget to another screen, press and hold the icon or widget and slowly drag it to the edge of the screen to switch it to another screen such as the home screen.
- Delete apps or widgets: Press & hold an icon or widget and slowly drag it, when the “X” icon appears at the top of the screen, drag the icon or widget into it.
- Press & hold an empty part of your Home screen, and the wallpaper icon will display, tap it and choose a wallpaper.

Connections and setup


MicroSD




- Insert the microSD card into the tablet's microSD slot until it clicks.
- To check the storage of the microSD card, go to Settings -> Storage.
- Remove the microSD card by pushing in on the card's edge. The card will pop out and can be removed

Headphones

Headphones can be connected to the tablet's headphones jack.



Connect to a Wi-Fi network




- Go to Settings -> Network & Internet, tap Wi-Fi to open the Wi-Fi screen and then tap Use Wi-Fi to turn it on.
- The device will scan Wi-Fi networks automatically and display the available names.
 - If the device finds a network that it has connected to previously, it will connect to it automatically.
- Tap a network name to connect to it, and enter a password if necessary.
- If your network does not broadcast its SSID, tap + Add network and enter the Network SSID (name) of the network. If necessary, enter security or other network configuration details

VPN (Virtual Private Network)

You can create a virtual private network (VPN) and connect to your private network securely through a public network, such as the internet. You must set a lock screen PIN or password before you can use credential storage. Add VPN network and follow the instructions on the screen

Bluetooth



- You can use Bluetooth to communicate between the unit and other Bluetooth devices, such as wireless headphones or a smartphone
- Go to Settings -> Connected devices -> Connection preferences -> Bluetooth, tap Bluetooth to open the Bluetooth screen and then tap Off to turn it on.
- It will scan automatically and display the available bluetooth devices. Be sure the device you want to connect to is in pairing mode. Follow the device's instructions to enter pairing mode.
- Tap an available bluetooth device name to pair with it and follow the instructions to complete the pairing.

Receive Files

When the Bluetooth share icon is shown in the Notification bar, touch and drag it to open the Notification Shade. Tap the notification and follow the instructions to complete the receiving.

Send Files

- Go to All Apps -> Files.
- Select a file you want to send, touch & hold it until the Notification bar appears. Touch icon and select Bluetooth, then follow the instructions to complete the sending.

Basic operation

Using the Touchscreen

Here are some basic procedures for interacting with the touchscreen.



- Tap

To select an item on the touchscreen, lightly tap it.




- **Drag or Swipe**

While holding an item such as an icon, it can sometimes be moved by dragging it to another area or screen. You may also be able to swipe your finger across a screen or item to navigate or move it.



- **Press & Hold**

In some instances, touching the item and holding your finger on it will present other options or menus.



- **Zoom**

By placing two fingers on the screen, you can slide them apart to “Zoom In”, or pinch them together to “Zoom Out”.

Google Play

In addition to the apps that come preinstalled on your tablet, you can download Android apps and games, music, movies, TV shows and magazines using the

- **Google Play Store app.**

- On the App menu, touch the Google Play Store icon.
- To search for an item from the Google Play Store app, touch the search icon in the upper right corner, and then type a keyword to search.
- Touch an available item to go to its details page. From there you can install or download the item.

- **Google**

A Google Account lets you organize and access your personal information from any computer or mobile device.

- **Add an Account**

You can use multiple Google Accounts and Microsoft Exchange ActiveSync accounts on your tablet. You may also be able to add other kinds of accounts, depending on your apps. To add some accounts, you may need to obtain details from your system administrator about the service to which the account connects. For example, you may need to know the account’s domain or server address.

- Go to Settings -> Accounts -> Add account
- Tap the kind of account to add. And then follow the on-screen instructions.

- **Remove an Account**

To remove a Google account, go to Settings -> Accounts -> Google [account-name], then tap Remove account

- **Settings**

let you configure the tablet, set app options, add accounts, and change other preferences.

- **Networks & Internet**

- **Wi-Fi**

- Enable or disable Wi-Fi, and connect to a wireless network so that you can check email, search the Web, or access social media websites.

- **Data usage**

- To view data usage.

- **Tethering**

- Enable or disable it.

- **VPN**

- You can add, set up, and manage virtual private networks (VPNs).

- **Airplane mode**

- Enable or disable Airplane mode.

- **Advanced**

- Allows you to set Private DNS.

- **Connected devices**

- **USB**

- Set preferences for connected USB device.

- **Pair new device**

- To pair other bluetooth devices.

- **Connection preferences**

- Set preferences for

Bluetooth, Cast, Printing and Chromebook, view the Files received via Bluetooth.

- **Apps & notifications**

- View the Recently opened apps and all apps, and set preferences for apps. To view information or uninstall an app, tap the relevant app.

- **Battery**

- View battery status.

- **Display**

- **Brightness level**

- Allows you to adjust the screen brightness.

- **Night Light**

- Enable or disable Night Light mode.

- **Wallpaper**

- To choose wallpaper.

- **Dark theme**

- Enable or disable Dark theme mode.

- **Screen timeout**

- Allows you to set the amount of time before the screen times out.

- **Advanced**

- Allows you to set Auto-rotate screen, Font size and Display size, screen saver, Lock screen display and HDMI settings.

- Sound

Allows you to set the Media volume, Alarm volume, Notification volume and others.

- Storage

View the total storage space and free space in the device's internal storage. View a list of apps in use and the storage capacity for photo & video, music & audio, games, files, apps and system.

- Privacy

Use the Privacy menu to configure how to help protect your privacy.

- Location

Use to enable or disable the Use Location. Turn on location service, your device determines your approximate location using Wi-Fi and mobile networks.

- Recent Location Requests

Displays applications and services that have recently requested your location.

- Wi-Fi and Bluetooth scanning

Enable or disable the Wi-Fi and Bluetooth scanning.

- Advanced

Set preferences for Emergency Location Service, Google Location Accuracy, Google Location History and Google Location Sharing.

- Security

Use the Security menu to configure how to help secure your device and its data.

- Accounts

- Accounts for Owner

This menu displays the current users you've created.

- Add account

You can add an email account or another type of account.

- Automatically sync data

Let apps refresh data automatically.

- Accessibility

Select preferences for accessibility items.

- Google

Use this menu to manage your Google apps and account settings.

- System

- Languages & input

Set preferences for Languages, Keyboard, and Advanced.

- Gestures

Use to set Jump to camera and Prevent ringing.

- Date & time

Use to set how date, time, time zone and time format will be displayed. If the tablet connected with a Wi-Fi, you can also select Use network-provided time and Use GPS-provided time. Set Use network-provided time to Off and then you can also set your own date and time rather than obtaining the current time from the network.

- Backup

Use to set data backup.

- Advanced

Allows you to set Reset options, Multiple users, and System update.

Preinstalled apps

Your tablet comes with many apps preinstalled to allow you to browse the web, send and receive email, and access entertainment. Spend some time exploring these apps to learn how your tablet can be most useful for you.

Additional information

- Tablet displays network or service error message
- When you are located in places with poor signal, your tablet may lose its Wi-Fi connection. Try moving closer to the Wi-Fi router.
- Touch screen response is slow or incorrect
- If the tablet's touch screen response is incorrect, please try the following:
- Remove any protective film on the touch screen. The protective film may prevent the device recognition input.
- Make sure that your fingers dry and clean before you tap the touch screen.
- Restart the tablet to clear any temporary software bugs.

Tablet is frozen or a serious error appears

- If the tablet is frozen or suspended, you may need to close the app program or reset the tablet.
- If the tablet is frozen or slow to respond, press and hold the power button for approximately 10 seconds to reset the tablet.
- If that doesn't work, insert a paper clip into the RESET hole on the back of the tablet, then press and hold the Power button for 4~5 seconds to turn on the unit.

Tablet gets warm

- When using for a long time, the tablet may be warm. This is normal and will not affect the life or performance of the unit. Tablet can not show video of opposite side during video call
 - The Wi-Fi signal is poor. Please move closer to your wireless router, or disconnect other devices from your wireless router, or increase bandwidth of internet connection.
 - Please check the Wi-Fi setting. It's recommended to use an IEEE 802.11 b/g/n. certified Wi-Fi network.
- Insufficient storage
- We recommend to reserve at least 700MB of free space in internal storage for APP download

Copyright and Trademark Notices

Google, Android, Google Play and other marks are trademarks of Google LLC. The Wi-Fi CERTIFIED Logo is a certification mark of the Wi-Fi Alliance. The Wi-Fi Protected Setup Mark is a mark of the Wi-Fi Alliance. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG Inc. Other trademarks and trade names are those of their respective owners. HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks, registered trademarks, or service marks of HDMI Licensing, LLC in the United States and/or other countries.

About HDMI

High-Definition Multimedia Interface (HDMI) is a highspeed digital interface that can transmit uncompressed high definition video and digital multichannel audio. It delivers high quality picture and sound quality. HDMI is fully backward compatible with DVI. As required by the HDMI standard, connecting to HDMI or DVI products without HDCP (High bandwidth Digital Content Protection) will result in no Video or Audio output.

Specification

Power: DC IN 12V (operate with AC adapter)

Specifications and external appearance are subject to change without notice

Accessory

The following accessories is included.

AC Adapter x1

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

- Changes or modifications not expressly approved by the party responsible for compliance (MLB International Inc., PO Box 1214, Lockport, NY, 14095, Tel: 716-240-0902) could void the user's authority to operate the equipment.
- the AC adapter is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the mains plug from mains completely, the AC adapter should be disconnected from the mains socket outlet completely.
- The socket-outlet shall be installed near the equipment and shall be easily accessible

CAN ICES-3(B) / NMB-3(B)

This device complies with Industry Canada Licenseexempt RSS Standard(s). Operation is subject to the following

two conditions:

- This device may not cause interference, and
- this device must accept any interference, including interference that may cause undesired operation of the device.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body.

Service Information

This product should be serviced only by those specially trained in appropriate servicing techniques. For instructions on how to obtain service

PLEASE READ AND SAVE THIS FOR FUTURE REFERENCE

Important safety instructions

Some of the following information may not apply to your particular product; however, as with any electronic product, precautions should be observed during handling and use.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments / accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

ADDITIONAL SAFETY INFORMATION

- The AC adapter and apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Always leave sufficient space around the product for ventilation. Do not place product in or on a bed, rug, in a bookcase or cabinet that may prevent air flow through vent openings.
- Do not place lighted candles, cigarettes, cigars, etc. on the product.
- Care should be taken so that objects do not fall into the product.
- Do not attempt to disassemble the cabinet. This product does not contain customer serviceable components.
- To prevent the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- Do not play your headset at high volume. Hearing experts warn against extended high-volume play

Limited warranty

VENTURER Electronics Inc.(VENTURER) makes the following limited warranty. This limited warranty extend to the original consumer purchaser and is limited to noncommercial use of the product.

One Year Parts & Labor Warranty

VENTURER products purchased in the United States or Canada are warranted to be free from defects in materials or workmanship for a period of one year from the date of their original retail purchase. If the unit fails to conform to this warranty, we will service the product using new or refurbished parts and products, at VENTURER's sole discretion. During a period of one year from the effective warranty date, VENTURER will provide, when needed, service labor to repair a manufacturing defect at its designated Service Center. To obtain warranty service in the United States or Canada, you must first contact our

Customer Support Center at <https://www.1800customersupport.com/>. The determination of service will be made by VENTURER

PLEASE DO NOT RETURN YOUR UNIT TO VENTURER WITHOUT PRIOR AUTHORIZATION.

New or remanufactured replacements for defective parts or products will be used for repairs by VENTURER at its designated Service Center for one year from the effective warranty date. Such replacement parts or products are warranted for an additional one year from the date of repair or replacement. The Customer will be required to ship the unit to the Service Center indicated at the time Customer Support is contacted to make the necessary repairs. The customer is responsible for all transportation charges to the service facility Packaging and Shipping Instruction When you send the product to the VENTURER service facility you must use the original carton box and packing material or an equivalent as designated by VENTURER. Your Responsibility

- You must retain the original sale receipt to provide proof of purchase.
These warranties are effective only if the product is purchased and operated in the United States or Canada.
- Warranties extend only to defects in material or workmanship and do not extend to any product or parts which have been lost or discarded, or damage to product or parts caused by misuse, accident, improper operation or maintenance, or use in violation of instructions provided with the product, or to product which has been altered or modified without authorization of VENTURER, or to products or parts thereof which have had the serial number removed or changed.

Out of Warranty

In the event your product requires repair after the limited warranty period has expired, please contact our

Customer Support Center at <https://www.1800customersupport.com/>


Important: You are responsible for any transportation, shipping or insurance relative to the return of the product to our Product Returns Center.

All warranties implied by state law, including the implied warranties of merchantability and fitness for a particular purpose, are expressly limited to the duration of the limited warranties set forth above. With the exception of any warranties implied by state law as hereby limited, the foregoing warranty is exclusive and in lieu of all other warranties, guarantees, agreements and similar obligations of the manufacturer or seller with respect to the repair or replacement of any parts. In no event shall VENTURER be liable for consequential or incidental damages. No person, agent, distributor, dealer or company is authorized to change, modify or extend the terms of these warranties in any manner whatsoever. The time within action must be commenced to enforce any obligation of VENTURER arising under the warranty or under any statute, or law of the United States or Canada or any state thereof is hereby limited to one year from the date of purchase. This limitation does not apply to implied warranties arising under state law. This warranty gives you specific legal rights and you may also have other rights, which may vary, from state to state. Some states do not allow limitations on how long an implied warranty lasts, when an action may be brought, or the exclusion or limitation of incidental or consequential damages, so the above provisions may not apply to you.

For more information on other products and services, please visit our website at :

<https://www.1800customersupport.com/> Important: Also keep your “Bill of Sale” as proof of purchase. **FOR SUPPORT AND SERVICE, PLEASE CONTACT US** <https://www.1800customersupport.com/>

Documents / Resources

	<p>VENTURER VCT9T48 Luna Max 14-Inch Android Tablet with Detachable SpaceMaker Fold-Up Keyboard [pdf] User Manual</p> <p>RCT6T48, A2HRCT6T48, VCT9T48 Luna Max 14-Inch Android Tablet with Detachable SpaceMaker Fold-Up Keyboard, VCT9T48, Luna Max 14-Inch Android Tablet with Detachable SpaceMaker Fold-Up Keyboard</p>
---	---

References

- [1800CustomerSupport.com](https://www.1800CustomerSupport.com) | [Get support for your Blackweb and ONN devices](#)
- [1800CustomerSupport.com](https://www.1800CustomerSupport.com) | [Get support for your Blackweb and ONN devices](#)