



## Veris HHX06 Adjustable Current Switch Installation Guide

[Home](#) » [VERIS](#) » Veris HHX06 Adjustable Current Switch Installation Guide 



**Current Monitoring**  
**Current Switches: Adjustable Trip Point, N.C. Output**

## Contents

- 1 HHX06 Adjustable Current Switch
- 2 APPLICATIONS
- 3 SPECIFICATIONS
- 4 WARRANTY
- 5 AGENCY APPROVALS
- 6 MONITORING FAN/PUMP MOTORS FOR POSITIVE PROOF OF FLOW (H606 & H806)
- 7 ORDERING INFORMATION
- 8 Documents / Resources
  - 8.1 References

## HHX06 Adjustable Current Switch

### HX06 SERIES

Detect Belt Loss, Coupling Shear, and Mechanical Failure



Hawkeye x06 Series solid- and split-core current switches provide accurate, reliable, and maintenance-free fan and pump status indication where an NC output is needed.

#### Adjustable trip point

Versatility with four available amperage ranges

#### No tubing needed

Easier to install than differential pressure switches

#### 100% solid-state

No moving parts to fail

#### Status LEDs

Output status LEDs for fast set up

#### Easy placement

Adjustable mounting bracket on the solid-core housing

## Self-gripping iris

Self-gripping iris on split-core housings for easy installation

## APPLICATIONS

- Monitoring fans, pumps, motors, and other electrical loads for proper operation
- Detecting belt loss and motor failure...ideal for fan and pump status
- Verifying lighting circuit loads
- Monitoring critical motors (compressor, fuel, etc.)
- Monitoring industrial process equipment status (OEM)

## SPECIFICATIONS

Sensor Power	5 to 30 Vdc
Insulation Class	600 Vac RMS (UL), 300 Vac RMS (CE)
Temperature Range	-15 to 60 °C (5 to 140 °F)
Humidity Range	10 to 90% RH non-condensing
Hysteresis	10% Typical
Off State Leakage	34 $\mu$ A @ 5 Vdc, 200 $\mu$ A @ 30 Vdc
On State Voltage Drop	1.9 Vdc max@ 0.1 A
Terminal Block Wire Size	H300: 22 to 16 AWG (0.3 to 1.3 mm <sup>2</sup> ) Others: 24 to 14 AWG (0.2 to 2.1 mm <sup>2</sup> )
Terminal Block Torque	H300: 7 in-lbs (0.8 N-m) Others: 3.5 to 4.4 in-lbs (0.4 to 0.5 N-m)


## WARRANTY

Limited Warranty	5 years
------------------	---------

## AGENCY APPROVALS

Agency Approvals	UL 508 open device listing; CE: EN61010-1, CAT III, Pollution Degree 2, basic insulation
------------------	--

## DETECTS BELT LOSS/COUPLING SHEAR!DETECTS BELT LOSS/COUPLING SHEAR!




Now you can easily detect when drive belts slip, break, or pump couplings shear.

In fact, a typical HVAC motor that loses its load has a reduction of current draw of up to 50%. That's why our sensors are the industry standard for status.

**Note:** Do not use the LED status indicators as evidence of applied voltage. (a) VFD systems generate fields that can disrupt electrical devices. Ensure that these fields are minimized and are not affecting the sensor.


## H606

### Dimensional Drawing




## H806

### Dimensional Drawing



**H706**  
**Dimensional Drawing**




\* Terminal block may extend up to 1/8" over the height dimensions shown.

\*\* Slide switch may extend up to 1/4" over the height dimensions shown.


## MONITORING FAN/PUMP MOTORS FOR POSITIVE PROOF OF FLOW (H606 & H806)

### Wiring Diagram



## MONITORING FAN/PUMP MOTORS FOR POSITIVE PROOF OF FLOW (H706)

### Wiring Diagram



## ORDERING INFORMATION

MODEL	AMPERAGE RANGE	STATUS OUTPUT (MAX.)	MIN. TRIP POINT	HOUSING	STATUS LED	UL	CE
H606	1.25 to 50 A	N.C. 0.1 A @ 30 V dc	1.25 A or less	Split-Core	•	•	•
I-1706	1 to 135 A		1.0 A or less	Solid-Core	•	•	•
I-1806	0.75 to 50 A		0.75 A or less	Solid-Core	•	•	•

1. Listed for use on 75°C insulated conductors.



HQ0001756.H 0324

800.354.8556

+1 503.598.4564

[sales@veris.com](mailto:sales@veris.com)

[intl@veris.com](mailto:intl@veris.com)

[veris.com](http://veris.com)



## Documents / Resources

A small image of the Veris HHX06 Adjustable Current Switch, showing its compact, rectangular design with a red status LED and a black adjustment knob.	<p><a href="#">Veris HHX06 Adjustable Current Switch</a> [pdf] Installation Guide</p> <p>HHX06 Adjustable Current Switch, HHX06, Adjustable Current Switch, Current Switch, Switch</p>
--	--

## References

- [User Manual](#)

### [Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.