



Vision Security Power Switch ZL7434EU-5 Manual

[Home](#) » [Vision Security](#) » Vision Security Power Switch ZL7434EU-5 Manual 



Contents

- 1 Vision
- 2 Power Switch
 - 2.1 SKU: ZL7434EU-5
 - 2.2 Quickstart
 - 2.3 Important safety information
 - 2.4 What is Z-Wave?
 - 2.5 Product Description
 - 2.6 Prepare for Installation / Reset
 - 2.6.1 Reset to factory default
 - 2.6.2 Safety Warning for Mains Powered Devices
 - 2.7 Inclusion/Exclusion
 - 2.7.1 Inclusion
 - 2.7.2 Exclusion
 - 2.8 Quick trouble shooting
 - 2.9 Association – one device controls an other device
 - 2.9.1 Association Groups:
 - 2.10 Configuration Parameters
 - 2.10.1 Parameter 1: Light type
 - 2.10.2 Parameter 2: Switch button type
 - 2.11 Technical Data
 - 2.12 Explanation of Z-Wave specific terms
 - 2.13 Related Posts

Vision

Power Switch

SKU: ZL7434EU-5



Quickstart

This is a

On/Off Power Switch

for

CEPT (Europe).

To run this device please connect it to your mains power supply.

To add this device to your network execute the following action:

Put the Z-Wave Interface Controller into inclusion mode, and following its instruction to add the ZL 7434-5 to your controller. To get in the inclusion mode, the distance between module and controller is suggested to be in one meter. Press 3 times program switch within 2 seconds or turn on the wall switch 3 times within 2 seconds (or press toggle switch 3 times) to be included.

Please refer to the

[Manufacturers Manual](#) for more information.

Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law.

The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material.

Use this equipment only for its intended purpose. Follow the disposal instructions.

Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.



This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc. please refer to www.z-wave.info.

Product Description

This module provides On/Off control for the appliance that is attached to this module by Z-Wave. It also can control two appliances independently. When the device is secure included into Z-Wave network, Z-Wave communication will be encrypted.* Size: 3.95 x 5.0 x 1.9 cm* Operating Range: Up to 100 feet line of sight* Operating Temp.: -10C~ 60C (14F~140F)* Operating Voltage: 90 VAC~240 VAC, 50/60 Hz* Max. Loading: 15A

Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

Power off first, press Program Switch and power on, ZL7434-5 will send the Device Reset Locally Notification command and reset to the factory default. (Remark: This is to be used only in the case of primary controller being

inoperable or otherwise unavailable.)

Safety Warning for Mains Powered Devices

ATTENTION: only authorized technicians under consideration of the country-specific installation guidelines/norms may do works with mains power. Prior to the assembly of the product, the voltage network has to be switched off and ensured against re-switching.

Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Inclusion

Put the Z-Wave Interface Controller into inclusion mode, and following its instruction to add the ZL 7434-5 to your controller. To get in the inclusion mode, the distance between module and controller is suggested to be in one meter. Press 3 times program switch within 2 seconds or turn on the wall switch 3 times within 2 seconds (or press toggle switch 3 times) to be included.

Exclusion

Put the Z-Wave Interface Controller into exclusion mode, and following its instruction to delete the ZL 7434-5 from your controller. Press 3 times program switch within 2 seconds or turn on the wall switch 3 times within 2 seconds (or press toggle switch 3 times) to be excluded.

Quick trouble shooting

Here are a few hints for network installation if things don't work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Don't poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Association – one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command, typically a 'Basic Set' Command.

Association Groups:

Group Number	Maximum Nodes	Description
--------------	---------------	-------------

1	5	Z-Wave Plus Lifeline
---	---	----------------------

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

IMPORTANT: Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a parameter to 200 it may be needed to set a value of 200 minus 256 = minus 56. In case of a two byte value the same logic applies: Values greater than 32768 may needed to be given as negative values too.

Parameter 1: Light type

To select the light type, 1 Wall Switch, 2 Wall Switches or wall switch with Light Indicator.

Size: 1 Byte, Default Value: 2

SettingDescription

1	1 or 2 Wall Switches
2	1 Wall Switch with Light Indicator(factory default).

Parameter 2: Switch button type

If customer chose 1 or 2 wall switches, then they have also select switch button type.

Size: 1 Byte, Default Value: 1

SettingDescription

1	With common on/off type switch button used(factory default).
2	With momentary type switch button used.

Technical Data

Hardware Platform	ZM5202
Device Type	On/Off Power Switch
Network Operation	Always On Slave
Firmware Version	02
Z-Wave Version	6.51.06
Certification ID	ZC10-15120003
Z-Wave Product Id	0x0109.0x200C.0x0C06
Frequency	XXfrequency
Maximum transmission power	XXantenna

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network.
Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network.
Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announce that it is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.