



# WatchGuard ML3AE8 Firebox M200 Network Security User Guide

[Home](#) » [Watchguard](#) » WatchGuard ML3AE8 Firebox M200 Network Security User Guide 

## Contents

- [1 WatchGuard ML3AE8 Firebox M200 Network Security](#)
- [2 Activate Your Firebox](#)
- [3 RapidDeploy QuickStart Setup](#)
- [4 Classic Activation Setup](#)
- [5 Next Steps](#)
- [6 About the Device Status Lights](#)
- [7 Reset the Firebox to Factory-Default Settings](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)



## WatchGuard ML3AE8 Firebox M200 Network Security




## Activate Your Firebox

1. Go to [www.watchguard.com/activate](http://www.watchguard.com/activate)
2. Log in to your WatchGuard account, or create a new account\*.  
\*If you create a new account, return to [www.watchguard.com/activate](http://www.watchguard.com/activate) after you finish the account creation process.
3. Type the serial number for your device.
4. During activation, select your setup method:
  - RapidDeploy QuickStart – Automatically download and apply a QuickStart configuration file to your device, pre-configured with security settings recommended by WatchGuard.
  - Classic Activation – Use the Web Setup Wizard to create a basic configuration file for your device.
5. Use the setup directions in this guide that match the method you selected.

## RapidDeploy QuickStart Setup

### Connect Your Firebox and Power it On

Make sure the computers on your network are configured to use DHCP. When you install your Firebox, it will assign an IP address on the [10.0.1.0/24](http://10.0.1.0/24) network.



### Connect to the Web UI

- A. Go to <https://10.0.1.1:8080>
- B. You can safely ignore any certificate warnings you see because the device uses a self-signed certificate.
- C. Log in with the user account admin and the Admin (readwrite) passphrase you set during activation.


Your device has a basic configuration:

- Allows outbound TCP, UDP, and ping traffic
- Blocks all unrequested traffic from the external network
- Includes optimized security settings
- Uses licensed security services to protect the trusted and optional networks

## Classic Activation Setup

### Connect Your Firebox and Power it On

Make sure your computer is configured to use DHCP. When you connect to the Firebox, it will assign an IP address on the [10.0.1.0/24](http://10.0.1.0/24) network.



## Connect to the Web UI

- A. Go to <https://10.0.1.1:8080>
- B. You can safely ignore certificate warnings, because the device uses a self-signed certificate.
- C. Log in with the user name admin and the passphrase readwrite.
- D. Follow the directions in the Web Setup Wizard to create a basic configuration file for a new device. Click More Information if you have questions.
- E. When the Wizard completes, log in to the Web UI with the admin user account and the Admin (readwrite) passphrase you set during the Wizard.
- F. Install the Firebox in your network.

Your device has a basic configuration:

- Allows outbound FTP, Ping, DNS, TCP, and UDP connections
- Blocks all unrequested traffic from the external network
- Inspects outgoing FTP, HTTP, and HTTPS traffic
- Uses licensed security services to protect the trusted and optional networks

## Next Steps

Congratulations! You have finished basic setup of your Firebox. You can use the Web UI to view and edit your configuration and to manage and monitor your Firebox. Or, you can download and install WatchGuard System Manager (WSM) and use Policy Manager and the WSM suite of management and monitoring tools. Here are some recommendations to help you get started:

Verify your Internet connectivity

- With your Firebox installed in your network, make sure that your users can successfully browse the Internet.

## Get the latest software

To upgrade the Firebox OS:

1. Log in to Fireware Web UI.
2. Select System > Upgrade OS.

To get the latest version of WSM, WatchGuard Dimension, VPN clients, and other software for your Firebox:

1. Go to [www.watchguard.com/support](http://www.watchguard.com/support) and click Download Software.
2. Find the software downloads page for your Firebox model and select the software you want to install.

### Explore the features and functions of your Firebox

Browse the Web UI or the tools in WatchGuard System Manager and click Help on any page or dialog box to learn more about the management, monitoring, and security features of your Firebox.

## About the Device Status Lights

### RJ45 interfaces

Interfaces 0 – 7 are RJ45 Ethernet interfaces that support link speeds of 10, 100, or 1000 Mbps. Each RJ45 interface has a pair of indicators. The right indicator shows the interface connection status. The left indicator shows interface activity.

Indicator	Indicator color	Interface Status
Connection (right)	Yellow	Link at 1000 Mbps
	Green	Link at 100 Mbps
	Not lit	Link at 10 Mbps, or no link
Activity (left)	Yellow, blinks	Power on, network activity
	Not lit	Power off, no connections

- Storage – When there is activity on the SD card, the storage indicator is yellow.
- Arm/Disarm – When the device is armed and ready to pass traffic, this indicator is green. When the device is powered on, but not ready to pass traffic, this indicator is red.
- Power– The power indicator on the left front of the device is green when the device is powered on.


## Reset the Firebox to Factory-Default Settings

If you ever need to, you can restore your Firebox to its factory-default settings. For example, if you do not know your administrator account passphrase or you want to start over with RapidDeploy QuickStart, you can reset your device. Make sure you back up your device configuration before you reset your device in case you want to restore it in the future.

For more information, see the Hardware Guide for your Firebox, available at:

[www.watchguard.com/help/documentation/hardware.asp](http://www.watchguard.com/help/documentation/hardware.asp)

## Documents / Resources

	<a href="#">WatchGuard ML3AE8 Firebox M200 Network Security</a> [pdf] User Guide ML3AE8 Firebox M200 Network Security, Firebox M300 Network Security
---	---