

WINDFLYER LITTLE TEDDI ALARM CLOCK



## Windflyer Little Teddi Alarm Clock User Guide

[Home](#) » [Windflyer](#) » Windflyer Little Teddi Alarm Clock User Guide 

### Contents

- 1 Windflyer Little Teddi Alarm Clock
- 2 IN THE BOX
- 3 SETUP AND MAINTENANCE
- 4 CONTROL PANEL
- 5 GOOD HABITS WITH LITTLE TEDDI
- 6 SLEEP TRAINER – SLEEP MODE
- 7 SLEEP SOUND MACHINE
- 8 NIGHT LIGHT
- 9 NAP TIMER
- 10 LOCK MODE
- 11 FREQUENTLY ASKED QUESTIONS
- 12 VIDEO – PRODUCT OVERVIEW
- 13 References
- 14 Related Posts

*windflyer*

**Windflyer Little Teddi Alarm Clock**




### **One-Year Limited Warranty**

- After-sales mailbox: [support@windflyershop.com](mailto:support@windflyershop.com)

### **MEET LITTLE TEDDI**


- SNOOZE & LIGHT RING(+/-)
- FACIAL EXPRESSION
- LIGHT RING
- DISPLAY
- CONTROL PANEL



**Fig. 1 LITTLE TEDDI**



## IN THE BOX



- LITTLE TEDDI
- AC ADAPTER
- CR2032 BATTERY (Pre-Installed)


## WARNING:

- Not suitable for children under 36 months
- **Choking hazard** – small parts

- Parental supervision required



## SETUP AND MAINTENANCE



**Fig. 2 AC Aadapter**

- **SETUP**

Attach the AC adapter jack to the LITTLE TEDDI's base and plug into a 100V-240V household outlet (Fig. 2).

- **INSTALL BATTERY**

LITTLE TEDDI comes with a pre-installed CR2032 battery. Pull the clear tab to remove the insulation sticker. Removing the insulation sticker will allow LITTLE TEDDI's memory settings to be saved.

- **STORE**

LITTLE TEDDI should be left on display, or stored in its box or a cool, dry place.







- **CLEAN**

Wipe off dust with a soft, damp cloth. Do not use liquids or abrasive cleaners.

- **USER TIP**


When LITTLE TEDDI is not plugged into an outlet, the included CR2032 battery preserves basic memory functions.

## DISPLAY

 ALARM	 SOUND+LIGHT	 SOUND
 LIGHT	 LOCK	 COUNTDOWN

## CONTROL PANEL

To program all settings, use the control panel on the bottom of LITTLE TEDDI (Fig. 3).



**Fig. 3** Control Panel

## TIME

When LITTLE TEDDI is first plugged in, the display will read “12:00 AM”.

### STEPS:



#### 1. Press SET

The word “SETTING” will appear on the display.

#### 2. Press TIME

The time will flash. Use (+/-) to adjust (Hold for rapid adjustment).



**NOTE:** Press TIME again and use (+/-) to toggle between 12/24H mode (AM/PM will appear under 12H mode).

#### 3. Press SET

To exit Time mode or,

#### 4. Press TIME

To loop back to the beginning.

**USER TIP** Single press  to lock and prevent accidental change of settings. Press and hold  for 2 seconds to unlock the control panel.

## ALARM

### STEPS:



#### 1. Press SET

The word "SETTING" will appear on the display.

#### 2. Press ALARM

The word "ALARM" will appear and alarm time will flash . Use(+/-) to adjust the alarm time (Hold for fast adjustment).

#### 3. Press ALARM

The alarm icon will appear. Use (+/-) to adjust the alarm volume (level 1 to 5) .

#### 4. Press SET

To exit Alarm mode or,

#### 5. Press ALARM


To loop back to the beginning.

Single press ALARM to toggle the alarm on or off. From off to on, the set alarm time will flash for 2 seconds, and alarm icon will stay on display. The alarm sound is set and can NOT be changed.

When the alarm sounds, the alarm's facial expression will display. The alarm will last 8 minutes and stop, if not interrupted by any action of the user (Fig. 4).



**Fig. 4 Alarm Goes Off**



**Fig. 5 Snooze Active**

- **SNOOZE**

Tap SNOOZE once to mute the alarm for 9 minutes. After 9 minutes, the alarm will sound again and you can repeat the process multiple times (Fig. 5).

- **TURN OFF**

To cancel the snooze at any time or turn off the alarm while it is sounding, press and hold SNOOZE for 2 seconds or press any button except(+/-) on the bottom.

## **GOOD HABITS WITH LITTLE TEDDI**

- When it is time to sleep, LITTLE TEDDI will close its eyes so your child will go to bed. When it is time to wake, LITTLE TEDDI will greet your child with a smile and the light ring will turn GREEN – green means go!
- **LITTLE TEDDI** also teaches your child to wait for good things to come. You have the option to turn on the “PLAY” setting, during which period (10, 20 30 ... 90 min before the wake time you set) LITTLE TEDDI will glow PALE GREEN, so that your child will wake/play quietly in his or her room until the light turns GREEN – again, green means go!
- **NOTE:** You can also turn off the PLAY setting.
- **EXAMPLE (Fig.6)** LITTLE TEDDI's wake time is set to 7:00 AM and the play period is 10mins, the light ring will glow pale green at 6:50 AM and turn green at 7:00 AM.



Sleep Time



Play Time



Wake Time

**Fig. 6 Sleep Trainer Example**

## **SLEEP TRAINER – SLEEP MODE**

### **STEPS:**



#### **1. Press SET**

The word “SETTING” will appear on the display.


#### **2. Press SLEEP**

LITTLE TEDDI will show a sleeping expression and time will flash on display. Use (+/-) to adjust the sleep time (Press and hold for rapid adjustment) .

#### **3. Press SLEEP**

Use (+/-) to turn on sound and light mode, sound-only mode, light-only mode, or sleeping expression-only mode (Fig. 7) .





**Fig. 7 Four Sleep Mode**

**4. Press SET**

To exit the Sleep mode or,

**5. Press SLEEP**

To loop back to the beginning.

**SLEEP TRAINER – SLEEP MODE**

To toggle the sleep mode on or off, press SLEEP. From off to on, the time and sleep icon will blink for 2 seconds, then the sleep icon will stay on the display.

- **USER TIP** The sleep sound is set in SLEEP SOUND OPTIONS (Page 12), and the sleep light is set in NIGHT LIGHT OPTIONS (Page 13).

**WHEN THE SLEEP MODE IS ACTIVATED:**

1. Press LIGHT repeatedly to adjust the light countdown time ranging from 90 minutes to 15 minutes or Stay Lit (ALL) or OFF.
2. Press SNOOZE repeatedly to adjust the light brightness (level 1 to 4).
3. Press SOUND repeatedly to adjust the ringtone countdown time ranging from 90 minutes to 15 minutes or Keep Sounding (ALL) or OFF.
4. Use (+/-) to adjust the ringtone volume (level 1 to 5).

**STEPS:**



**1. Press SET**

The word “SETTING” will appear on the display.

**2. Press WAKE**

The word “WAKE” will appear and wake time will flash on display. LITTLE TEDDI will show a smiling expression and the light will glow green. Use (+/-) to adjust the wake time(Press and hold for rapid adjustment). The “WAKE” will automatically turn off after 2H if not interrupted by any action of the user.

**3. Press WAKE**

Press WAKE again to enter the Play Setting. LITTLE TEDDI will show a playful expression and the light will glow pale green. Use (+/-) to adjust play time ranging from 90 minutes to 10 minutes or OFF.

**4. Press SET**

To exit the Wake mode or,

**5. Press WAKE**

To loop back to the beginning.

From off to on, the wake icon and set wake time will blink for 2 seconds, and the wake icon will stay on the display.

**USER TIP** You can press SNOOZE and hold on 2s to turn off the white light/wake when the olav/wake mode is activated.

## **SLEEP SOUND MACHINE**

### **SLEEP SOUND OPTIONS**

**1. Press SET**

The word “SETTING” will appear on the display.

**2. Press SOUND**

The word “SOUND” will appear below the line and the first sound option S 01 will flash. Use (+/-) to choose among the following 4 options: S 01 music box, S 02 lullaby, S 03 ocean wave, S 04 white noise.

**3. Press SET**

To exit the Sleep Sound setting.

## **SOUND TIMER**

- Press SOUND repeatedly to adjust the duration of sounds. Options available are ALL (continuous), OFF, 15/30/60/90 minutes. The setting will automatically be saved after 2 seconds and exit.
- Use (+/-) to adjust the sound volume while it is sounding (level 1 to 5).

**USER TIP** When an alarm is sounding, it will override the sound machine.

## **NIGHT LIGHT**

### **NIGHT LIGHT OPTIONS**

#### **1. Press SET**

The word "SETTING" will appear on the display.

#### **2. Press LIGHT**

The word "LIGHT" will appear and "L 01" will flash on display. The night light will glow red color. Use (+/-) to choose the light color (L 01 is red color; L02 is blue; L03 is purple; L04 is yellow; L05 is loop color).

#### **3. Press SET**

To exit the Night Light Option mode.

## **LIGHT TIMER**

- Press LIGHT repeatedly to adjust the duration of the night light. Options available are ALL (continuous), OFF, 15/30/60/90 minutes. The setting will automatically be saved after 2 seconds and exit.
- Press SNOOZE repeatedly to adjust the night light brightness when it lights up (level 1 to 4).

**USER TIP** For optimal sleep quality, we recommend using the red night light at bedtime!

## **NAP TIMER**

### **NAP OPTIONS**

#### **1. Press SET**


The word "SETTING" will appear on the display.

#### **2. Press NAP**

Use (+/-) to turn on sound and light mode, sound only mode, or light only mode (Fig. 8). NOTE: The nap sound is alarm sound and the light color is green – both are set and can NOT be changed.

#### **3. Press SET**

The exit Nap setting.



**Fig. 8 Three Nap Mode**

## NAP TIMER

- Press NAP repeatedly to adjust the duration of nap timer. Options available are OFF, 15/30/60/90/180 minutes. The setting will automatically be saved after 2 seconds and exit.


**NOTE:** When the nap is finished, LITTLE TEDDI will wake up and the alarm sound will play (if you choose sound mode) and/or green light will glow (if you choose light mode). To turn off the nap timer alarm or light, press and hold SNOOZE for 2 seconds or press NAP if it's in unlocked mode.

## BRIGHTNESS CONTROL

- There are 5 brightness levels for LCD Display and Facial Expression. To adjust the brightness, press TIME repeatedly to scroll through the options.
- There are 4 brightness levels for light ring. When it lights up, press SNOOZE repeatedly to scroll through the options.


## REPLACE BATTERY

- Using the included small torx screwdriver, remove the screw from the battery cartridge (Fig. 9). Insert the battery positive side up and fully slide the cartridge back into the compartment. Put screw into place to secure battery compartment.



**Fig. 9 Battery Compartment**

## LOCK MODE

Single press  to lock and prevent accidental change of settings. The following features still function in lock mode.

- Press SNOOZE once to snooze for 9 minutes.

- Press and hold SNOOZE for 2 seconds, or press any button except {+/-} on the bottom to turn off the alarm sound when the alarm is sounding.
- Press and hold SNOOZE for 2 seconds to turn off the nap timer alarm or light when the nap timer is finished.
- Press SNOOZE repeatedly to adjust the night light brightness when it lights up (level 1 to 4).
- Press SNOOZE and hold on 2s to turn off the white light/wake when the play/wake mode is activated.
- Press TIME repeatedly to adjust the brightness of LCD display and facial expression (level 1 to 5).

Please scan these QR codes below to watch the videos about how to finish setting .



**TIME SETTING**

[Video](#)



**ALARM SETTING**

[Video](#)



**SLEEP SETTING**

[Video](#)



**PLAY-WAKE**

[Video](#)



**NIGHT LIGHT**

[Video](#)



**NAP TIMER**

[Video](#)

## FREQUENTLY ASKED QUESTIONS

What are some of the features of the Windflyer Little Teddi Alarm Clock?

The Windflyer Little Teddi Alarm Clock has night lights, sleep sounds, a sleep trainer function, and a regular alarm.

How does the sleep trainer function work on the Windflyer Little Teddi Alarm Clock?

The Windflyer Little Teddi Alarm Clock uses facial expressions and colored lights to signal to kids when it's okay to wake up in the Windflyer Little Teddi Alarm Clock.

What kind of facial expressions does the Windflyer Little Teddi Alarm Clock use?

The Windflyer Little Teddi Alarm Clock shows a smiling face when it's okay to wake up and a sleepy face when it's time to sleep in the Windflyer Little Teddi Alarm Clock.

What colors does the night light use for the sleep trainer function on the Windflyer Little Teddi Alarm Clock?

Green typically means it's okay to wake up on the Windflyer Little Teddi Alarm Clock, while other colors might signal sleep time.

What kind of sleep sounds does the Windflyer Little Teddi Alarm Clock play?

The Windflyer Little Teddi Alarm Clock typically offers sounds like music box melodies, lullabies, ocean waves, and white noise.

How do I set the time on the Windflyer Little Teddi Alarm Clock?

The instructions for setting the time on the Windflyer Little Teddi Alarm Clock can be found in the user manual, but it typically involves buttons on the clock.

Does the Windflyer Little Teddi Alarm Clock require batteries?

Windflyer Little Teddi Alarm Clock usually operates on AA batteries.

Does the Windflyer Little Teddi Alarm Clock allow for different wake-up faces besides just smiling?

It's unlikely, as the smiling face typically signifies it's okay to wake up on the Windflyer Little Teddi Alarm Clock.

Is the Windflyer Little Teddi Alarm Clock made from safe materials for children?

Look for information on the product description or packaging to confirm the Windflyer Little Teddi Alarm Clock is made from child-safe, non-toxic materials.

How long does a clock alarm usually ring before it turns off?

Really depends on the alarm. I have seen them turn off after 1 minute, after 10 minutes, after an hour, and go until you shut them off.

## VIDEO – PRODUCT OVERVIEW



[Download the PDF link: Windflyer Little Teddi Alarm Clock-User-Guide.mp4](#)

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.