


windflyer

LITTLE TEDDI

Children's Sleep Trainer, Sound Machine,
Alarm Clock, Nap and Night Light Timer

SETUP GUIDE



One-Year Limited Warranty

After-sales mailbox: support@windflyershop.com

MEET LITTLE TEDDI




Fig. 1 LITTLE TEDDI



ALARM



SLEEP




PLAY




WAKE

IN THE BOX



LITTLE TEDDI



AC ADAPTER



CR2032 BATTERY
(Pre-Installed)

WARNING:

- Not suitable for children under 36 months
- Choking hazard - small parts
- Parental supervision required



TORX SCREWDRIVER



SETUP AND MAINTENANCE

SET UP

Attach the AC adapter jack to the LITTLE TEDDI's base and plug into a 100V-240V household outlet (Fig. 2).




Fig. 2 AC Aadapter

INSTALL BATTERY

LITTLE TEDDI comes with a pre-installed CR2032 battery. Pull the clear tab to remove the insulation sticker. Removing the insulation sticker will allow LITTLE TEDDI's memory settings to be saved.

STORE

LITTLE TEDDI should be left on display, or stored in its box or a cool, dry place.







CLEAN

Wipe off dust with a soft, damp cloth. Do not use liquids or abrasive cleaners.

USER TIP

When LITTLE TEDDI is not plugged into an outlet, the included CR2032 battery preserves basic memory functions.

DISPLAY

 ALARM	 SOUND+LIGHT	 SOUND
 LIGHT	 LOCK	 COUNTDOWN

CONTROL PANEL

To program all settings, use the control panel on the bottom of LITTLE TEDDI (Fig. 3).




Fig. 3 Control Panel

When LITTLE TEDDI is first plugged in, the display will read “12:00 AM”.

STEPS:

SET

⋮

TIME
(+/-)

⋮

SET

1. Press SET

The word “**SETTING**” will appear on the display.

2. Press TIME

The time will flash. Use (+/-) to adjust (Hold for rapid adjustment).

NOTE: Press **TIME** again and use (+/-) to toggle between 12/24H mode (**AM/PM** will appear under 12H mode).



3. Press SET

To exit Time mode or,

4. Press TIME

To loop back to the beginning.

USER TIP

Single press  to lock and prevent accidental change of settings. Press and hold  for 2 seconds to unlock the control panel.

STEPS:



1. Press **SET**

The word “**SETTING**” will appear on the display.

2. Press **ALARM**

The word “**ALARM**” will appear and alarm time will flash.
Use **(+/-)** to adjust the alarm time (Hold for fast adjustment).

3. Press **ALARM**

The alarm icon will appear. Use **(+/-)** to adjust the alarm volume (level 1 to 5).

4. Press **SET**

To exit Alarm mode or,

5. Press **ALARM**

To loop back to the beginning.

Single press **ALARM** to toggle the alarm on or off. From off to on, the set alarm time will flash for 2 seconds, and alarm icon will stay on display. The alarm sound is set and can NOT be changed.

ALARM

When the alarm sounds, the alarm facial expression will display. Alarm will last 8 minutes and stop, if not interrupted by any action of the user (Fig. 4).

SNOOZE

Tap **SNOOZE** once to mute the alarm for 9 minutes. After 9 minutes, alarm will sound again and you can repeat the process multiple times (Fig. 5).

TURN OFF

To cancel the snooze at any time or turn off the alarm while it is sounding, press and hold **SNOOZE** for 2 seconds or press any button except (+/-) on the bottom.



Fig. 4 Alarm Goes Off




Fig. 5 Snooze Active

GOOD HABITS WITH LITTLE TEDDI

When it is time to sleep, LITTLE TEDDI will close its eyes so your child will go to bed. When it is time to wake, LITTLE TEDDI will greet your child with a smile and the light ring will turn **GREEN** – green means go!

LITTLE TEDDI also teaches your child to wait for good things to come. You have the option to turn on the “**PLAY**” setting, during which period (10, 20 30...90 min before the wake time you set) LITTLE TEDDI will glow **PALE GREEN**, so that your child will wake/play quietly in his or her room until the light turns **GREEN** – again, green means go!

NOTE: You can also turn off **PLAY** setting.

EXAMPLE (Fig.6)

LITTLE TEDDI's wake time is set to 7:00AM and play period is 10mins, the light ring will glow pale green at 6:50AM and turn green at 7:00AM.



Sleep Time



Play Time



Wake Time

Fig. 6 Sleep Trainer Example

SLEEP TRAINER - SLEEP MODE

STEPS:

1. Press SET

The word “SETTING” will appear on the display.

2. Press SLEEP

LITTLE TEDDI will show a sleeping expression and time will flash on display. Use (+|-) to adjust the sleep time (Press and hold for rapid adjustment).

3. Press SLEEP

Use (+|-) to turn on sound and light mode, sound only mode, light only mode, or sleeping expression only mode (Fig. 7).




Fig. 7 Four Sleep Mode

4. Press SET

To exit the Sleep mode or,

5. Press SLEEP

To loop back to the beginning.

SLEEP TRAINER - SLEEP MODE

To toggle the sleep mode on or off, press **SLEEP**. From off to on, time and sleep icon will blink for 2 seconds, then the sleep icon will stay on the display.

USER TIP

The sleep sound is set in **SLEEP SOUND OPTIONS** (Page 12), and the sleep light is set in **NIGHT LIGHT OPTIONS** (Page 13).

WHEN THE SLEEP MODE IS ACTIVATED:

1. Press **LIGHT** repeatedly to adjust the light countdown time ranging from 90 minutes to 15 minutes or Stay Lit (ALL) or OFF.
2. Press **SNOOZE** repeatedly to adjust the light brightness (level 1 to 4).
3. Press **SOUND** repeatedly to adjust the ringtone countdown time ranging from 90 minutes to 15 minutes or Keep Sounding (ALL) or OFF.
4. Use **(+|-)** to adjust the ringtone volume (level 1 to 5).

SLEEP TRAINER - WAKE MODE

STEPS:

SET



WAKE
(+|-)



WAKE
(+|-)



SET

1. Press SET

The word “**SETTING**” will appear on the display.

2. Press WAKE

The word “**WAKE**” will appear and wake time will flash on display. LITTLE TEDDI will show a smiling expression and the light will glow green. Use **(+|-)** to adjust the wake time(Press and hold for rapid adjustment). The “**WAKE**” will automatically turn off after 2H if not interrupted by any action of the user.

3. Press WAKE

Press **WAKE** again to enter the Play Setting. LITTLE TEDDI will show a playful expression and the light will glow pale green. Use **(+|-)** to adjust play time ranging from 90 minutes to 10 minutes or OFF.

4. Press SET

To exit the Wake mode or,

5. Press WAKE

To loop back to the beginning.

From off to on, the wake icon and set wake time will blink for 2 seconds, and the wake icon will stay on the display.

USER TIP

You can press **SNOOZE** and hold on 2s to turn off the white light/wake when the play/wake mode is activated.

SLEEP SOUND MACHINE

SLEEP SOUND OPTIONS

1. Press **SET**

The word "**SETTING**" will appear on the display.

2. Press **SOUND**

The word "**SOUND**" will appear below the line and first sound option S 01 will flash. Use (+/-) to choose among the follow 4 options: S 01 music box, S 02 lullaby, S 03 ocean wave, S 04 white noise.

3. Press **SET**

To exit Sleep Sound setting.

SOUND TIMER

Press **SOUND** repeatedly to adjust the duration of sounds. Options available are ALL (continuous), OFF, 15/30/60/90 minutes. The setting will automatically be saved after 2 seconds and exit.

Use **(+|-)** to adjust the sound volume while it is sounding (level 1 to 5).

USER TIP

When an alarm is sounding, it will override the sound machine.

NIGHT LIGHT OPTIONS

1. Press **SET**

The word “**SETTING**” will appear on the display.

2. Press **LIGHT**

The word “**LIGHT**” will appear and “**L 01**” will flash on display. The night light will glow red color. Use **(+|-)** to choose the light color (L 01 is red color; L02 is blue; L03 is purple; L04 is yellow; L05 is loop color).

3. Press **SET**

To exit Night Light Option mode.

LIGHT TIMER

Press **LIGHT** repeatedly to adjust the duration of night light. Options available are ALL (continuous), OFF, 15/30/60/90 minutes. The setting will automatically be saved after 2 seconds and exit.

Press **SNOOZE** repeatedly to adjust the night light brightness when it lights up (level 1 to 4).

USER TIP

For optimal sleep quality, we recommend using the red night light at bed time!

NAP TIMER

NAP OPTIONS

1. Press SET

The word “**SETTING**” will appear on the display.

2. Press NAP

Use (+|-) to turn on sound and light mode, sound only mode, or light only mode (Fig. 8). **NOTE:** The nap sound is alarm sound and the light color is green - both are set and can NOT be changed.

3. Press SET

The exit Nap setting.




Fig. 8 Three Nap Mode

NAP TIMER

Press **NAP** repeatedly to adjust the duration of nap timer. Options available are OFF, 15/30/60/90/180 minutes. The setting will automatically be saved after 2 seconds and exit.

NOTE: When the nap is finished, LITTLE TEDDI will wake up and the alarm sound will play (if you choose sound mode) and/or green light will glow (if you choose light mode). To turn off the nap timer alarm or light, press and hold **SNOOZE** for 2 seconds or press **NAP** if it's in unlocked mode.

BRIGHTNESS CONTROL

1. There are 5 brightness levels for LCD Display and Facial Expression. To adjust the brightness, press **TIME** repeatedly to scroll through the options.
2. There are 4 brightness levels for light ring. When it lights up, press **SNOOZE** repeatedly to scroll through the options.

REPLACE BATTERY

Using the included small torx screwdriver, remove the screw from the battery cartridge (Fig. 9). Insert the battery positive side up and fully slide the cartridge back into the compartment. Put screw into place to secure battery compartment.





Fig. 9 Battery Compartment

LOCK MODE

Single press  to lock and prevent accidental change of settings. The following features still function in lock mode.

- Press **SNOOZE** once to snooze for 9 minutes.
- Press and hold **SNOOZE** for 2 seconds, or press any button except **(+/-)** on the bottom to turn off the alarm sound when the alarm is sounding.
- Press and hold **SNOOZE** for 2 seconds to turn off the nap timer alarm or light when the nap timer is finished.
- Press **SNOOZE** repeatedly to adjust the night light brightness when it lights up (level 1 to 4).
- Press **SNOOZE** and hold on 2s to turn off the white light/wake when the play/wake mode is activated.
- Press **TIME** repeatedly to adjust the brightness of LCD display and facial expression (level 1 to 5).

Please scan these QR codes below to watch the videos about how to finish setting.



TIME SETTING

Video



ALARM SETTING

Video



SLEEP SETTING

Video



PLAY-WAKE

Video



NIGHT LIGHT

Video



NAP TIMER

Video