



Yealink SIP-W60B Performance SIP Cordless Phone System User Guide


[Home](#) » [Yealink](#) » Yealink SIP-W60B Performance SIP Cordless Phone System User Guide 

Contents

- [1 Yealink SIP-W60B Performance SIP Cordless Phone System](#)
- [2 Yealink SIP-W60B End User Guide](#)
- [3 Introduction](#)
- [4 Accessing the CommPortal](#)
- [5 Features](#)
- [6 Registering a Handset](#)
- [7 User Information and Voicemail](#)
- [8 Introduction](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

Yealink

Yealink SIP-W60B Performance SIP Cordless Phone System



Yealink SIP-W60B End User Guide

REV. 02.24.2023

Introduction

The Yealink SIP-W60B is a desk phone that comes with a variety of features. This guide will help you get started with your new phone. For more information on the features, please reference the AirePBX Feature Guide at <https://airespring.com/resources/resources-others/?d=guides>.

Accessing the CommPortal

To configure your phone, log in at <https://commportal.airespring.com/>. Once you have logged in, select Devices and add the YealinkW60B.

Features

In this section, you can enable or disable Call Log.

Preferences

In this section, you can enable or disable Call Display, Display Method, and Internal Ringer.

Handsets

In this section, you can configure which description type is displayed on the handset by using directory number, extension, or custom description.

Registering a Handset

1. Charge the W53H or W56H handset.
2. On the base, hit the center button. The top light on the handset will start blinking.
3. On the handset, hit the Reg button.

4. The handset will register to the base, upload new firmware and install.

User Information and Voicemail

In this section, you can configure your user information (number, name, description) and voicemail.

Contact Us

If you need further assistance, please contact us at 888-389-2899 or email us at customerservice@airespring.com.

Introduction

This guide will help you get up and running with your new desk phone. For an explanation of the listed features please reference the AirePBX Feature Guide at <https://airespring.com/resources/resources-others/?d=guides>.

Accessing the CommPortal

To configure phone, log in at <https://commportal.airespring.com/>

Once you login, select Devices and add the Yealink W60B

The screenshot displays the 'Phone Status' configuration page in the AirePBX CommPortal. The interface has a dark blue header with navigation tabs: 'Home', 'Messages and Calls', and 'Contacts'. The 'Phone Status' section includes a status dropdown set to 'Available for Calls', an 'Apply' button, and a 'Cancel' button. Below this, the 'Incoming calls will:' section is set to 'Ring your Account Phone'. A box labeled 'A' indicates the 'Account Phone'. The 'If there is no answer' section has two options: 'Forward to another phone after 36 seconds' (unselected) and 'Send to voicemail after 24 seconds' (selected). The 'If your phone is busy' section has two options: 'Forward to another phone' (unselected) and 'Send to voicemail' (selected). To the right, an 'Advanced Settings' panel contains three checkboxes: 'Forward Selected' (unselected), 'Reject Selected' (unselected), and 'Anonymous Callers' (unselected). Below the 'Phone Status' section is a 'Your Services' section with five orange circular icons: 'Call Settings', 'Message Settings', 'Notifications', 'Reminders', and 'Group Mailboxes'. At the bottom, a dark blue footer contains three columns of links: 'Personal Details' (Roxana Cortez, New Prod MGMT, Admin for New Prod MGMT, Devices, Allocated Licenses, Set Emergency Location), 'Security' (Change Password, Change Call Services PIN, Change Voicemail PIN), and 'Support' (Help, Downloads, Send Feedback).

Once you access to the phone page, the following screen will display:

- On the handset hit the Reg button
- The handset will register to the base and will upload new firmware and install. A temporary error of that the base is not available may be displayed just prior to the firmware upgrade starting.
- Once complete Time & Date should be displayed with the Handset name at the bottom of the screen
- If multiple handsets (up to 8) need to be configured to the W60B base each will have to complete its firmware upgrade and come in-service prior to the next one being able attach to the base. Expect the process to take 5-10 minutes per handset.
- If multiple handsets get registered to the base they will assume sequential handset number from 1 to 8.
- While one of the handsets is firmware upgrading, all handsets on the W60B are non-operational. Attempting to use one will result in a “Other handset is upgrading!” message.

Lines 1 – 8

In this section you will be able to configure:


User's information (Number, Name, Description) and Voicemail.



Contact us at: 888-389-2899

email: customerservice@airespring.com

Documents / Resources

 <p>End User Guide for Yealink SIP-W60B</p> <p>Yealink END USER GUIDE</p>	<p>Yealink SIP-W60B Performance SIP Cordless Phone System [pdf] User Guide SIP-W60B Performance SIP Cordless Phone System, SIP-W60B, Performance SIP Cordless Phone System, SIP Cordless Phone System, Cordless Phone System, Phone System</p>
--	--

References

- [AireSpring - Cloud, Fully Managed and Connected](#)
- [Resources - AireSpring](#)
- [Airespring Phone Settings](#)