



ZEROZERO ROBOTICS Hover 2 User Manual

[Home](#) » [ZEROZERO](#) » ZEROZERO ROBOTICS Hover 2 User Manual 

Contents


- [1 ZEROZERO ROBOTICS Hover 2](#)
- [2 OVERVIEW](#)
- [3 FCC Regulations FCC](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

ZEROZERO


ZEROZERO ROBOTICS Hover 2



OVERVIEW




- For more information, please download the User Manual from the official website.
- This guide is subject to change without prior notice. Please visit the official website for more detailed information.
- Product certification information is available on Home > Settings > Compliance information page
- CMIIT ID: 2019AP7432 FCC ID: 2AIDWZR-100A




- According to changes in market demand or production plan, Shenzhen Zero Zero Infinity Technology Co., Ltd. may change the product specifications and appearance. Please contact us if you have any questions.

Charge the Palm Pilot



- Plug the charging cable into the USB-C Port.
- It takes about 2.5 hours to fully charge.

Connect Hover 2




- Press and hold the power button for 2 seconds to turn on the PalmPilot. Then, select and connect to the Hover 2 hotspot with the Direction Control Stick (press down to select).
 - If the Hover 2 hotspot is not found, press and hold the Wi-Fi / RC toggle button on the drone for 4s, and try to connect again after hearing the beep.

Takeoff Hover 2


- Push the Altitude Control Wheel up for 2 seconds to takeoff.

Landing Hover 2

- Push the Altitude Control Wheel down until Hover 2 lands on the ground, hold for 2 seconds to stop the propellers.



Controlling Hover 2



FCC Regulations FCC

This equipment complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information (SAR) SAR

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy. The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and be positioned a minimum of 1.0 cm from the body.


FCC Note FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



- zzrobotics.com

Documents / Resources

	ZEROZERO ROBOTICS Hover 2 [pdf] User Manual ROBOTICS Hover 2, ROBOTICS, Hover 2
---	--

Manuals+.