

# TRIDONIC sceneCOM S RTC Application Controller User Guide

Home » TRIDONIC » TRIDONIC sceneCOM S RTC Application Controller User Guide 🖫

- 1 TRIDONIC sceneCOM S RTC Application Controller
- **2 Product Information**

**Contents** 

- **3 Product Usage Instructions**
- 4 About this document
- **5 Release versions**
- 6 Features Release 12.2023
- 7 Features Release 11.2023
- 8 Features Release 10.2023
- 9 Features Release 09.202310 Documents / Resources
  - 10.1 References
- 11 Related Posts

## **TRIDONIC**

**TRIDONIC sceneCOM S RTC Application Controller** 



#### **Product Information**

#### **Specifications**

• Hardware version: 1.0

nRF version: 1.1STM version: 2.1.1

• sCS commissioning App version:

o iOS: V 2.0.2 B204

Android: V 2.0.2 B204

• sCS Remote App version:

o iOS: 1.1.2 B23

· Android: 1.1.2 B23

• Valid with release: 12.2023

#### **Product Usage Instructions**

#### sCS Remote app

#### Colour Control

If you change the colour control of one head, all heads will receive the same colour temperature. This ensures that all heads of your FSL will have the same colour temperature.

#### • FSL Ordering by Signal Strength

FSLs out of range are ordered by last seen date. If the signal strength changes, the FSL order will also change.

#### • New Global On/Off Behaviour

If you turn on or off a multi-head FSL, all heads will react simultaneously. Previously, the heads were switched on/off one after the other.

#### Presence Luminous Intensity Setting

The presence luminous intensity can now be set in the Settings page. If the light regulation is active, it will be expressed in lux. If the light regulation is not active, it will be expressed in percent.

#### sCS commissioning app

#### • New Global Group Concept for FSL Application

Three new global groups are introduced, and drivers are automatically added to those groups. Group 13 is for Direct Drivers, Group 14 is for Indirect Drivers, and Group 15 is a general global group.

#### New Light Regulation Algorithm for FSL Multi-Head Application

With this update of the light regulation algorithm, the lux level of all sensors is considered, and the light regulation regulates the light until all sensors have reached the set value. In the past, the light regulation was done head-dependent. With this improvement, the whole FSL is regulated homogeneously, meaning that all heads will have the same lux level.

#### **FAQ**

#### Q: What is the purpose of the sCS Remote app?

A: The sCS Remote app allows users to control the colour temperature and on/off behaviour of multiple FSL heads simultaneously.

#### • Q: How can I set the presence luminous intensity?

A: You can set the presence luminous intensity in the Settings page of the sCS Remote app. If light regulation is active, it will be expressed in lux. If light regulation is not active, it will be expressed in percent.

Release notes – sceneCOM S RTC CWM 31 BT NF DA2 | 12-2023 | en

#### **About this document**

This document shows the history of released sceneCOM S RTC CWM 31 BT NF DA2 versions. For more details make sure to also have a look in the manuals of the apps and check also the release notes in the app stores:

<u>sceneCOM S RTC commissioning app and sceneCOM S remote app</u>

#### Release versions

			sCS commissioning App version		sCS Remote App version		
Hardware version	nRF version	STM version	iOS	Android	iOS	Android	Valid with release
1.0	1.1	2.1.1	V 2.0.2 B204	V 2.0.2 B204	1.1.2 B23	1.1.2 B23	12.2023
1.0	1.1	2.0.2	2.0.1 B201	2.0.1 B201	1.0	1.0	11.2023
1.0	1.1	2.0.2	2.0.0 B185	2.0.0 B184	1.0	1.0	10.2023
1.0	1.1	2.0.1	2.0.0 B185	2.0.0 B184	1.0	1.0	09.2023

#### Features Release 12.2023

### sCS Remote app Colour Control improved

If a user changes the colour control of one head, all heads will receive this colour temperature. This ensures that all heads of your FSL will have the same colour temperature.

#### FSLs now ordered by signal strength

- FSLs out of range are ordered by last seen date.
- If the signal strength changes, the FSL order also changes.

#### New global on/off behaviour

If you turn on or off a multi-head FSL, all heads will react simultaneously. In the past the heads were switched on/off one after the other.

#### "Presence Luminous Intensity" can now be set in the "Settings" page.

• If the light regulation is active, it will be expressed in lux if the light regulation is not active it will be expressed in percent.

### sCS commissioning app New global group concept for FSL application

- 3 new global groups are introduced, drivers are automatically added to those groups
- Group 13 is introduced as a global group for Direct Drivers
- Group 14 is introduced as a global group for Indirect Drivers
- Group 15 is introduced as a global group

Head	Direct driver	´s group	Indirect driver's group		
	App group	DALI group	App group	DALI group	
1 A (Master)	A DL	0,13,15	A IL	1,14,15	
2 B	B DL	2,13,15	B IL	3,14,15	
3 C	C DL	4,13,15	CIL	5,14,15	
4 D	D DL	6,13,15	DIL	7,14,15	

#### New light regulation algorithm for the FSL multi head application

With this update of the light regulation algorithm, the lux level of all sensors is considered and the light regulation regulates the light until all sensors have reached the set value.

In the past the light regulation was done head depended. With this improvement the whole FSL is regulated homogeneous, which means that all heads will have the same lux level.

#### **Example of a 4 Head FSL**

#### Scenario A:

Head A in presence -> Sensor of Head A will be used as reference, because there is just one Head in presence state.

- If swarm feature is not enabled \_ Head B, C and D will stay off
- · If swarm feature is enabled

Head B, C and D will go to "swarm direct neighbour level", the heads will regulate to e.g. 50% of the programmed target value (if the direct neighbour level is programmed to 50%) but as the reference sensor the sensor who measures the lowest lux level of the three heads will be considered.

#### Scenario B:

Head A and B in presence → Sensor that measures the lower lux level will be used as reference sensor.

- · If swarm feature is not enabled
- Head C and D will stay off.
- · If swarm feature is enabled

Head C and D will go to "swarm direct neighbour level", the heads will regulate to e.g. 50% of the programmed target value (if the direct neighbour level is programmed to 50%) but as the reference sensor the sensor who measures the lowest lux level of the two heads will be considered.

#### Features Release 11.2023

General stability improvements

#### Features Release 10.2023

• Start up algorithm improved so that an easy replacement of FSL heads is possible.

#### Features Release 09.2023

#### First release version

- · RTC Real Time Clock provided
- NFC ready
- · Revised floor plan editor for faster setup
- New toolbars for faster applying of luminaires, input devices and group assignment
- · All new controller bar to connect and manage devices
- New home for global settings, scenes and Human Centric Lighting (HCL) profiles
- Free-standing luminaire (FSL) configurator to create various luminaire setups
- Adaptive SWARM module and IR6+ remote support

#### **Documents / Resources**



TRIDONIC sceneCOM S RTC Application Controller [pdf] User Guide sceneCOM S RTC Application Controller, sceneCOM S RTC, Application Controller, Controller

#### References

• User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.