

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Scan](#) /
- › [Scan SCAPPEEARCOL Collapsible Ear Defender Instruction Manual](#)

Scan SCAPPEEARCOL

Scan SCAPPEEARCOL Collapsible Ear Defender Instruction Manual

Model: SCAPPEEARCOL

INTRODUCTION

Thank you for choosing the Scan SCAPPEEARCOL Collapsible Ear Defenders. These ear defenders are designed to provide effective hearing protection in noisy environments, reducing noise levels by 28 decibels (SNR 28dB) while allowing for normal conversation. Please read this manual carefully before use to ensure proper fit, function, and maintenance.

PRODUCT OVERVIEW

The Scan SCAPPEEARCOL ear defenders feature a collapsible design for easy storage and portability. They are equipped with comfortable ear cups and an adjustable headband to ensure a secure and effective seal around the ears.



Image: Front view of the Scan SCAPPEEARCOL Collapsible Ear Defenders, showcasing the red ear cups and black headband.



Image: The Scan SCAPPEEARCOL Collapsible Ear Defenders shown in their folded, compact state, ideal for storage and transport.

SETUP AND ADJUSTMENT

1. **Unfold the Ear Defenders:** Gently unfold the ear defenders until the headband is fully extended and the ear cups are in position.
2. **Position on Head:** Place the ear defenders over your ears, ensuring the ear cups completely cover your outer ears.
3. **Adjust Headband:** Slide the ear cups up or down along the headband to achieve a snug and comfortable fit. The headband should rest over the top of your head.
4. **Ensure a Seal:** Verify that the ear cushions form a tight seal around your ears. Any gaps can compromise noise reduction effectiveness. Adjust as necessary.



Image: A visual representation demonstrating the adjustable nature of the ear defender headband, allowing for a personalized and comfortable fit.

OPERATING INSTRUCTIONS

Once properly adjusted, the ear defenders will provide continuous hearing protection. They are suitable for general purpose use in environments with moderate to high noise levels, such as workshops, construction sites, or during gardening tasks.

- **Wear Continuously:** For maximum protection, wear the ear defenders continuously while exposed to noise.
- **Check Fit Regularly:** Periodically check the fit to ensure the ear cups maintain a good seal, especially if you move or adjust your headwear.
- **Communication:** The SNR 28dB rating allows for normal conversation to be heard, though muffled, ensuring you can still communicate effectively in many situations.



Image: A person wearing the Scan SCAPPEEARCOL ear defenders along with safety glasses, demonstrating proper usage in a work environment.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and effectiveness of your ear defenders.

- **Cleaning:** Clean the ear defenders with a damp cloth.
- **Drying:** Allow the ear defenders to air dry completely before storage.
- **Storage:** Store in a clean, dry place away from direct sunlight and extreme temperatures. The collapsible design facilitates compact storage.
- **Inspection:** Regularly inspect the ear cups, cushions, and headband for any signs of wear, damage, or deterioration. Replace if necessary to maintain optimal protection.

TROUBLESHOOTING

If you experience issues with your ear defenders, consider the following:

- **Reduced Noise Reduction:**

- Ensure the ear cups are fully covering your ears and forming a tight seal.
- Adjust the headband for a snug fit.
- Check for any damage to the ear cushions or cracks in the ear cups that might compromise the seal.

- **Discomfort:**

- Re-adjust the headband and ear cups to find a more comfortable position.
- Ensure no hair or other objects are trapped under the ear cushions.

If problems persist, discontinue use and consider replacing the ear defenders.

SPECIFICATIONS

- **Model:** SCAPPEEARCOL
- **Noise Reduction Rating (SNR):** 28dB
- **Type:** Collapsible Ear Defender
- **Compliance:** EN 352-1 (Hearing protectors) - *Note: An accompanying image displays an SNR of 32dB, however, the product description and feature bullets specify an SNR of 28dB for this model. Please refer to your product packaging for the exact rating of your specific unit.*
- **Care Instructions:** Clean with a damp cloth and allow to air dry.

CE EN 352-1
Hearing protectors

SNR 32dB



SNR – Single Number Rating – simplified noise reduction factor. A single number that represents the amount of attenuation that the hearing protector can provide.

Image: This image displays ear defenders with a stated SNR of 32dB and compliance with EN 352-1. Please note that the product description for this specific model indicates an SNR of 28dB. Always verify the specifications on your product packaging.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. Scan provides quality products, and support is available through authorized channels.