

[Manuals.plus](#) /

› [Newport Brass](#) /

› Newport Brass 125 East Linear Deck Mounted Soap and Lotion Dispenser User Manual

Newport Brass 125

Newport Brass 125 East Linear Deck Mounted Soap and Lotion Dispenser User Manual

Model: 125

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Newport Brass 125 East Linear Deck Mounted Soap and Lotion Dispenser. Please read these instructions carefully before installation and use to ensure proper function and longevity of the product.

PRODUCT OVERVIEW





Figure 1: Newport Brass 125 East Linear Deck Mounted Soap and Lotion Dispenser. This image displays the complete dispenser unit, featuring a satin gold pump mechanism and spout, connected to a white reservoir bottle. The design is characterized by its clean, linear aesthetic.

The Newport Brass 125 East Linear dispenser is designed for deck mounting, providing a convenient and elegant solution for dispensing soap or lotion. It features a durable brass construction with a satin gold finish, complementing contemporary bathroom or kitchen designs.

SETUP AND INSTALLATION

Before beginning installation, ensure all necessary tools and components are available. Professional installation is recommended.

Components:

- Dispenser pump head with spout
- Mounting shank and nut
- Reservoir bottle
- Washer (if applicable)

Installation Steps:

1. **Prepare Mounting Hole:** Ensure a suitable mounting hole (typically 1-1/4" to 1-1/2" diameter) is available on the deck surface. If not, drill a new hole according to the manufacturer's specifications, ensuring it is clear of obstructions below.
2. **Insert Dispenser Shank:** From above the deck, insert the threaded shank of the dispenser pump head through the mounting hole.
3. **Secure Dispenser:** From below the deck, place any provided washer over the threaded shank, followed by the mounting nut. Tighten the mounting nut securely by hand, then use a wrench to ensure a firm connection, being careful not to overtighten.
4. **Attach Reservoir Bottle:** Fill the reservoir bottle with your desired liquid soap or lotion. Screw the filled reservoir bottle onto the threaded shank from below the deck until it is hand-tight.
5. **Test Operation:** Pump the dispenser head several times to prime the pump and ensure proper dispensing.

OPERATING INSTRUCTIONS

Filling the Dispenser:

- To fill or refill, simply lift the pump head assembly straight up from the deck.
- Pour liquid soap or lotion directly into the reservoir bottle from above the deck.
- Do not overfill.
- Replace the pump head assembly by inserting it back into the mounting shank.

Dispensing:

- Press down firmly on the pump head to dispense soap or lotion.
- Allow the pump head to return to its original position before pressing again for additional dispensing.

MAINTENANCE

Cleaning:

- Clean the exterior of the dispenser regularly with a soft, damp cloth.
- Avoid abrasive cleaners, harsh chemicals, or polishes, as these can damage the finish.
- For stubborn spots, use a mild soap solution and rinse thoroughly.

Pump Mechanism Care:

- If the pump becomes stiff or clogged, remove the pump head and rinse it thoroughly under warm water.
- For severe clogs, soak the pump mechanism in warm water for several minutes to dissolve any dried soap or lotion.
- Ensure the pump tube is clear of debris.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dispenser does not pump.	Reservoir empty; pump clogged; pump not primed.	Refill reservoir; clean pump mechanism (see Maintenance); pump several times to prime.
Dispenser leaks.	Reservoir bottle not securely attached; mounting nut loose.	Ensure reservoir bottle is hand-tight; check and tighten mounting nut from below the deck.
Pump is stiff or difficult to press.	Dried soap/lotion in pump mechanism; using overly thick liquid.	Clean pump mechanism thoroughly (see Maintenance); dilute liquid soap/lotion if too thick.

SPECIFICATIONS

- **Model:** 125 East Linear
- **Brand:** Newport Brass
- **Material:** Brass
- **Color/Finish:** Satin Gold
- **Height:** 11" (top to bottom)
- **Width:** 4-3/4" (left to right)
- **Item Weight:** 5 pounds
- **UPC:** 091388224058

Note: Dimensions and weight are approximate and may vary slightly. Product dimensions (1 x 1 x 1 inches) listed in some specifications may refer to packaging.

WARRANTY AND SUPPORT

This Newport Brass product is covered under a limited warranty and limited commercial trim warranty. For specific details regarding your warranty coverage, please refer to the documentation provided with your purchase or visit the official Newport Brass website.

For technical assistance, replacement parts, or further inquiries, please contact Newport Brass customer support directly. Contact information can typically be found on the manufacturer's website or product packaging.

© 2023 Newport Brass. All rights reserved.

This manual is for informational purposes only. Newport Brass reserves the right to make changes to products and specifications without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question