

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Peavey](#) /
- › [Peavey Sanpera I Foot Controller Instruction Manual](#)

Peavey Sanpera I Foot Controller

Peavey Sanpera I Foot Controller Instruction Manual

INTRODUCTION

The Peavey Sanpera I Foot Controller is designed to enhance the functionality of compatible Peavey amplifiers, particularly the Vypyr series. This robust foot controller provides hands-free control over various effects and amplifier parameters, allowing musicians to focus on their performance.

It features a **Whammy/Volume/Wah/Pitch Shifter expression pedal**, four momentary selector buttons with LEDs, looper activation and control, and a bank select function. Constructed with a roadworthy cast-metal housing and high-quality metal switches, the Sanpera I is built for durability and reliable use.



Image of the Peavey Sanpera I Foot Controller, showing the expression pedal, four footswitches with LED indicators, and its robust metal casing.

SETUP

1. **Unpacking:** Carefully remove the Sanpera I Foot Controller from its packaging. Inspect the unit for any signs of damage.
2. **Connection:** Connect the Sanpera I Foot Controller to the dedicated foot controller input on your compatible Peavey amplifier (e.g., Peavey Vypyr series). Refer to your amplifier's manual for the specific cable type and connection port. Ensure the connection is secure.
3. **Power:** The Sanpera I Foot Controller typically draws power directly from the connected amplifier. Ensure your amplifier is powered on and functioning correctly.

OPERATING

The Sanpera I Foot Controller provides real-time control over your amplifier's effects and settings, allowing for dynamic performance adjustments.

- **Expression Pedal:** Use the integrated expression pedal for dynamic control over various effects such as Whammy, Volume, Wah, and Pitch Shifter. The specific function controlled by the pedal will depend on the active preset or amplifier mode selected on your Peavey amplifier.

- **Momentary Selector Buttons:** The four momentary selector buttons, each equipped with an LED indicator, allow for quick selection of presets, activation/deactivation of effects, or other assigned functions. Consult your amplifier's instruction manual for detailed information on button assignments and customization.
- **Looper Control:** Activate and control the looper function of your compatible Peavey amplifier directly from the foot controller. This includes essential looper operations such as recording, playback, overdubbing, and stopping loops.
- **Bank Select Function:** Utilize the bank select function to navigate through different banks of presets stored in your amplifier. This expands your accessible sound palette during live performance or practice sessions.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior surfaces of the foot controller. Avoid using abrasive cleaners, solvents, or excessive moisture, as these can damage the finish or internal components.
- **Storage:** When not in use, store the Sanpera I Foot Controller in a dry environment, away from extreme temperatures, high humidity, and direct sunlight.
- **Inspection:** Periodically inspect all cables and connections for signs of wear, fraying, or damage. Replace any damaged cables immediately to ensure proper functionality and safety.

TROUBLESHOOTING

- **No Power or No Response:**
 - Ensure the foot controller cable is securely connected to both the Sanpera I and the amplifier.
 - Verify that the connected amplifier is powered on and functioning correctly.
 - Check the cable for any visible damage. Try a different compatible cable if available.
- **Incorrect Effect Control:**
 - Confirm that the correct preset or amplifier mode is selected on your amplifier.
 - Refer to your amplifier's instruction manual for proper configuration and assignment of the Sanpera I's controls.
- **Expression Pedal Not Working:**
 - Ensure the expression pedal is assigned to a specific function within your amplifier's settings.
 - Check for any physical obstructions that might be preventing full movement of the pedal.

SPECIFICATIONS

Item Model Number	Sanpera I Foot Controller
Item Weight	4.69 pounds (2.13 Kilograms)
Product Dimensions	12.25 x 11.5 x 4.75 inches
Hardware Interface	1/4-inch Audio
Signal Format	Analog
Voltage	9 Volts

Amperage	300 Milliamps
-----------------	---------------

WARRANTY AND SUPPORT

For detailed warranty information regarding your Peavey Sanpera I Foot Controller, please refer to the documentation provided with your original purchase or visit the official Peavey website. For technical support, product registration, or service inquiries, please contact Peavey customer service directly through their official channels.