

Sanitas 314.31

Sanitas SWB 50 Heated Mattress Protector User Manual

INTRODUCTION

This manual provides important information for the safe and effective use of your Sanitas SWB 50 Heated Mattress Protector. Please read these instructions carefully before first use and keep them for future reference.

The Sanitas SWB 50 is designed to provide comfortable warmth for your bed. It features three temperature settings and an integrated safety system to ensure safe operation.



This diagram illustrates the main characteristics of the heated mattress protector, including its washability, dimensions, material certification, adjustable heat settings, breathability, and integrated safety features.

SETUP

Unpacking

Carefully remove the heated mattress protector from its packaging. Ensure all components are present and undamaged.

Placement

Place the heated mattress protector directly on your mattress. Ensure it lies flat and smooth, without creases or folds. The control unit should be positioned at the head end of the bed, within easy reach.



The image displays the heated mattress protector correctly positioned on a bed, ensuring it is smooth and covers the mattress surface evenly.

OPERATING INSTRUCTIONS

Connecting to Power

Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the product's requirements.

Turning On and Temperature Settings

To turn on the heated mattress protector, slide the switch on the control unit to the desired temperature setting. The Sanitas SWB 50 offers three temperature settings:

- **Setting 1:** Minimum warmth
- **Setting 2:** Medium warmth
- **Setting 3:** Maximum warmth

For rapid pre-heating, set the control to level 3 for approximately 30-45 minutes before use. Once the desired warmth is achieved, you can reduce the setting or turn off the device.



A detailed view of the control unit, highlighting the power switch and the three distinct temperature settings (1, 2, 3) for adjusting warmth.

Safety System

The integrated safety system is designed to prevent overheating. In case of a malfunction, the device will automatically switch off. If this occurs, unplug the device and contact customer support.

MAINTENANCE AND CARE

Cleaning

Always unplug the heated mattress protector from the power outlet and allow it to cool completely before cleaning.

The Sanitas SWB 50 is machine washable up to 30°C. Ensure the control unit is detached before washing. Do not dry clean, bleach, tumble dry, or iron the heated mattress protector.

After washing, reshape the protector and allow it to air dry thoroughly before reattaching the control unit and using it again.



This icon confirms the heated mattress protector is machine washable at temperatures up to 30 degrees Celsius.

TROUBLESHOOTING

Device Not Heating

- Check if the power cord is securely plugged into the electrical outlet and the control unit.
- Ensure the control unit is set to a temperature level (1, 2, or 3) and not in the 'off' position.
- If the safety system has activated, the device may have automatically switched off. Unplug and wait a few minutes before trying again. If the issue persists, contact customer support.

Uneven Heating

- Ensure the heated mattress protector is laid flat on the mattress without any folds or creases, which can affect heat distribution.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	314.31
Brand	Sanitas
Power	60 W
Dimensions (L x W x H)	150 x 80 x 1 cm
Weight	2.69 kg
Material	Polyester
Temperature Settings	3
Safety System	Integrated overheating protection
Washable	Machine washable up to 30°C (control unit detachable)
Certification	Oeko-Tex Standard 100



The Oeko-Tex Standard 100 label confirms that the textile components of the heated mattress protector have been tested for harmful substances and are safe for human ecological use.

WARRANTY

This Sanitas product is covered by a manufacturer's warranty. Please refer to the warranty card included with your product or visit the official Sanitas website for detailed warranty terms and conditions.

CUSTOMER SUPPORT

For any questions, technical assistance, or service requests, please contact Sanitas customer support. Contact information can typically be found on the product packaging, the official Sanitas website, or by referring to the warranty documentation.