

Dr. Brown's 850T

Dr. Brown's Deluxe Baby Bottle Warmer (Model 850T) Instruction Manual

INTRODUCTION

The Dr. Brown's Deluxe Baby Bottle Warmer is designed to quickly and safely warm baby bottles and food jars using electric steam heat. This system is compatible with all Dr. Brown's bottles and most other bottle brands. It features an easy-to-use LCD control panel, audio and visual alerts, and an automatic shut-off function for convenience and safety.

SAFETY INFORMATION

WARNING: Read the ENTIRE instruction manual to become familiar with the features of the product before operating. Failure to operate the product correctly can result in damage to the product, personal property and cause serious injury. Failure to operate this product in a safe and responsible manner could result in injury or damage to the product or other property. This product is not intended for use by children. Do not attempt disassembly or use with incompatible components. This manual contains instructions for safety, operation and maintenance. It is essential to read and follow all the instructions and warnings in the manual, prior to setup or use, in order to operate correctly and avoid damage or serious injury.

Do Not Immerse in Water. Household Use Only.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Dr. Brown's Deluxe Baby Bottle Warmer:

- **Hinged Lid:** Covers the warming chamber.
- **Warming Chamber:** Where the bottle or food jar is placed for warming.
- **Removable Water Reservoir:** Located on the side, holds water for steam generation.
- **Control Panel and LCD Timer Display:** For setting and monitoring warming cycles.
- **Removable Basket:** Holds bottles and food jars in the warming chamber.
- **Storage Caps:** Used to cover bottles during warming.



Image: The Dr. Brown's Deluxe Baby Bottle Warmer, a white unit with a grey hinged lid and a digital display on the front, shown on a countertop.

SETUP

1. **Unpack:** Remove all packaging materials and ensure all components are present.
2. **Clean:** Before first use, wipe down the exterior with a damp cloth. Clean the removable basket and lid with warm, soapy water. Do not immerse the main unit in water.
3. **Fill Water Reservoir:** Open the side reservoir and fill it with distilled water. Using distilled water helps prevent mineral buildup and prolongs the life of the unit. The reservoir is designed to hold enough water for several warming cycles.
4. **Place Basket:** Insert the removable basket into the warming chamber. The basket can be adjusted for different bottle sizes.
5. **Plug In:** Connect the power cord to a standard electrical outlet (120V AC only, for use in US and Canada).

Video: An official product video demonstrating the setup and use of the Dr. Brown's Deluxe Bottle Warmer, including filling the water reservoir, placing the basket, and inserting a bottle.

OPERATING INSTRUCTIONS

1. **Prepare Bottle:** Fill the baby bottle with milk or formula. If using Dr. Brown's bottles, slightly unscrew the top before warming to prevent milk from traveling up the vent. Place a storage cap on the bottle.

2. **Place Bottle in Warmer:** Insert the prepared bottle into the removable basket within the warming chamber. Ensure the basket is adjusted to the correct height for your bottle size.
3. **Close Lid:** Close the hinged lid securely over the warming chamber.
4. **Set Warming Time:** Use the up/down arrow buttons on the control panel to adjust the warming time according to the Warming Time Chart (see below). The unit has a cycle memory to repeat the last preferred heating time.
5. **Start Warming:** Press the play button to begin the warming cycle. The LCD display will show a countdown.
6. **Monitor:** Audio and visual alerts will indicate when the warming cycle is complete. The unit automatically shuts off after the cycle is finished.
7. **Remove Bottle:** Carefully open the lid and use the basket handles to lift the warm bottle out.
8. **Test Temperature:** Always test the temperature of the milk on your wrist before feeding to ensure it is not too hot for your baby.



Image: A hand carefully placing a Dr. Brown's baby bottle into the warming chamber of the bottle warmer.

WARMING TIME CHART (DR. BROWN'S PLASTIC BOTTLES)

This chart provides approximate warming times. Actual times may vary depending on the initial temperature, volume, and material of the bottle. Always test milk temperature before feeding.

Bottle Size	Room Temp	Refrigerator	Frozen*
2 oz / 4 oz Narrow			

Bottle Size	Room Temp	Refrigerator	Frozen*
2 oz / 60 mL	2:20	3:15	7:30
4 oz / 120 mL	2:45	4:00	9:00
5 oz / 9 oz Wide-Neck			
5 oz / 150 mL	1:20	2:30	5:15
7 oz / 210 mL	3:20	5:45	11:05
9 oz / 270 mL	3:40	6:05	11:20

**Multiple cycles may be required for times exceeding 8 minutes (Cycle 1 + Cycle 2 = total time).*

MAINTENANCE AND CLEANING

Regular cleaning is essential for optimal performance and longevity of your bottle warmer.

- **Daily Cleaning:** After each use, wipe down the warming chamber and lid with a damp cloth.
- **Descaling:** Mineral deposits can accumulate over time, especially if tap water is used. To descale, mix white vinegar and water (e.g., 1:1 ratio) and pour it into the warming chamber. Run a warming cycle without a bottle. After the cycle, unplug the unit, let it cool, and rinse the chamber thoroughly with clean water. Repeat if necessary.
- **Exterior:** Wipe the exterior of the unit with a damp cloth. Do not use abrasive cleaners.
- **Note:** The unit is not dishwasher safe.

TROUBLESHOOTING

If you encounter issues with your Dr. Brown's Deluxe Baby Bottle Warmer, consider the following:

- **Inconsistent Warming:** Ensure the water reservoir is adequately filled with distilled water. Verify that the correct warming time is selected based on the milk volume and starting temperature (room temp, refrigerated, frozen).
- **Leaks or Spills:** If using Dr. Brown's bottles, ensure the top is slightly unscrewed during warming to allow air to vent. Check for proper placement of the bottle and basket.
- **Mineral Buildup:** If you notice white or discolored residue, perform a descaling cycle as described in the Maintenance section.
- **Unit Not Turning On:** Check if the unit is properly plugged into a working electrical outlet.







SPECIFICATIONS

- **Product Dimensions:** 5.5 x 7.9 x 9.6 inches
- **Item Model Number:** 850T
- **Material Type:** Plastic
- **Material Composition:** BPA Free Plastic with Electronic Components
- **Item Weight:** 2 pounds
- **Power:** 120V AC, 60Hz (for use in US and Canada only)

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your product or visit the official Dr. Brown's website. Keep your purchase receipt for proof of purchase.

Related Documents - 850T

 <p>Dr. Brown's natural flow</p> <p>Deluxe Bottle Warmer Model Number 850T</p> <p>Châuffe-biberon Deluxe Modèle Numéro 850T</p> <p>Calentador de biberones Deluxe Número de Modelo 850T</p>	<p>Dr. Brown's Natural Flow Deluxe Bottle Warmer 850T - User Manual and Instructions</p> <p>Comprehensive user manual and safety instructions for the Dr. Brown's Natural Flow Deluxe Bottle Warmer (Model 850T). Learn about setup, operation, cleaning, and warming time charts for bottles and food jars.</p>
 <p>Dr. Brown's natural flow</p> <p>Deluxe Bottle Warmer Model 850T</p>	<p>Dr. Brown's Natural Flow Deluxe Bottle Warmer Model 850T User Manual</p> <p>Comprehensive guide to operating, cleaning, and maintaining the Dr. Brown's Natural Flow Deluxe Bottle Warmer (Model 850T) for safely warming baby bottles and food jars.</p>
 <p>Dr. Brown's natural flow</p> <p>Deluxe Bottle Warmer Model Number 850T</p>	<p>Dr. Brown's Deluxe Bottle Warmer (Model 850T) - User Manual and Instructions</p> <p>Comprehensive user manual for the Dr. Brown's Natural Flow Deluxe Bottle Warmer (Model 850T). Includes setup, operation, safety instructions, and a warming time chart for baby bottles and food jars.</p>
 <p>Dr. Brown's</p> <p>INSTRUCTIONS FOR USE INSTRUCTIONS D'UTILISATION INSTRUCCIONES DE USO</p> <p>Deluxe Bottle Warmer and Sterilizer Model Number AC147 (AC147-001)</p> <p>Châuffe-biberon de luxe avec stérilisateur Modèle numéro AC147 (AC147-001)</p> <p>Calentador de biberones y Esterilizador Deluxe Número de modelo AC147 (AC147-001)</p>	<p>Dr. Brown's Deluxe Bottle Warmer and Sterilizer: Instructions for Use</p> <p>Comprehensive user manual for the Dr. Brown's Deluxe Bottle Warmer and Sterilizer (Model AC147), covering setup, operation for warming and sterilizing, cleaning, troubleshooting, and warranty information.</p>
 <p>Dr. Brown's Natural Flow</p> <p>Deluxe Bottle Warmer</p>	<p>Dr. Brown's Natural Flow Deluxe Bottle Warmer: User Manual and Safety Guide</p> <p>Detailed instructions and safety information for the Dr. Brown's Natural Flow Deluxe Bottle Warmer. Learn how to use, clean, and maintain your bottle warmer for efficient and safe warming of baby bottles and food jars.</p>
 <p>Dr. Brown's natural flow</p> <p>INSTRUCTIONS FOR USE INSTRUCTIONS D'UTILISATION INSTRUCCIONES DE USO</p> <p>Insta-Feed™ Bottle Warmer Model Number AC144</p> <p>Châuffe-biberon Insta-Feed™ Modèle Numéro AC144</p> <p>Calentador de biberones Insta-Feed™ Número de Modelo AC144</p>	<p>Dr. Brown's Insta-Feed Bottle Warmer: User Manual, Instructions, and Safety Guide</p> <p>Comprehensive instructions for the Dr. Brown's Insta-Feed Bottle Warmer, covering usage, safety guidelines, warming guide, sterilizing small parts, cleaning, de-scaling, troubleshooting, and warranty information. Learn how to safely warm baby bottles and food jars.</p>

