

Fujitsu FI-C100CF1

Fujitsu FI-C100CF1 Cleaner F1 User Manual

Model: FI-C100CF1 (Part No. PA03950-0352)

1. INTRODUCTION

The Fujitsu FI-C100CF1 Cleaner F1 is a specialized cleaning solution designed for the maintenance of Fujitsu document scanners. This product is formulated to effectively clean rollers and other internal components, ensuring optimal performance and extending the lifespan of your equipment. Regular use helps prevent paper jams and maintains high-quality scanning results.

2. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using this product.

- **Harmful if Swallowed or Inhaled:** Do not inhale or swallow the liquid. If swallowed, rinse mouth thoroughly with water and **do not induce vomiting**. Seek immediate medical attention and show this product's label to the physician.
- **Skin and Eye Irritant:** Avoid contact with eyes, skin, and face. If contact occurs, rinse immediately with plenty of water for several minutes. If irritation persists, seek medical attention.
- **Protective Measures:** Wear protective gloves, especially if you have sensitive skin.
- **Intended Use Only:** Use this product only for its intended application, which is cleaning scanner rollers and belts. Do not use for any other purpose.
- **Keep Out of Reach:** Store out of reach of children and pets.
- **Clothing Contact:** Avoid contact with clothing as the solution may cause stains. If clothing becomes contaminated, rinse immediately with water.
- **Storage Conditions:** Do not store above 40°C (104°F) or in direct sunlight. Do not freeze the product.
- **Post-Use Hygiene:** Wash hands thoroughly with soap and water after each use.
- **Product Appearance:** The liquid inside may turn cloudy or show floating bodies/precipitation after a long period or if frozen. This does not affect its cleaning performance.
- **Container Handling:** Close the container lid tightly after each use.

3. PRODUCT OVERVIEW

The Fujitsu FI-C100CF1 Cleaner F1 is supplied in a spray bottle for easy application. It is specifically formulated for cleaning the rubber rollers and belts found in Fujitsu document scanners.



Image 1: Fujitsu FI-C100CF1 Cleaner F1 spray bottle. The bottle is white with a clear cap over a spray nozzle. The label on the bottle contains product information and safety warnings in both Japanese and English.

4. USAGE INSTRUCTIONS

4.1. Preparation

1. Ensure the scanner is powered off and unplugged from the electrical outlet.
2. Open the scanner cover to access the rollers and belts that require cleaning.
3. Wear appropriate protective gloves to prevent skin contact.
4. Have a clean, lint-free cloth readily available.

4.2. Application

1. Lightly spray a small amount of the FI-C100CF1 cleaner onto the lint-free cloth. Do not spray directly onto scanner components.
2. Gently wipe the surface of the rollers and belts with the moistened cloth. Ensure all visible dirt, dust, and residue are removed.
3. For stubborn dirt, repeat the process with a fresh section of the cloth.
4. Allow the cleaned components to air dry completely before closing the scanner cover.

4.3. Post-Cleaning

1. Close the scanner cover securely.
2. Plug in and power on the scanner.
3. Wash your hands thoroughly with soap and water after handling the cleaner.

5. STORAGE AND DISPOSAL

5.1. Storage

- Store the cleaner in a cool, dry place, away from direct sunlight and heat sources.
- Ensure the cap is tightly closed after each use.
- Do not store in temperatures exceeding 40°C (104°F) or allow it to freeze.
- Keep out of reach of children and pets.

5.2. Disposal

Dispose of the empty container and any remaining solution according to local environmental regulations. Do not pour down drains or dispose of with regular household waste.

6. TROUBLESHOOTING

Issue	Possible Cause / Solution
Liquid appears cloudy or has floating particles.	This is normal and does not affect the cleaning performance of the product.
Skin irritation after contact.	Rinse affected area thoroughly with water. Wear protective gloves during future use. If irritation persists, seek medical attention.
Product accidentally ingested.	Rinse mouth with water. Do not induce vomiting. Seek immediate medical attention and show the product label.

7. SPECIFICATIONS

Feature	Detail
Brand	Fujitsu
Model Number	FI-C100CF1
Part Number	PA03950-0352
Item Form	Liquid
Scent	Water Lily
Specific Uses For Product	Personal (for cleaning scanner components)
Material Feature	Fragrance Free
Active Agent	Anionic surfactant 0.5wt%
CAS No.	577-11-7
Net Weight	100ml (approximately 5.6 ounces)
Product Dimensions	6.75 x 1.72 x 1.75 inches

8. WARRANTY AND SUPPORT

For information regarding product warranty, technical support, or service, please refer to the official Fujitsu documentation provided with your scanner or visit the official Fujitsu website. Contact details for customer support can typically be found on the manufacturer's website or in your scanner's user manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question