

Versa G097

Versa G097 Single Automatic Watch Winder Instruction Manual

Model: G097

1. INTRODUCTION

Thank you for choosing the Versa G097 Single Automatic Watch Winder. This device is designed to keep your automatic watch wound and ready to wear, maintaining its accuracy and extending its lifespan. The G097 features a direct drive motor, touch button settings, and an adjustable watch pillow for optimal performance.

Please read this manual thoroughly before operating the watch winder to ensure proper use and care.

2. PRODUCT OVERVIEW

Key Features:

- **Direct Drive Motor:** Ensures quiet and reliable operation.
- **Touch Button Settings:** Easy selection of winding modes and Turns Per Day (TPD).
- **12 Winding Settings:** Customizable options for various automatic watch movements.
- **Display Light:** Illuminates the watch for visibility.
- **Adjustable Watch Pillow:** Accommodates a wide range of watch sizes, from 6 to 8.25 inches.
- **Compact Design:** Space-efficient and modern aesthetic.

Components:

- Versa G097 Watch Winder Unit
- Power Adapter
- Spring Action Watch Pillow
- Additional Attachment for Large Watches



Image: The Versa G097 watch winder with an automatic watch securely placed inside.



MULTIPLE SETTINGS

For direction and TPD
(Turns Per Day)

ADJUSTABLE

Spring action pillow to
hold small and large
wrists

PLENTY OF SPACE

To hold large size watches

Image: A detailed view highlighting the multiple settings, adjustable spring-action pillow, and ample space for large watches within the Versa G097.

3. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Place the Watch:** Gently compress the spring-action watch pillow and place your automatic watch onto it. Ensure the watch is securely seated. For larger watches, use the additional attachment provided to ensure a snug fit.
3. **Insert Watch Pillow:** Insert the watch pillow with the watch into the winder's rotating compartment.
4. **Connect Power:** Plug the power adapter into the DC input port on the back of the winder, then plug the adapter into a standard electrical outlet.



Image: A close-up view of the watch pillow, designed to securely hold watches.

Adjustable Watch Pillow
Great for Small and Large Wristbands
and Oversize Watches

Pillow without adapter:
6 – 7.25 inches

Pillow with large adapter:
6.75 – 8 inches

Image: A diagram illustrating how the adjustable watch pillow accommodates different wrist sizes and oversized watches.

4. OPERATING INSTRUCTIONS

The Versa G097 features touch button controls for power, rotation direction, and Turns Per Day (TPD) settings. The blue LED indicator lights will show the current selection.

Controls:

- **Power Button:** Turns the winder ON/OFF.
- **Rotation Direction Button:** Cycles through available rotation modes:

- Clockwise (CW)
- Counter-Clockwise (CCW)
- Bi-directional (alternating CW and CCW)
- **TPD (Turns Per Day) Button:** Selects the desired TPD setting. The G097 offers 12 settings, typically ranging from 650 to 1250 TPD.
- **Display Light Button:** Toggles the internal blue display light ON/OFF.

Recommended Settings:

Most automatic watches require between 650 and 850 TPD in a bi-directional rotation. It is recommended to start with these settings. Some specific watch movements may require clockwise only, counter-clockwise only, or higher TPD settings (e.g., 1050 TPD).

Refer to your watch manufacturer's specifications for the precise TPD and rotation direction requirements for your specific watch model. If you encounter issues keeping your watch wound, consult your watch's manual or contact Versa support for assistance in finding the correct setting.

Note: This winder is not compatible with Seiko Kinetic watches.

5. MAINTENANCE

- **Cleaning:** Wipe the exterior of the winder with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Watch Pillow Care:** Ensure the watch pillow is clean and free of debris to prevent scratching your watch.
- **Power Disconnection:** If the winder will not be used for an extended period, disconnect it from the power outlet.
- **Placement:** Place the winder on a stable, level surface away from direct sunlight, extreme temperatures, and high humidity.

6. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|------------------------------------|--|--|
| Winder is not operating. | No power, or power button is off. | Ensure the power adapter is securely plugged into both the winder and the wall outlet. Press the power button to turn the unit on. |
| Watch is not winding sufficiently. | Incorrect TPD or rotation direction settings for your watch. | Consult your watch's manual for specific winding requirements. Adjust the TPD and rotation direction settings on the winder accordingly. Try increasing TPD or switching to bi-directional mode. |
| Winder makes unusual noise. | Watch not seated correctly, or internal issue. | Ensure the watch is properly seated on the pillow and the pillow is correctly inserted into the winder. If the noise persists, contact customer support. |

7. SPECIFICATIONS

- **Model Name:** G097
- **Product Dimensions:** 5.75 x 5.75 x 5.75 inches
- **Item Weight:** 1.43 Pounds
- **Power Source:** Battery Powered (via adapter)
- **Material:** Plastic
- **Manufacturer:** Versa
- **UPC:** 818404020544

8. WARRANTY AND SUPPORT

Warranty:

The Versa G097 Watch Winder comes with a **1-year limited manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support:

For technical assistance, troubleshooting, or warranty claims, please contact Versa customer support. You can find contact information on the official Versa website or through your retailer.