

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gaggia](#) /
- › [Gaggia Coffee Cleaning Tablets Instruction Manual](#)

Gaggia 21001686

Gaggia Coffee Cleaning Tablets Instruction Manual

Model: 21001686

INTRODUCTION

Gaggia Coffee Cleaning Tablets are designed to maintain the optimal performance and longevity of your Gaggia espresso machine. These non-toxic and biodegradable tablets effectively remove coffee residue and oils that accumulate in the brew group and other internal components, ensuring consistently high-quality coffee.





Image: Gaggia Coffee Cleaning Tablets packaging.

SAFETY INFORMATION

Please read all safety warnings on the product packaging before use. Keep out of reach of children. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. Do not ingest. Store in a cool, dry place.



Prodotto per la pulizia delle macchine per il caffè



(IT) (CH) Attenzione! Contiene carbonato di potassio. Può irritare le vie respiratorie. In caso di consultazione di un medico, tenere a disposizione il contenitore o l'etichetta del prodotto. Tenere fuori dalla portata dei bambini. In caso di malessere, contattare un CENTRO ANTIVELENI o un medico. Il sistema di pulizia del circuito del latte Saeco contiene carbonato di potassio, potassio pirofosfato, sodio gluconato e (C16-C18) alcol etossilati. Questo prodotto contiene meno del 5% di tensioattivi non ionici e dal 15% al 30% di fosfati.

(EN) Warning! Contains potassium carbonate. May cause respiratory irritation. If medical advice is needed, have product container or label at hand. Keep out of reach of children. Call a POISON CENTER or doctor/physician if you feel unwell. Saeco Milk Circuit Cleaner contains potassium carbonate, potassium pyrophosphate, sodium gluconate, and C16-C18

ethoxylated alcohols. This product contains less than 5% non-ionic surfactants and 15% or over but less than 30% phosphates.

(DE) (AT) (CH) Achtung! Enthält Kaliumcarbonat. Kann die Atemwege reizen. Ist ärztlicher Rat erforderlich, Verpackung oder Kennzeichnungsetikett bereithalten. Darf nicht in die Hände von Kindern gelangen. Bei Unwohlsein GIFTINFORMATIONSZENTRUM oder Arzt anrufen. Der Saeco Reiniger für den Milchkreislauf enthält Kaliumcarbonat, Pyrophosphat, Natriumgluconat und (C16-C18) ethoxylierte Alkohole. Dieses Produkt enthält weniger als 5% nichtionische Tenside and zwischen 15% und 30% Phosphate.

(FR) (BE) (CH) Attention! Contient du carbonate de potassium. Peut irriter les voies respiratoires. En cas de consultation d'un médecin, garder à disposition le récipient ou l'étiquette. Tenir hors de portée des enfants. Appeler un CENTRE ANTIPOISON ou un médecin en cas de malaise. Le produit de nettoyage pour circuit de lait Saeco contient du carbonate de potassium, du pyrophosphate de potassium, du gluconate de sodium et des alcools éthoxylés (C16-C18). Ce produit contient moins de 5% de tensioactifs non ioniques et 15% ou plus mais moins de 30% de phosphates.

(ES) Atención. Contiene carbonato de potasio. Puede irritar las vías respiratorias. Si se necesita consejo médico, tener a mano el envase o la etiqueta. Mantener fuera del alcance de los niños. Llamar a un CENTRO DE INFORMACION TOXICOLOGICA o a un médico en caso de malestar. **(ES)** 91-5620420. El limpiador del circuito de leche de Saeco contiene carbonato de potasio, pirofosfato de potasio, gluconato de sodio y alcoholes etoxilados (C16-C18). Este producto contiene menos de un 5% de tensoactivos no iónicos y un 15% o más, pero menos del 30%, de fosfatos.

(NL) (BE) Waarschuwing! Bevat kaliumcarbonaat. Kan irritatie van de luchtwegen veroorzaken. Bij het inwinnen van medisch advies, de verpakking of het etiket ter beschikking houden. Buiten het bereik van kinderen houden. Bij onwel voelen een ANTIGIFCENTRUM of een arts raadplegen. Het reinigingsmiddel voor het melkdoorloopsysteem van Saeco bevat kaliumcarbonaat, kalium pyrofosfaat, natriumgluconaat en vetalcohol (C16-C18). Dit product bevat minder dan 5% niet-ionische oppervlakte-actieve stoffen en 15% à 30% fosfaten.

(PL) Uwaga! Zawiera węglan potasu. Może powodować podrażnienie dróg oddechowych. W razie konieczności zasięgnięcia porady lekarza należy pokazać pojemnik lub etykietę. Chronić przed dziećmi. W przypadku złego samopoczucia skontaktować się z OŚRODKIEM ZATRUC lub z lekarzem. Srodek do czyszczenia obiegu mleka Saeco zawiera węglan potasu, pirofosforan potasu, glikonian sodu i alkohole oksyetylenowane (C16-C18). Produkt zawiera surfaktanty niejonizujące (mniej niż 5%) oraz 15% lub więcej (ale maks. 30%) fosfatów.

(PT) Atenção. Contém carbonato de potássio. Pode provocar irritação das vias respiratórias. Se for necessário consultar um médico, mostre-lhe a embalagem ou o rótulo. Manter fora do alcance das crianças. Caso sinta indisposição, contacte um CENTRO DE INFORMAÇÃO ANTIVENENOS ou um médico. **(PT)** 808250143. O agente de limpeza para circuitos de leite da Saeco contém carbonato de potássio, pirofosfato de potássio, gluconato de sódio e álcoois etoxilados C16-C18. Este produto contém menos de 5% de surfactantes não iónicos e 15% ou mais de fosfato, mas sem ultrapassar os 30%.



21001685

8 012335 000176 >

SETUP

Before initiating the cleaning cycle, ensure your espresso machine is powered on and has sufficient water in the reservoir. Refer to your specific Gaggia espresso machine's user manual for detailed instructions on accessing the cleaning cycle menu. Typically, you will need to navigate to the 'Clean' or 'Maintenance' section.

1. Ensure the water tank is filled with fresh water.
2. Empty the drip tray and coffee grounds container.
3. Place an empty container (minimum 0.5 liter capacity) under the coffee spout to collect the cleaning solution.

OPERATING INSTRUCTIONS

Follow these steps to clean your Gaggia espresso machine using the cleaning tablets:

1. Access the 'Clean' or 'Maintenance' menu on your Gaggia espresso machine's display.
2. Select the 'Brew Group Clean' option.
3. When prompted, open the pre-ground coffee compartment or the designated cleaning tablet slot.
4. Insert one Gaggia Coffee Cleaning Tablet into the compartment.
5. Close the compartment securely.
6. Press 'Start' or confirm the cleaning cycle on your machine's display.
7. The machine will automatically perform the cleaning cycle, which typically takes about 5 minutes. Follow any additional on-screen prompts.
8. Once the cycle is complete, empty and rinse the drip tray and coffee grounds container.

For a visual guide, please watch the instructional video below:

Video: Demonstrating the process of using Gaggia Coffee Cleaning Tablets to clean an espresso machine's brew group.

MAINTENANCE

Regular cleaning with Gaggia Coffee Cleaning Tablets is crucial for maintaining the performance and taste of your coffee. It is recommended to perform a cleaning cycle every 2-4 weeks, or as indicated by your machine's maintenance alerts, depending on usage frequency. Consistent cleaning prevents the buildup of coffee oils and residues, which can affect flavor and machine functionality.

- Use for cleaning brew group filters or portafilter.
- Each tablet is capable of removing coffee residue to ensure optimal machine performance.
- Compatible with semi and super-automatic espresso machines.

TROUBLESHOOTING

If you encounter issues during the cleaning process, consider the following:

- **Cleaning Cycle Not Starting:** Ensure all machine components (water tank, drip tray, grounds container) are correctly positioned and the machine is not displaying any other error messages.
- **Tablet Not Dissolving:** Verify that the tablet was placed in the correct compartment as per your

machine's instructions. Some machines require the tablet to be placed directly into the brew group.

- **Machine Still Indicates Cleaning Needed:** If the cleaning indicator persists after a cycle, ensure the cycle completed fully and all prompts were followed. You may need to run another cycle if the machine was heavily soiled.

For persistent issues, consult your Gaggia espresso machine's specific user manual or contact Gaggia customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	0.25 x 0.5 x 5.5 inches
Item Weight	0.32 ounces
Brand	Gaggia
Item Form	Tablet
Scent	Coffee
Specific Uses For Product	Coffee Maker
Material Feature	Biodegradable
Model Number	21001686
UPC	8012335000176

ENVIRONMENTAL INFORMATION

This product is certified 'Compact by Design' by Amazon, indicating a commitment to reducing environmental impact through efficient packaging and design.





Less Packaging



Less Air in Container



More Efficient Shape



Waterless Technology

WARRANTY AND SUPPORT

Gaggia Coffee Cleaning Tablets are designed to work with Gaggia espresso machines. For product-specific inquiries or support related to your Gaggia espresso machine, please refer to the machine's original documentation or visit the official Gaggia website for customer service contact information.

