

Artemide USC-A005015

Artemide Tizio Table Lamp

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Artemide Tizio Table Lamp. Designed by Richard Sapper, this iconic lamp is renowned for its innovative counterweight system and adjustable design, providing precise illumination for various tasks. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your Tizio lamp.

Safety Information

Please read all safety instructions carefully before using the lamp. Retain this manual for future reference.

- **Electrical Safety:** Always unplug the lamp from the power outlet before cleaning, performing maintenance, or replacing the bulb. Do not operate the lamp with a damaged cord or plug.
- **Heat Warning:** The halogen bulb and surrounding lamp head can become very hot during operation. Avoid touching these parts while the lamp is on or immediately after turning it off. Allow sufficient time for cooling.
- **Correct Bulb Type:** Use only the specified bulb type (GY6.35, 35W Halogen). Using an incorrect bulb may cause overheating or damage to the lamp.
- **Indoor Use Only:** This lamp is designed for indoor use in dry locations. Do not expose it to water or high humidity.
- **Stable Placement:** Ensure the lamp base is placed on a stable, level surface to prevent tipping.
- **Ventilation:** Do not cover the lamp head or bulb, as this can lead to overheating. Ensure adequate air circulation around the lamp.

Package Contents

Please verify that all components are present and undamaged upon unpacking:

- Artemide Tizio Table Lamp Unit (Base, Arms, Lamp Head)
- Halogen Bulb (GY6.35, 35W)
- Power Cord
- Instruction Manual

Setup

Assembly

The Artemide Tizio lamp typically comes pre-assembled or requires minimal setup. Follow these steps for initial preparation:

1. Carefully remove all packaging materials from the lamp.
2. Place the lamp base on a stable, flat surface where you intend to use it.
3. If the halogen bulb is not pre-installed, gently insert the GY6.35 bulb into its socket in the lamp head. Avoid touching the glass part of the bulb with bare hands, as oils can reduce bulb life. Use a clean cloth or glove.
4. Connect the power cord to the lamp base and then plug it into a standard electrical outlet.



Image: Detailed view of the lamp's articulated structure, highlighting the base and arm connections.

Placement

Position the lamp on a desk, table, or other appropriate surface. Ensure there is enough space for the arms to extend and adjust freely without obstruction. The lamp's balanced design allows for a wide range of motion.



Image: Multiple Tizio lamps demonstrating their adjustable nature and various configurations.

Operating Instructions

Power On/Off

The Artemide Tizio lamp features a touch-sensitive switch, typically located on the base or a discreet part of the arm. Gently touch the designated area to turn the lamp on or off.

Adjusting the Lamp

The lamp's signature feature is its fully adjustable, balanced electrical conductor arms. These arms allow you to effortlessly position the lamp head to direct light precisely where needed. The lamp head also features an adjustable shade for further light control.

- Gently grasp the lamp head or the arms to move them into the desired position. The counterweight system will hold the lamp in place.
- The lamp head can be tilted and rotated to fine-tune the direction of light.



Image: The Tizio lamp positioned with its arms extended, illustrating its flexibility for directing light.

Maintenance

Cleaning

To maintain the appearance and functionality of your lamp:

- Always unplug the lamp before cleaning.

- Use a soft, dry cloth to wipe down the lamp's surfaces.
- Avoid using abrasive cleaners, solvents, or polishes, as these can damage the finish.
- For the glass lens, a slightly damp cloth can be used, followed by a dry cloth to prevent streaks.

Bulb Replacement

When the bulb needs replacement:

1. Ensure the lamp is unplugged and has completely cooled down.
2. Carefully remove the protective glass lens or cover from the lamp head, if applicable.
3. Gently pull out the old GY6.35 halogen bulb from its socket.
4. Insert a new GY6.35, 35W halogen bulb. Remember to handle the new bulb with a clean cloth or glove to avoid leaving fingerprints, which can shorten bulb life.
5. Replace the protective glass lens or cover.
6. Plug the lamp back in and test its operation.

Troubleshooting

If you encounter issues with your Artemide Tizio Table Lamp, refer to the following table:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, faulty bulb, or switch issue.	Ensure the lamp is securely plugged in. Check if the outlet is functional. Replace the bulb. If the issue persists, contact support.
Lamp gets very hot.	Normal operation for halogen bulbs, or incorrect bulb wattage.	Halogen bulbs naturally produce significant heat. Ensure proper ventilation and do not touch the lamp head when hot. Verify you are using a 35W GY6.35 bulb.
Light is dim or flickers.	Aging bulb, loose connection, or dirty reflector.	Replace the bulb. Check the bulb's connection in the socket. Clean the inner high-efficiency anodized aluminum reflector with a soft, dry cloth.
Arms do not hold position.	Wear in the counterweight mechanism.	This is rare for a properly maintained lamp. Ensure all pivot points are clean. If the issue persists, contact Artemide customer service for assistance.

Specifications

Feature	Detail
Brand	Artemide
Model	Tizio Table Lamp (Model: USC-A005015)
Design	Richard Sapper

Feature	Detail
Lamp Type	Table Lamp
Color	Black
Material	Alloy Steel, Aluminum, Glass
Finish Type	Painted
Base Material	Aluminum
Bulb Base	GY6.35
Light Source Type	Halogen
Wattage	35 watts
Voltage	35 Volts
Switch Type	Touch
Special Feature	Adjustable, Balanced Electrical Conductor Arms
Product Dimensions	39"D x 25"W x 39"H (Adjustable)
Item Weight	4 Pounds
Indoor/Outdoor Usage	Indoor
Certification	ETL, UL

Warranty and Support

Warranty information for your Artemide Tizio Table Lamp is typically provided with your purchase documentation or can be found on the official Artemide website. Please retain your proof of purchase for warranty claims.

For technical support, replacement parts, or further assistance, please contact Artemide customer service through their official website or the retailer from whom you purchased the lamp.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question