

Luxor RDSTC11RD

Luxor STC Series 2-Shelf Tub Cart User Manual

Model: RDSTC11RD

INTRODUCTION

Thank you for choosing the Luxor STC Series 2-Shelf Tub Cart. This manual provides essential information for the safe assembly, operation, and maintenance of your new utility cart. Please read these instructions thoroughly before use and retain them for future reference.



Image: The Luxor STC Series 2-Shelf Tub Cart, showcasing its two shelves and overall structure.

SAFETY INFORMATION

Always follow basic safety precautions when using this product to reduce the risk of injury or damage.

- Do not exceed the maximum weight capacity of 300 lbs (100 lbs per shelf).
- Ensure all casters are locked when the cart needs to remain stationary.
- Distribute weight evenly across the shelves to maintain stability.
- Avoid placing hot items directly on the plastic shelves without proper insulation.
- Keep hands and feet clear of moving parts, especially during assembly and when moving the cart.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 2 x High-Density Polyethylene Shelves
- 4 x Leg Posts
- 4 x Heavy-Duty 4-inch Casters (2 with brake)
- Assembly Hardware (screws, nuts, washers)
- Assembly Tool (if included)

ASSEMBLY INSTRUCTIONS

The Luxor STC Series Tub Cart is designed for easy assembly. Follow these steps:

1. **Attach Casters:** Secure the four heavy-duty 4-inch casters to the bottom shelf. Ensure the two casters with brakes are positioned on the same side for easy access. Use the provided hardware and tighten securely.
2. **Install Leg Posts:** Insert the four leg posts into the designated slots on the bottom shelf. Ensure they are fully seated and aligned.
3. **Attach Top Shelf:** Place the top shelf onto the leg posts, aligning the holes. Press down firmly until the shelf is securely in place.
4. **Secure Shelves:** Use the remaining hardware to secure the shelves to the leg posts. Tighten all screws evenly to ensure stability.
5. **Final Check:** Verify that all connections are tight and the cart is stable before use.

Your browser does not support the video tag.

Video: This video demonstrates the assembly and features of a 2-shelf heavy-duty plastic utility cart, including its 360-degree rotating wheels with lockable brakes, solid construction, and multi-compartment storage handle.

OPERATING INSTRUCTIONS

Moving the Cart

To move the cart, unlock the casters by disengaging the brakes on the two braking wheels. Use the molded push handle on the top shelf to guide the cart to your desired location. The 360-degree rotating wheels allow for easy maneuverability in tight spaces.

Loading the Cart

The cart has a total weight capacity of 300 lbs, with each shelf supporting up to 100 lbs. Distribute items evenly across the shelves to maintain balance and prevent tipping. The tub shelves are 2 3/4 inches deep, providing a secure area for items.

MAINTENANCE

Regular maintenance will prolong the life of your utility cart:

- **Cleaning:** Wipe down the cart with a damp cloth and mild detergent as needed. The high-density polyethylene material resists stains, scratches, dents, and rust.

- **Casters:** Periodically check the casters for debris or hair that may impede movement. Clean as necessary. Ensure caster bolts remain tight.
- **Storage:** Store the cart in a dry, temperate environment when not in use.

TROUBLESHOOTING

Problem	Solution
Cart is difficult to move.	Check if caster brakes are engaged. Inspect casters for debris or damage. Ensure weight is evenly distributed.
Cart feels unstable.	Verify all assembly hardware is securely tightened. Ensure weight does not exceed capacity and is evenly distributed.
Casters are not locking properly.	Check for obstructions in the brake mechanism. Ensure the brake lever is fully engaged.

SPECIFICATIONS

Feature	Detail
Model	RDSTC11RD
Dimensions (H x W x D)	37.5" x 24" x 18"
Material	High-Density Polyethylene Structural Foam
Number of Shelves	2
Shelf Clearance	26"
Tub Shelf Depth	2.75"
Weight Capacity	300 lbs (100 lbs per shelf)
Casters	4 x 4-inch Heavy-Duty (2 with brake)
Color	Red
Assembly Required	Yes

WARRANTY AND SUPPORT

Warranty Information

This Luxor STC Series Tub Cart comes with a Lifetime Warranty, covering defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, missing parts, or warranty inquiries, please contact Luxor customer support. Refer to the product packaging or the manufacturer's official website for the most current contact information.

